

EMD-1ZW Electricity Power Reader

Introduction

The Energy Meter is a Z-Wave Electricity Power reader designed to be used with a digital watt hour meter supporting LED pulse output port. The E-meter reads the LED pulse from the watt hour meter and transmits the data to Z-Wave network coordinator.

The Energy Meter is a Z-Wave enabled device and is fully compatible with any Z-Wave enabled network.

Z-Wave is a wireless communication protocol that uses a low-power RF radio. By taking advantage of the Z-Wave mesh network, commands can be routed to their destination via intermediary "listening" Z-Wave products.

Parts Identification

1. LED indicator

The LED indicator lights up in the following conditions:

- Flashes once:
The Energy Meter is transmitting a signal.
- Flashes twice:
The Energy Meter is successfully added into a Z-Wave network.

2. Mounting Holes

3. Battery compartment Cover

Remove the cover to insert 2 Alkaline AA 1.5V batteries to power up the Energy Meter.

4. LED Sensor Jack


Plug the Sensor into this jack to receive LED signal from the watt hour meter.

5. Function Button

- Press the button 3 times within 1.5 seconds to send a learn code.
- Press and hold the button for 10 seconds to factory reset.

6. IR Sensor

Attach the IR sensor to the watt hour meter, and plug into the IR sensor Jack to read data from the watt hour meter.



Features

● **Battery and Low Battery Detection**

The Energy Meter uses 2 Alkaline 1.5V batteries as its power source. It features a Low Battery Detection function. When the battery voltage is low, the Energy Meter will transmit a Low Battery signal to notify the Z-Wave network coordinator.


The Energy Meter will report its battery percentage to the Control Panel respectively at 100%, 75%, 50%, 25%. If the battery voltage is low (25%), a Low Battery signal will be sent to the Control Panel to notify the user.

When changing batteries, after removing the old batteries, press the function button a couple times to fully discharge before inserting new batteries.

● **Adding Device (Inclusion)**

This product can be included and operated in any Z-Wave network with other Z-Wave certified devices from other manufacturers and/or other applications. All non-battery operated nodes within the network will act as repeaters regardless of vendor to increase the reliability of the network.

- Insert batteries to power on the E-meter.
- Put the Z-Wave control panel into **Inclusion mode** (please refer to the Z-Wave control panel manual).
- Within 1.5 seconds, press the Function Button 3 times.
- Refer to the operation manual of the Z-Wave Gateway or Control Panel to complete the adding process.
- If the device has already been added (included) into another Z-Wave Gateway/Control Panel, or if the device is unable to be added into the current Z-Wave Gateway/Control Panel, try removing it first (see **Removing Device**).



● **Removing Device (Exclusion)**

The device must be removed from existing Z-Wave network before being added into another.

Exclusion Mode

- Put the Z-Wave Gateway or Control Panel into **Exclusion mode** (please refer to the Z-Wave or control panel manual).
- Within 1.5 seconds, press the Function Button 3 times and the device will be removed from the Z-Wave network.

Factory Reset

Factory resetting the device will restore it to factory default settings (i.e. not included into any Z-Wave network). Please only use this procedure if the Z-Wave Gateway or Control Panel is lost or otherwise inoperable.

- Press and hold the Function Button of the device for 10 seconds to factory reset.


Operation

● **Installation**


Wat Hour Meter connection.

A Washer with double-side adhesive tape is provided to connect the IR sensor to watt hour meter

1. Locate the LED pulse output port on the watt hour meter, remove the double-side adhesive tape cover on the washer and apply the washer around the LED port.



2. The sensor head has built-in magnet. Apply the sensor head to the washer to attach the sensor to LED port for reading LED pulse from watt hour meter



Wall Mounting

The Energy Meter has two mounting holes on the back for wall mounting.

1. Mark the mounting location on the wall according to mounting hole position
2. Install two screws at the mounting location.
3. Hook the Energy Meter onto the screws.

● **Energy Consumption Monitor**

- The Energy Meter reads LED pulse from the watt hour meter to monitor energy consumption.
- The Energy Meter will transmit current wattage every 5 minutes to Z-Wave Gateway/Control Panel
- The Energy Meter transmits a power data to coordinator whenever accumulated power usage increases by 1kW/hr.
- To clear the Energy Meter of its accumulated power consumption data, follow steps below:
 1. Remove the batteries to power down.
 2. Press and hold the function button and reinsert batteries again when holding down the button.
 3. Keep holding the button and release after 3 seconds. The accumulated power consumption data will be cleared.

Z-Wave Information

Device Type: Whole Home Meter-Simple

Role Type: Listening Sleeping Slave (LSS)

Maximum number of devices that can be added to the group: 3

Command Class Support/Control

Mandatory CC Support:

- Association CC, v2
- Association Group Information CC
- Battery CC
- Device Reset Locally CC
- Manufacturer Specific CC, v2
- Meter CC, V2
- Version CC, v2
- Z-Wave Plus Info CC, v2
- Power Level CC,
- Firmware Update CC, v2
- CRC16 Encap CC

Z-Wave's Groups (Association Command Class Version 2)

Group 1 for "LifeLine":

- Battery CC (COMMAND_CLASS_BASIC)
- Device Reset Locally CC
- Meter CC