



USER GUIDE

1 OVERVIEW OF THE LOCKSET



2 HOW TO LOCK / UNLOCK / PROGRAM THE LOCKSET

1 HOW TO LOCK / UNLOCK THE LOCKSET



⚠ The screen is temporarily disabled after 4 consecutive incorrect entries.

2 HOW TO PROGRAM THE LOCKSET

BASIC SETTINGS

Change Programming Code	<ul style="list-style-type: none"> Programming Code can be used to program or unlock the lockset. The default Programming Code is "12345678". 	Press [SET] for 1 second.	Programming Code (4-8 digits)	→ # → 1 → 0 → # →	New Programming Code(4-8 digits)	→ # →	Same New Programming Code(4-8 digits)	→ # →
Add a User Code(S)	<ul style="list-style-type: none"> User Code can be used to unlock the lockset. User Code capacity: 25 sets (4-8 digits). 	Press [SET] for 1 second.	Programming Code (4-8 digits)	→ # → 2 → 0 → # →	New User Code (4-8 digits)	→ # →	Same New User Code (4-8 digits)	→ # →
Delete individual User Code(S)	<ul style="list-style-type: none"> Delete individual User Code(s). 	Press [SET] for 1 second.	Programming Code (4-8 digits)	→ # → 3 → 0 → # →	User Code	→ # →	Same User Code	→ # →
Delete ALL User Codes	<ul style="list-style-type: none"> Delete ALL User Codes at once. 	Press [SET] for 1 second.	Programming Code (4-8 digits)	→ # → 4 → 0 → # → C				

ADVANCED SETTINGS

Add Single-use User Code(S)	<ul style="list-style-type: none"> Single-use User Code can only be used once to unlock the lockset. Single-use User Code capacity: 4 sets (4 digits). 	Press [SET] for 1 second.	Programming Code (4-8 digits)	→ # → 2 → 1 → # →	Single-use User Code (4 digits)	→ # →	Same Single-use User Code (4 digits)	→ # →
Guiding Code	<ul style="list-style-type: none"> Guiding Code is a set of random codes to be entered prior to any User Code to prevent code probing by placing finger prints on every button making code discovery more difficult. 	Press [SET] for 1 second.	Programming Code (4-8 digits)	→ # → 2 → 2 → # →	Turn On	1 → #	Turn Off	0 → #
Vacation Mode	<ul style="list-style-type: none"> Vaction mode temporarily disable ALL User Codes. 	Press [SET] for 1 second.	Programming Code (4-8 digits)	→ # → 5 → 0 → # →	Turn On	1 → #	Turn Off	0 → #
Volume Control	<ul style="list-style-type: none"> Turn on / off door lock operation volume. Volume is always on in the programming mode. 	Press [SET] for 1 second.	Programming Code (4-8 digits)	→ # → 6 → 0 → # →	Turn On	1 → #	Turn Off	0 → #
Auto-lock	<ul style="list-style-type: none"> Auto-lock is disabled by default. 	Press [SET] for 1 second.	Programming Code (4-8 digits)	→ # → 8 → 0 → # →	Turn On	1 → #	Turn Off	0 → #
Auto-lock Delay Timer	<ul style="list-style-type: none"> Default Auto-lock Delay Timer : 10 seconds. Auto-lock Delay Timer range: 10 -99 seconds. 	Press [SET] for 1 second.	Programming Code (4-8 digits)	→ # → 7 → 0 → # →	Enter New Amount (10 - 99)	→ #		
Include / Exclude to Z-Wave network	<ul style="list-style-type: none"> Turn on inclusion / exclusion mode at your Z-Wave controller when including / excluding the lock. Refer to your Z-Wave controller instruction for more information. 	Press [SET] for 1 second.	Programming Code (4-8 digits)	→ # → 9 → 0 → # →	Include / Exclude successfully (beep x 1)		OR	Include / Exclude unsuccessfully (beep x 3)

⚠ The lockset will exit the programming mode and resume to the stand-by status if no input is made in 10 seconds.
 • 3 Beeps means something was entered incorrectly. Please redo the step again.

