IQ PANEL 2 / IQ PANEL 2+

INSTALLATION MANUAL

Qolsys IQ Panel 2/2+
Software Version 2.6.0



The Qolsys IQ Panel 2 & IQ Panel 2+ is a 7" touchscreen built with an Android operating system, providing full security and smart home functionality in an easy to use interface.

INCLUDED IN BOX

IQ Panel 2/2+



Power Supply

Table Stand



ABOUT THIS GUIDE

This document outlines the basic hardware specifications and software directions to install and customize the IQ Panel 2 & IQ Panel 2+. Note that the information presented is not comprehensive, but is specifically dedicated to those menus, features, and systems accessible solely to those with the proper installation code. Features accessible to users and installers alike are outlined in the IQ Panel 2 User Guide. The information contained is confidential and proprietary, and is solely owned by Qolsys Inc. Any reproduction, modification or distribution without permission is strictly prohibited.

SUPPORT

QUESTIONS?

Contact us at
techsupport@qolsys.com

TABLE OF CONTENTS

PANEL OVERVIEW
5- Exterior Front
6- Exterior Back
7- Interior

INSTALLING THE PANEL
9- Wall Mount Option
10- Table Stand Option
11- Wiring Diagram
12- Powering the Panel

USER INTERFACE
14- Home Screen Overview
15- Message Center
16- Settings Tray

PROGRAMMING
18- Screen Lock
19- Settings
21- Advanced Settings
22- Setup Wizard
26- Installation
28- Installer/Dealer Settings
37- System Logs
38- Siren and Alarms
41- Security and Arming
44- Camera Settings
46- Z-Wave Device List
47- Sound
51- Partitions
52- Local Automation

SECURITY SENSORS
55- Security Sensors
56- Auto Learn Sensor
57- Add Sensor
58- Scan QR Code
59- Partition Name
60- Sensor Type
61- Sensor Groups
77- Sensor Name
79- Chime Type
80- Voice Prompts
81- Source
82- Edit Sensor
83- Delete Sensor
84- Sensor Status
86- Panel Motion Settings

WI-FI DEVICES
88- Wi-Fi Devices
90- Access Point Settings
91- AP Connected Devices
92- IQ Remote Devices
93- 3rd Party Connections

Z-WAVE™ DEVICES
95- Z-Wave Devices
96- Add Device
97- Clear Device
98- Delete Failed Device
99- Remove All Devices
100- View/Edit Associations
101- Z-Wave Settings
103- SmartStart
104- Provisioning List

BLUETOOTH DEVICES
106- Bluetooth Devices
107- Add Device
108- Edit Device
109- Delete Device
110- Remove All Devices
111- Settings
112- Add Speaker

SYSTEM TESTS
114- System Tests
116- Wi-Fi Test
117- Sensor Test
121- Cellular Test
122- Image Sensor Config
123- Z-Wave Test
124- Rediscover Network
125- Neighbor Info
126- Counters
128- Z-Wave Diagnostics
129- Advanced Z-Wave Diag
130- PowerG Test
131- Zigbee Test
132- Panel Glass Break Test
135- Dual Path Test
136- Daughter Cards Test
137- Panel Test

CUSTOMIZATION
139- User Management
140- Dealer Branding
141- Contact Info
142- Load Custom Logo
143- On-Screen Billboard
144- Load Help Videos
145- Connecting to Wi-Fi
146- Weather
147- Photo Frame
150- Load Images from SD Card

MAINTENANCE
152- Upgrade Software
153- Upgrade Software Using Wi-Fi
154- Software Update Via SD Card
155- Automatic Background Check
156- Battery Replacement

TROUBLESHOOTING
158- About
161- Power Down
162- Panel Reboot
163- Hard Reboot
164- Panel Test Troubleshooting
166- Cannot Load Help Videos

LEGAL
168- Important Information

SPECIFICATIONS
177- Specifications
179- Supported S-Line Sensors
180- Supported PowerG Sensors
181- Supported 433 DSC Sensors
182- Supported 433 AT&T Sensors

PANEL OVERVIEW

Warning: This Product should be installed in accordance with the National Fire Alarm Code, ANSI/NFPA 72, (National Fire Protection Association, Batterymarch Park,Quincy, MA 02269) and with National Electric Code, ANSI/NFPA 70. Printed information describing proper installation, operation, testing, maintenance, evacuation planning, and repair service is to be provided with this Product. In Canada the product shall be installed in accordance with the Standard for the Installation of Residential Fire Warning Systems, CAN/ULC-S540.

Warning: For Canadian installations this Product and all sensors associated with it (collectively, the "System") should be tested once a week. The test shall be performed also with primary DC power de-energized. For recommended smoke detectors maintenance instructions refer to user manual associated with compatible Qolsys model QS5110-P840 smoke detector.

EXTERIOR FRONT



EXTERIOR BACK



INTERIOR



***CAUTION** The battery should NEVER be disconnected without following proper power-down procedures
Failure to comply may result in data corruption, panel failure, and a void of the manufacturer's warranty

INSTALLING THE PANEL

WALL MOUNT OPTION

Note: For UL/ULC Commercial Burg installations (UL1610/ULC-S304 Security Level II compliant) use only wall mount option



1. Insert your thumb or finger under the opening on the back cover and firmly pull up to remove. This cover is not needed for wall mount.

2. Press tabs on the bottom of the panel and pull apart to remove the back plate.

Mount to the wall using appropriate hardware ensuring it is level.



1. Hang the front of the panel with the hanging strap on the back plate as shown above.

2. Using the provided hole in the lower right hand side of the backplate as a template, drill a 1/4" hole in the wall and feed the white RF antenna into the wall.

3. Screw required in break-away wall tamper for UL 1610

IMPORTANT: Not properly routing the RF antenna in the wall will greatly reduce RF sensor range.



Connect the power supply to the barrel jack or to the (+/Red) and (-/Black) terminals if using a custom length wire.

1. Latch the bottom of the panel into place, ensuring the the RF antenna and power wire are routed into the wall and not pinched.

2. Swing the panel up towards the 4 snap tabs at the top.

This product when installed as per these instructions does not present the risk of fire, electric shock, or injury to persons.



Firmly pinch "*diagonally and down*" from the top front of the bezel at all 4 snap tab locations to ensure proper closure. You will hear a "pop" or "snap" sound when each tab has closed properly and the gap along the top should be tightly seated.

IMPORTANT: Not properly closing the panel could result in damage to the backplate or false panel tampers.

TABLE STAND OPTION



Insert your thumb or finger under the opening on the back cover and firmly pull up to remove.



1. With the included power supply and cable, plug the barrel connector into the jack next to the terminals as shown above.
2. Route the cable under the hook next to the battery.
3. Route the cable through the strain relief opening.



Replace the cover by inserting the top first, then while making sure the cable passes under the opening firmly press down on the bottom until the cover "snaps" into place.



Insert table stand dowels into the 2 upper keyholes.

Slide the stand firmly upwards until you hear a "click" from each side.

WIRING DIAGRAM



NOTES

IMPORTANT IF USING CUSTOM LENGTH WIRE:

- 5.5vDC Transformer: Use 18AWG wire no longer than 25ft to ensure sufficient power is received at the panel.

- 7vDC Transformer: Use 18AWG wire no longer than 100ft to ensure sufficient power is received at the panel.

* The minimum permissible wire size shall not be smaller than 22 AWG

** A 7vDC power supply is only supported on panels with hardware revision E or newer.

NOTE: Inputs are used only for residential Burglary applications. SENSOR 1, 2 & EXT SIREN are not permissible in UL1610 installations.

NOTE: Use only UL/ cUL listed external siren in UL/cUL listed installations. Rating:12vDC/300mA

POWERING THE PANEL



Connect power supply.
WARNING! Use a 5vDC to 7vDC Power Supply ONLY

If using the provided cable, the "striped" wire is (+)
Note: Power supply shall be located within same room as control unit

Press and hold the power button on the right side of the panel for 3 seconds to power up.

USER INTERFACE

HOME SCREEN OVERVIEW

The home screen is divided into three sections. The header shows the date & time, today's weather, message center and the Settings tray. The Primary interface shows arming options and sensor status & partition select. The footer shows panic options and additional pages.



MESSAGE CENTER

The header contains the the pull down settings tray, the weather icon, time/date and a message icon in the upper right portion of the screen where you will find Security Provider messages and contact info, alerts, video tutorials and FAQ's

CONTACT US	This is where you will find the Security Provider's Contact Information
VIDEO TUTORIALS	This is where you will find Video Tutorials to help with common questions
ALERTS/ALARMS (1)	This is where you will find Panel Alerts/Alarms notifications
MESSAGES	This is where you will find messages from the Security Provider

SETTINGS TRAY

To access the Settings tray swipe down on the bar at the top of the screen. The Settings tray has quick access to system, battery, Wi-Fi, bluetooth & cellular status as well as volume control, brightness, a lock screen icon and other quick settings.



FIND IT



Swipe down for access

When partitions or screen lock are ENABLED, a Lock Screen icon replaces the Status icon. Touch this icon to switch between partitions.

When partitions are DISABLED, a Status icon resides in the upper left corner of the settings tray. Touch this icon to return to the security page.

PROGRAMMING

SCREEN LOCK

When the "Screen Lock" or "Partitions" setting are enabled, a lock screen will be presented once the panel has been woken from either a touch on the screen or pressing the wake/sleep button on the side of the panel. This prevents unauthorized access to the panel and/or one partition from accessing another as well as managing permissions to "Advanced Settings".

4 DIGIT SCREEN LOCK



6 DIGIT SCREEN LOCK



SETTINGS

The Settings page allows quick access to various simple features & settings that do not require the protection of a Dealer, Installer or Master code to be changed.

Setting	Description
Display	Adjust brightness, font size & 12/24 hour time
SD Card	Mount, unmount and manage SD Cards that are installed in a panel
Weather Temperature	Toggle between Farenheight and Celcius
Status	View the "Current Status" of security sensors: Zone #, Name, Status (Open, Close, Active, Idle, Tamper, Failure), Battery and sensor History. Also view "Alarms" and "History" for security sensors globally
Z-Wave™ Device Status	View the "Current Status" of Z-Wave devices: Name, Type, Status (Normal, Failure), and Battery. Also view "Alerts" and "History" for Z-Wave globally
Other Z-Wave Devices	Shows Z-Wave devices that are learned into the panel but that are not part of the main user interface (Lights, Locks, Thermostats & Garage Doors)

FIND IT



Swipe down for access

SETTINGS

SETTINGS

Setting	Description
EU Events	Display events as required for EN Grade 2. **NOTE:** This icon will only appear when the "En Grade 2" setting is Enabled.
Automation	Add, Edit or mange local lighting automation rules. These rules are separate from any cloud based rules that may be set through Alarm.com. Examples of possible rules are as follows: - **Night**: Turns light on at 7pm and off at 6am - **Evening**: Turns light on at 7pm and off at 11pm - **Front Door**: Turns light on for 15mins when Front Door opens between 5pm and 7am (must have a sensor with the default quick name "Front Door" added in the panel) - **Doorbell**: Turns light on between 5pm and 7am for 15 mins when Doorbell is activated (must have a sensor with the default quick name "Doorbell" added in the panel)
Activity Monitor	Activity Monitor allows access to disarm sensors that are programmed as 24 hours zones, such as Sensor Groups 8, 9 & 25. A valid Master, User or Guest code is required to control 24 hour activity sensors. 2 options are provided: - **Quick Access**: 300 second temporary access - **Deactivate**: Disarms 24 hour sensors until they are re-activated manually
License	Qolsys End User License Agreement
Advanced Settings	Access advanced settings & programming. A valid Dealer (default 2222), Installer (default 1111) or Master Code (default 1234) is required
Smart Energy Optimizer	Shift energy usage to off-peak hours (thermostats) and reduce energy usage during on-peak hours

ADVANCED SETTINGS



To access the Advanced Settings menu pull down the Settings tray at the top of the screen, select "Settings" and then "Advanced Settings". Enter your dealer, installer or master code. The code used to enter Advanced Settings determines the level of access. When using partitions the code entered at the screen lock determines the access level for Advanced Settings.

INSTALLER MENU (1111)

DEALER MENU (2222)

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

* The "Partitions" icon will only appear if Partitions are enabled under Installer/Dealer Settings

SETUP WIZARD

Setup Wizard
The "Easy Install Wizard" is an onscreen, step-by-step programming tool that makes the already fast and intuitive installation process even easier, ensuring every install is consistent and follows best practices.

Launch Wizard
Selecting Launch Wizard will initiate the Easy Setup Wizard based on the page configuration chosen.

Wizard Settings
Choose which pages you want to be shown during the Wizard walkthrough. Select Advanced or Simple sensor setup.



FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SETUP WIZARD

LAUNCH WIZARD

Launch Wizard

Selecting Launch Wizard will initiate the Easy Setup Wizard based on the page configuration chosen in Wizard Settings. Available pages are: Welcome, Network, System Check, Security, Sensor Test, Panel Glass Break, Z-Wave, Bluetooth, IQ Remote, Users, Dealer & Update.



FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SETUP WIZARD

LAUNCH WIZARD

WIZARD SETTINGS

Wizard Settings
Choose which pages you want to be shown during the Wizard walkthrough.
Select Advanced or Simple sensor setup

Setting	Default	Description
Update	Enabled	Show the option to check for software updates in the Setup Wizard
Security	Enabled	Show the option to add and edit security sensors in the Setup Wizard
Security Sensor Setup Format	Advanced	Determines whether the Security page of the Setup Wizard shows Advanced Sensor pairing (PRO) or Simple Sensor pairing (DIY)
Panel Glass Break	Enabled	Show the option to enable or disable the panel glass break in the Setup Wizard
Z-Wave	Enabled	Show the option to include and edit Z-Wave devices in the Setup Wizard
Bluetooth	Enabled	Show the option to pair Bluetooth devices in the Setup Wizard

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SETUP WIZARD

WIZARD SETTINGS

WIZARD SETTINGS

Setting	Default	Description
Users	Enabled	Show the option to add users in the Setup Wizard
Dealer	Enabled	Show the option to add and edit Dealer Contact Info in the Setup Wizard
IQ Remote	Enabled	Show the option to pair IQ Remotes in the Setup Wizard **NOTE:** IQ Remote is not used in UL/cUL listed applications
Sensor Signal Test	Enabled	Activate the sensor test as part of the Setup Wizard
Download Mobile App	Enabled	Show the option to scan a QR code and download the Alarm.com app

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SETUP WIZARD

WIZARD SETTINGS

INSTALLATION

If Dealer Contact info is not previously filled out or pushed from Alarm.com, a pop up is generated when accessing the "Installation" icon, requiring that dealer contact information to be entered. This information is used to populate the "Contact Us" tab in the Message Center. **NOTE**: Company Name and Company Phone Number are required and must be filled out to continue with panel programming.



FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

INSTALLATION

INSTALLATION

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

INSTALLATION

INSTALLER/DEALER SETTINGS

Installer/Dealer Settings
Change panel settings like supervisory times, power and cell loss timeout and SIA settings.

Setting	Default	Description
Account Number	blank	Security provider account number (up to 10 characters)
Power Management	Enabled	An energy-saving function when running on battery power only
SIA Power Restoration	Disabled	Turn on or off sensor hold for 60 seconds during power restore
ULC Commercial Power Restoration	Disabled	When enabled, ignore all sensor activity for 120 seconds after power restoration
Loss of Supervisory Signals for Emergency Sensors	4	Select the length in hours (4, 12, 24) before reporting a loss of supervision on life safety devices. **NOTE:** For UL/cUL Resi Fire and UL Commercial Burg (UL1610) the wireless supervision window for Emergency sensors (Smoke, Heat & CO Detectors) shall be set to 4h
Loss of Supervisory Signals for PowerG Emergency Sensors	4	Select the length of time (20, 30 min, 1, 2, 4, 12, 18 hours) before reporting a loss of supervision on PowerG life safety devices. **NOTE:** For UL/cUL Resi Fire and UL Commercial Burg (UL1610) the wireless supervision window for Emergency sensors (Smoke, Heat & CO Detectors) shall be set to 4h

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

INSTALLATION

INSTALLER/DEALER SETTINGS

*** Additional options available only through the Dealer Code.**

INSTALLER/DEALER SETTINGS

Setting	Default	Description
Loss of Supervisory Signals for Z-Wave	4	Select the length in hours (4, 24) before reporting a loss of supervision on Z-Wave Sirens.
Loss of Supervisory Signals for Non Emergency Sensors	24	Select the length in hours (4, 12, 24) before reporting a loss of supervision on security devices. **NOTE:** For UL/cUL Resi Fire and UL Commercial Burg (UL1610) the wireless supervision window for Non-Emergency sensors (all intrusion sensors) shall be set to 4h
Loss of Supervisory Signals for PowerG Non Emergency Sensors	24	Select the length of time (20, 30 min, 1, 2, 4, 12, 18 hours) before reporting a loss of supervision on PowerG security devices. **NOTE:** For UL/cUL Resi Fire and UL Commercial Burg (UL1610) the wireless supervision window for Non-Emergency sensors (all intrusion sensors) shall be set to 4h
Loss of Cell Signal Timeout	30	Select the length in minutes (10-120) before reporting a loss in cellular signal. **NOTE:** For UL Commercial Burg (UL1610) the cell supervision is hardcoded to 200s
Communication Test	Monthly	Choose Never, Daily, Weekly or Monthly when enabling the communication test.
Communication Test Start Time	Randomized	Select the time of day that the panel will send its Communication Test. If no time is selected the time will automatically be randomized.

INSTALLER/DEALER SETTINGS

Setting	Default	Description
SIA Limits **NOTE**: For UL resi burg set entry delay to 45 sec and exit delay to max 120 sec. For UL Commercial Burg (UL1610) maximum entry and exit delay should not exceed 60 sec. **NOTE:** For ULC Security Level I (resi burg) set entry delay to 180 sec. For ULC Security Level II (commercial burg) set entry delay to 60 sec and exit delay to 45 sec max.	Enabled	When **enabled**, the range for entry and exit delays is as follows: -Entry delay: 30-240 seconds, Exit Delay: 45-254 seconds When **disabled**, the range for entry and exit delays are as follows: -Entry delay: 5 to 240 seconds, Exit delay: 5 to 254 seconds When **enabled** the range for Dialer Delay is: 15 to 45 seconds When **disabled** the range for Dialer Delay is: 0 to 254 seconds
EN Grade 2 **NOTE:** This feature is not used in UL/cUL listed applications	Disabled	The setting enables EN Grade 2 compliance on the Panel. When Enabled, the following behaviors and/or settings are changed automatically: - Entry Procedure (EU) - follows entry procedures and alarm transmission delays specified by EN 50131 - Disables the "Auto Bypass" setting so that the Panel will protest arming when sensor and panel trouble conditions are present (i.e. Open, Tamper, Low Battery, etc) - Trouble condition alerts can not be acknowledged until the condition is resolved - Trouble beeps are expanded to include fault indications required by EN 50131 - "Screen Lock" setting is enabled automatically. Screen will lock 30 seconds after Disarming - A new icon called "EU Events" is added to the "Settings" page which records mandatory history events specified by EN 50131. - "Loss of Supervisory Signals for PowerG Non-Emergency Sensors" is set to 2 hours by default. - "LED Indicator" setting is Disabled automatically. - "Partitions" setting is not available. - "Dealer or Installer Access Requires User Permission" setting is Enabled automatically.

INSTALLER/DEALER SETTINGS

Setting	Default	Description
EU Event Swinger Shutdown Count	3	Determines the number of times a particular event will record to "EU Events" log before shutdown. The count (3-10) will reset after and arm or disarm event. **NOTE:** This setting is greyed out and not selectable unless EN Grade 2 is Enabled.
Favorite Languages	English/Español	Set the Panel's language toggle to your favorite 2 languages. Choose from English (United States), Français (Canada), Español (Estados Unidos), Italiano (Italia), Nederlands (Nederland), Norsk bokmål (Norge), Svenska (Sverige) and Íslenska (Ísland), Deutsch (Deutschland), Magyar, (Magyarország), Dansk (Danmark), Română (România), Portuguesa (Portugal), Polskie (Polska), Suomalainen (Suomi), Français (France), Español (España).
Standby Button	Enabled	Turning this setting off completely disables the "Power Button" on the right side of the panel and all of it's functions. To re-enable this setting you must first check the box then follow the on screen prompts to press the "Toggle" switch in the back of the panel
LED Indicator	Enabled	Manually Enable/Disable the LED Status Light on the panel. **NOTE:** This setting will automatically be set to Disabled when EN Grade 2 is Enabled.
6 Digit User Code	Disabled	This is a global setting for all codes used on the panel and changes the input from 4 digits to 6 digits. When enabled, a "00" will be appended to all existing 4 digit codes
Commercial Sensor and Device Names	Disabled	Enabling this features changes the sensor name vocabulary from residential naming to commercial naming.

INSTALLER/DEALER SETTINGS

Setting	Default	Description
Wellness Support **NOTE:** This feature is not used in UL/cUL listed applications	Disabled	When Enabled, Auxiliary Pendants learned into Group 6 behave like a traditional PERS pendant. The system generates a signal to Alarm.com but does not generate a loud local alarm that needs to be disarmed between button presses. **NOTE:** This feature can not be enabled if Partitions are enabled.
WI-FI Warning Messages	Enabled	When enabled the panel will display a pop up when entering "Settings" letting the end user know that Wi-Fi has been disconnected.
Partitions	Disabled	Create up to 4 partitions by enabling this feature. **NOTE:** This setting will automatically be greyed out and unavailable when EN Grade 2 is Enabled.
Other Automation **NOTE:** This feature is not used in UL/cUL listed applications	Disabled	When Enabled, the Panel can support Zigbee Automation devices as well as Deako Lighting integrations. These devices are added through the "Other Automation" icon that will appear under the "Devices" icon. **NOTE:** Zigbee integration requires that a Zigbee daughter card be installed in the panel.
PowerG Camera Alarm Image Upload Count	10	Determines the number of Images to be uploaded by any PowerG PIR CAM when triggered during an Alarm. Choose between 10 and 1.
Security Page	Enabled	Choose whether or not you want the "Security Page" to appear as part of primary user interface on the panel. **NOTE:** Before the Security Page can be disabled, you must enable the "Wellness Page" or the "Home Control Page". This feature can not be disabled if Partitions are enabled.
Wellness Page **NOTE:** This feature is not used in UL/cUL listed applications	Disabled	Choose whether or not you want the "Wellness Page" to appear as part of primary user interface on the panel. **NOTE:** This feature can not be enabled if Partitions are enabled.

INSTALLER/DEALER SETTINGS

Setting	Default	Description
Check-in/Check-Out **NOTE:** This feature is not used in UL/cUL listed applications	Disabled	Choose whether or not you want a "Check-in" and "Check-out" button to appear as part of the Wellness Page UI. This feature allows a nurse to check in/out and have their picture taken by the panel as record of their visit. **NOTE:** The Wellness Page must be enabled in order for this feature to also be enabled.
Home Control Page	Disabled	Choose whether or not you want the "Home Control Page" to appear as part of primary user interface on the panel. **NOTE:** Before the Home Control Page can be enabled there must be at least two (2) different "types" of automation devices added to the panel (Lights, Locks or Thermostats). This feature can not be enabled if Partitions are enabled.
Door Lock Page **NOTE:** This feature is not used in UL/cUL listed applications	Enabled	Choose whether or not you want the "Door Lock Page" to appear as part of primary user interface on the panel anytime a Door Lock is added as a device.
Thermostat Page **NOTE:** This feature is not used in UL/cUL listed applications	Enabled	Choose whether or not you want the "Thermostat Page" to appear as part of primary user interface on the panel anytime a Thermostat is added as a device.
Scenes Support **NOTE:** This feature is not used in UL/cUL listed applications	Disabled	When enabled, a new icon will appear in the panel UI on left hand footer enabling the use of Scenes that have been created on Alarm.com. **NOTE:** This feature can not be enabled if Partitions are enabled.
Stream Live Video Cameras to IQ Remote	Disabled	This setting allows a user to view cameras from the IQ Remote. When enabled, Cameras that are streaming to the primary panel will also stream to the IQ Remote.

INSTALLER/DEALER SETTINGS

Setting	Default	Description
PowerG RF Jam Detection	Disabled	When enabled the system can detect when an unusual amount of RF signals are being transmitted in the PowerG spectrum leading to a potential panel malfunction. This event reports to the central station when enabled. Choose from Disabled, UL20/20 or En 30/60. **NOTE:** RF Jam shall be enabled for UL/ULC applications
Jam Detection	Disabled	When enabled the system can detect when an unusual amount of RF signals are being transmitted on the frequency of the legacy daughter card installed in the panel (319.5MHz, 345MHz or 433MHz) leading to a potential panel malfunction. This event reports to the central station when enabled. **NOTE:** RF Jam shall be enabled for UL/ULC applications
Jam Detection Local Alarm **NOTE:** Not evaluated by UL/cUL	Disabled	When enabled the system will sound a local alarm. "Jam Detection" must be active for this to function properly
SRF Jam Sensitivity Level	Normal	Choose between HIGH and NORMAL sensitivity levels
Allow Master Code to Access Security Sensors	Disabled	Allow the Master Code to access to the Security Sensor icon, including Auto Learn Sensor, Add Sensor, Edit Sensor, Delete Sensor, Sensor Status & Sensor Group
Open/Close Reports Allowed For Auto Learn	Enabled	Rather than sending a tamper to auto learn a sensor, enabling this will allow an open/close of the sensor to trigger auto learn
Panel Glass Break Detector **NOTE:** This feature is not used in UL/cUL listed applications	Disabled	Creates an independent zone that leverages the panel's built-in microphones to act as a glass break detector. This will fall into the zone order at the time you enable this feature. **NOTE:** This feature can not be Enabled if Panel Ambient Noise Detection is Enabled.

INSTALLER/DEALER SETTINGS

Setting	Default	Description
Panel Motion Detector **NOTE:** This feature is not used in UL/cUL listed applications	Disabled	Creates an independent zone that leverages the panel's built-in camera to act as an activity motion detector. This will fall into the zone order at the time you enable this feature. Motion can trip once every 4 minutes. **NOTE:** The panel motion detector is for activity monitoring and automation only (Group 25) and will not create an alarm condition or act as a security PIR.
Panel Ambient Noise Detector **NOTE:** This feature is not used in UL/cUL listed applications	Disabled	When Enabled, the Panel's built-in microphones can monitor for loud noise detection above a settable dB threshold and generate an alert. Useful for MDU, apartments and short term rentals where noise complaints are a concern. After an alert is generated, a 30 second cool down period is instituted. **NOTE:** This feature can not be Enabled if Panel Glass Break Detector is Enabled.
Ambient Noise Threshold	85 dB	Set the threshold at which the Panel Ambient Noise Detector determines there is enough noise to generate an alert. Choose from values between 75 and 95 dB. **NOTE:** This setting is greyed out and not selectable unless Panel Ambient Noise Detector is Enabled.
Noise Detector Duration	20 min	Determines the length of time for which the panel must detect noise above the threshold level in order to generate a noise notification.
Noise Detector Popup	Disabled	Determines whether the panel indicates locally on the screen that noise event has been detected.
Zigbee Network Type **NOTE:** This feature is not used in UL/cUL listed applications	Home Automation and Security	Choose which type of Zigbee network you'd like to use. Options are Home Automation and Security or Smart Energy. **NOTE:** This setting only appears when a Zigbee daughter card is installed in the Panel.

INSTALLER/DEALER SETTINGS

Setting	Default	Description
Zigbee Network Type	Home Automation and Security	Choose which type of Zigbee network you'd like to use. Options are Home Automation and Security or Smart Energy. **NOTE:** This setting only appears when a Zigbee daughter card is installed in the Panel.
Delete All Sensors	Deletes all security sensors and Bluetooth devices programmed in the panel	
Delete All Z-Wave Devices	Performs a factory reset on the Z-Wave controller. Does not factory reset previously included devices.	
Zigbee Reset	Deletes all Zigbee sensors and resets the Zigbee Network. **NOTE:** This setting only appears when a Zigbee daughter card is installed in the Panel.	
Master Reset*	Restores panel to factory settings and erases all content	
Data Recycle	This feature erases all User data previously stored. (Wi-Fi SSID & Password, User Codes, Panel Camera Images, Custom PhotoFrame Images, Message Center & Panel Event History).	
IQ Remote Reset Authentication	Disabled	If Enabled, the IQ Remote will require authentication (Dealer or Installer Code) to master reset it.

SYSTEM LOGS

System logs allow the panel to send non-customer identifying information to the server for troubleshooting and bug identification.

Setting	Default	Description
Upload logs to the server	*Requires manual push*	Tell the panel to begin uploading a history of it's activity to the server. This information is used to troubleshoot bugs and diagnose panel problems. The panel will upload any logs saved in it's memory
Auto Upload Logs	Disabled	Automatically upload the system's log to the servers every 24 hours
Log Level	Debug	Tell the panel how much information to record in log files. **No log output:** No information recorded **Fatal**: Record fatal or severely problematic information only **Error**: Record all errors and fatal issues **Warn**: Record warnings, errors, and fatal issues **Info**: Record all generic, non-customer related information **Debug**: Record diagnostic messages, Info, Warnings, Errors, and Fatal issues **Verbose**: Record all non-customer identifying information

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

INSTALLATION

SYSTEM LOGS

SIREN AND ALARMS

Siren and Alarms

Change siren and alarm settings for certain types of alarm events.

Setting	Default	Description
Panel Sirens	All Sirens On	**All Sirens Off:** This will disable the siren for all alarm types including any paired or hardwired external sirens. After 30 mins the fire siren will be re enabled. **All Sirens On:** This is the default setting which enables the siren for all alarms **Installer/Test Mode:** This disables the siren for all alarm types including any paired or hardwired external sirens for 30 mins then all sirens are re-enabled
Siren Annunciation	Disabled	Panel siren pauses periodically to announce which locations have triggered the alarm. **NOTE:** for UL/cUL this feature is not allowed for Fire, CO, Burglar Alarm
Fire Verification	Disabled	When enabled, panel requires two fire events from smoke detector (one detector twice or two detectors once each) **NOTE:** Not allowed on UL/cUL installations

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

INSTALLATION

SIREN AND ALARMS

SIREN AND ALARMS

Setting	Default	Description
Burglary Alarm Confirmation	Disabled	When enabled, a confirmed alarm requires two sequential burglary alarms within the Burglary Alarm Confirmation Timer window. **NOTE:** This setting is greyed out and unavailable unless EN Grade 2 is enabled.
Burglary Alarm Confirmation Timer	30	Timer used for Burglary Alarm Confirmation. **NOTE:** This setting is greyed out and unavailable unless EN Grade 2 is enabled.
Severe Weather Siren Warning	Enabled	When enabled, siren will sound when the panel receives a severe weather alert. When disabled, panel will use severe weather chime
Dialer Delay	:30	Amount of time (in seconds) before panel will attempt call to central station after an alarm event is triggered When SIA Limits enabled: :15 to :45 seconds When SIA Limits disabled: :0 to :254 seconds
Siren Timeout	4 min	Determine how long before siren stops sounding during an alarm event (4 minutes to 15 minutes). **NOTE**: For UL/cUL residential fire/burg applications the minimum bell timeout shall be set to 5 min. For UL Commercial Burglary installations, minimum bell time out shall be set to 15 minutes.
Water/Freeze Siren/Temperature	Disabled	When enabled, siren will sound when a water or freeze detector is triggered. When disabled, the panel emits a "water" tone

SIREN AND ALARMS

Setting	Default	Description
PowerG Smoke Detector Siren	Fire Alarms Only	When set to "Fire Alarms Only", PowerG Smoke Detectors that are learned into the system will only sound during fire alarm events. When set to "All Alarms", PowerG Smoke Detectors will act as additional wireless sirens and will sound during all alarm events.
Police Panic	Enabled	Allows Police Panic to be enabled or disabled.
Fire Panic	Enabled	Allows Fire Panic to be enabled or disabled.
Auxiliary Panic	Enabled	Allows Auxiliary Panic to be enabled or disabled.
Audible Siren for Wireless Supervisory Failures	Disabled	When this setting is enabled and the system is armed, supervisory failures for non-emergency sensors are treated the same as a tamper and cause an alarm to be generated.
Allow Master Code To Access Siren and Alarms	Disabled	Allow the master code to access these features and settings. **NOTE**: not allowed for UL/cUL.

SECURITY AND ARMING

Security and Arming

Change arming settings, entry and exit delays, enable Duress Authentication and more.

Setting	Default	Description
Dealer Code*	2222	Code to access all options
Installer Code	1111	Code to access installer options only
Swinger Shutdown	Enabled	Determines whether the panel allows the same sensor to trip the alarm more than once (enabled), or not (disabled)
Swinger Shutdown Count	1	Determines the number of times the same sensor is allowed to trip the alarm during the same arming period (1-6). Swinger Shutdown must be enabled in order for this setting to work
Panel Tamper	Enabled	This setting enables or disables the Panel Tamper switch on the back of the panel. **NOTE**: for UL/cUL this setting shall be Enabled
Screen Lock **NOTE:** This feature is not used in UL/cUL listed applications	Disabled	When enabled, a screen lock page will appear. Screen lock restricts access to the panel based on valid user codes. **NOTE**: This setting is required and is automatically enabled when Partitions are enabled. It is also enabled for "En Grade 2"

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

INSTALLATION

SECURITY AND ARMING

*** Additional options available only through the Dealer Code.**

SECURITY AND ARMING

Setting	Default	Description
Secure Arming	Disabled	Require user code for arming the panel. **NOTE**: this option shall be enabled for UL/cUL.
Refuse Arming When Battery Low	Disabled	Will not allow panel to arm if battery is low (below 8%)
Auto Bypass	Enabled	Toggle whether or not to bypass open or tampered sensors automatically. **NOTE**: Shall be disabled for UL/cUL. This setting is turned off and greyed out when the "En Grade 2" setting is enabled.
Final Exit Door Arming	Disabled	When enabled, if Arm Away is selected at the panel then there is no timed exit delay. Instead, the system is not fully armed until an Entry/Exit door is violated. **NOTE:** This setting is greyed out an unavailable unless EN Grade 2 is enabled.
Auto Stay	Enabled	If panel is armed "Away" but a delay door is not opened, the panel assumes you are still home and changes arming to "Stay" mode
Arm Stay - No Delay	Enabled	Arm stay immediately with no countdown timer
Auto Exit Time Extension	Enabled	Automatically extend countdown timer if delay door is opened during countdown process a second time
Keyfob Instant Arming	Enabled	When enabled, turns off exit delay if keyfob is used to arm the system
Keyfob Alarm Disarm	Disabled	When enabled this will Allow a keyfob to disarm alarm events, except panics originating from the same key fob

SECURITY AND ARMING

Setting	Default	Description
Keyfob Disarming	Enabled	When Disabled, a Keyfob will not be able to disarm the panel
Engineer's Reset	Disabled	If a confirmed alarm occurs on a burglary zone, the system is locked out after disarming until a 5 digit reset code provided by the installer is entered in.
Allow Master Code to Access Security and Arming	Disabled	Allow the master code to access these features and settings. **NOTE:** this option shall be disabled for UL/cUL. This option shall be enabled for UL Commercial Burg installations.
Normal Entry Delay	30 Secs	How much time users have to enter their code after opening a door (30-240secs). With SIA limits disabled the minimum time can be set to 5 secs. **NOTE:** For UL Commercial Burg (UL1610) maximum entry delay should not exceed 60s
Normal Exit Delay	60 Secs	How much time users have to exit the location before the panel arms itself (30-254secs). With SIA limits disabled the minimum time can be set to 5 secs. Door/Window group 10 follows the "Normal Exit Delay" **NOTE:** For UL Commercial Burg (UL1610) maximum exit delay should not exceed 60s
Long Entry Delay	100 Secs	A second separate entry delay that can be used on a sensor needing more time when tripped (45-240secs). With SIA limits disabled the minimum time can be set to 5 secs
Long Exit Delay	120 Secs	A second separate exit delay that can be used on a sensor needing more time when tripped (45-254secs). With SIA limits disabled the minimum time can be set to 5 secs. Door/Window group 12 follows the "Long Exit Delay"

CAMERA SETTINGS

Camera Settings

Enable/Disable Disarm photos and Alarm photos. Secure images requiring a code to either view or delete.

Setting	Default	Description
Secure Delete Images	Enabled	When enabled, a code is required to delete disarm and image sensor photos
Panel Camera	Enabled	When disabled, all Panel Camera related functions are turned off, including: Disarm Photos, Alarm Photos, Alarm Videos and Settings Photos. Additionally the Panel Camera Page is also removed
Disarm Photos	Enabled	When enabled, the built-in camera will take a single photograph when a user disarms the panel. When disabled, the panel will not capture images upon disarm
Alarm Photos	Enabled	When enabled, the built-in camera will take a single photograph during an alarm event
Alarm Videos	Enabled	When an alarm is triggered the panel will record a video clip for 4 mins from it's built in 5mp panel camera

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

INSTALLATION

CAMERA SETTINGS

Note: Supplementary feature not evaluated by UL/cUL

CAMERA SETTINGS

Setting	Default	Description
Settings Photos	Disabled	Whenever Advanced Settings are accessed the panel will take and store a photo
Allow Master Code to Access Image Settings	Disabled	Allow the master code to access these features and settings

Z-WAVE DEVICE LIST*

Z-Wave Device List
Shows device specific information for programmed Z-Wave devices.

Pressing "Info" displays:

- Product Info
- Protocol Info
- Application Info
- Supported Command Classes

Pressing "Re-Interview" will resend all initial pairing commands to that device.

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

Z-WAVE DEVICE LIST

*This page only available through the Dealer Code.

SOUND

Sound

Customize panel sounds. Enable/Disable voices, chimes, trouble beeps and more.

Setting	Default	Description
Volume	n/a	Controls the panel's voice volume, beeps and chime volume and the media volume (help videos) through individual sliders
Edit Chimes	n/a	Allows you to select from various chimes for each individual device
Voice Settings		
Voices	Enabled	This is a global setting for Sensors, Panel messages, Activity Monitoring Sensors, and Z-Wave device voices and indicates whether the panel should "speak"
Sensors	Enabled	Turns Sensor voices on (enabled) or off (disabled)
Panel	Enabled	Turns Panel voices on (enabled) or off (disabled)
Activity Monitoring	Enabled	Turns Activity Monitoring voices on (enabled) or off (disabled)

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SOUND

SOUND

Setting	Default	Description
Z-Wave Device Voice Prompts	Enabled	Turns Z-Wave Device voices on (enabled) or off (disabled)
Remote Z-Wave Device Voice Prompts	Enabled	Turns voices on (enabled) or off (disabled) for Z-Wave devices being controlled remotely (via Alarm.com)
Chime Settings		
All Chimes	Enabled	This is a global setting for Sensors, Panel messages and Activity Monitoring Sensors chimes and indicates whether the panel should emit tones or "beeps"
Sensor Chimes	Enabled	Turns chimes on (enabled) or off (disabled) for Sensors
Panel	Enabled	Turns Panel chimes on (enabled) or off (disabled)
Activity Sensor	Enabled	Turns Activity Sensor chimes on (enabled) or off (disabled)

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SOUND

SOUND

Setting	Default	Description
Trouble Beeps		
Trouble Beeps	Disabled	Toggles all sensor and panel trouble beeps on or off. By default all trouble beeps are disabled
Sensor Low Battery	Disabled	Panel sounds when a sensor battery is low. Chime type and frequency are set below. By default these sounds are disabled
Sensor Tamper Beeps	Disabled	Panel sounds when a sensor is tampered. Chime type and frequency are set below. By default these sounds are disabled
Panel Tamper Beeps	Disabled	Panel sounds when tampered or opened. Chime type and frequency are set below. By default these sounds are disabled
Edit Trouble Beep Chimes	n/a	Select the chime type for Sensor Low Battery, Sensor Tamper, and Panel Tamper
Trouble Beeps Timeout	30	Determines the amount of time between each trouble beep. Length can be set between 3-60 mins. (default is 30 mins)
Fire and Life Safety Device Trouble Beeps	Disabled	Panel will sound a trouble alert if a fire safety device is tampered, failed or has a low battery (disabled by default)

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SOUND

SOUND

Setting	Default	Description
Partition Sounds*		
Global Fire Siren	Enabled	When Partitions are enabled this setting determines whether Fire alarms sound in all partitions (enabled) or in only the partition they are assigned to (disabled)
Global Instrusion Sounds and Sirens	Disabled	Intrusion alarms and entry/exit sounds will sound in all partitions
Global Auxiliary Sirens	Disabled	Auxiliary alarm will sound in all partitions
Global Chimes and Voices	Disabled	Chimes and voices will play in all partitions
All Sounds in Partition 1	Disabled	Sounds and alarms from all other partitions will sound in partition 1
Other Sounds		
Touch Sounds	Enabled	This setting determines whether a touch sound is played when touching the screen (enabled) or not (disabled)
Exit Beeps	Enabled	Play exit beeps for the Quick Exit and Quick Access feature on the panel (enabled) or not (disabled)

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SOUND

*** Additional settings available only when Partitions are enabled.**

PARTITIONS*

Partitions
Edit the default name of a partition and view a list of users and sensors that are currently assigned to a given partition. Partitions 1, 2, 3 & 4 only appear when Partitions are enabled and when at least one sensor is learned into them.



Overview:
View the number of partitions set up on a system. There must be at least one sensor assigned to a partition before it can be viewed/edited

Info:
View Users and Sensors associated with each partition

Edit:
Rename a partition that suits it's location or area being protected

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

PARTITIONS

* The "Partitions" icon will only appear if Partitions are enabled under Installer/Dealer Settings

LOCAL AUTOMATION*

Local Automation
This hardcoded scene is designed for Panels installed in new construction properties that do not yet have an Alarm.com account activated, but that need to manage Z-Wave devices locally in a "vacant home mode".



Runs Daily:
- Automatically LOCK all locks at night (8pm)
- Set all thermostats to AUTO mode with a target temperature of 65°F - 78°F
- Turn Light 1 ON at night (8pm) and then turn all lights OFF in the morning (6am)

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

LOCAL AUTOMATION

*This page only available through the Dealer Code.

DEVICES

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

INSTALLATION

DEVICES

*Unsupported Z-Wave Devices icon only available through the Dealer Code.

SECURITY SENSORS

SECURITY SENSORS

Security Sensors
Add, edit or delete up to 128 security RF or life safety devices. This includes support for Image Sensors, when Image Sensor Daughter Card is installed.

Auto Learn Sensor
Pair sensors quickly by tripping or tampering and then editing the information

Add Sensor
Pair sensors manually by typing in a DL code or Serial number

Edit Sensor
Make changes to existing sensors

Delete Sensor
Remove a sensor

Sensor Status
Monitor sensor status in realtime

Sensor Group
Quick reference to all sensor groups and their actions

Panel Motion Settings
Adjust Panel Motion sensitivity and masking areas

Remove All PowerG Sensors
Delete all PowerG sensors from the Panel

Remove All Zigbee Sensors
Delete all Zigbee sensors from the Panel.

PowerG Output Rules
Configure PGMs when using the PGxWLSHW8

NOTE: Zigbee devices are not used in UL/cUL listed applications

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

INSTALLATION

DEVICES

SECURITY SENSORS

AUTO LEARN SENSOR





1. Select "**Auto Learn Sensor**"

2. Open/Close or Tamper a sensor to enroll. Image sensors have a 2 min enrolling window. For contacts **HARDWIRED** into "Sensor 1 or 2" on the back of the panel, simply open the contact. For PowerG contacts, hold the "enroll" button until the yellow LED flashes.

3. Panel will chime and display the sensor's DL code, or HW1/HW2 for hardwired contacts. Select OK to confirm.

4. Configure **Partition Name**, **Sensor Type**, **Sensor Group**, **Sensor Name**, **Chime Type** and **Voice Prompts** with the smart filtering drop down lists.

5. Select "**Add New**" to complete and move to the next sensor.

NOTE: The hardwire inputs on the panel can only be programmed as a Door/Window, Motion or Glass Break "Sensor Type".

When enrolling an "S-Line" sensor, the panel will auto detect that it's encrypted and change the "Source" field to S-Line.

IQ Panel 2+ only: When enrolling a sensor of a different frequency (345MHz, 433MHz, PowerG) the Source field will change to accommodate the incoming signal type.

When a sensor with the frequency 345 is used, you will be given an additional field to specify the Loop #.

ADD SENSOR



1. Select "**Add Sensor**" (**NOTE**: These same fields can be edited later from the "Edit Sensor" app)

2. Select the appropriate **Source** based on the frequency of device being manually learned in

3. Tap the field marked "**Sensor DL ID**" to open the keyboard. Enter the DL code or Sensor ID on the back of the device and touch "Done"

4. Use the drop down menu to select which **Partition** you would like the sensor to be added to (if enabled)

5. Choose **Sensor Type** from list

6. Indicate **Sensor Group** from list

7. Choose **Sensor Name** from the list or create a "Custom Name" using the built in keyboard with Custom Text to Speech.

8. Choose **Chime Type** from list

9. Indicate whether you want **Voice Prompts** on or off

10. Click "**Add New**" to save the information and complete the process.

SCAN QRCODE

*This feature is only used with Qolsys S-Line 319 Sensors that have compatible QR code labels on the box



1. Select "**Add Sensor**"

2. Tap the button marked "**Scan QRCode**" to open the camera. Hold the QR code label on the sensor box up to the camera to automatically scan the Sensor DL ID



3. Use the drop down menu to select which **Partition** you would like the sensor to be added to (if enabled)

4. Choose **Sensor Type** from list

5. Indicate **Sensor Group** from list

6. Choose **Sensor Name** from the list or create a "Custom Name" using the built in keyboard with Custom Text to Speech.

7. Choose **Chime Type** from list

8. Indicate whether you want **Voice Prompts** on or off

9. Click "**Add New**" to save the information and complete the process.

PARTITION NAME

When Partitions are enabled (see Dealer/Installer Settings) you may then assign a sensor to a specific partition. This will allow independent control and arming of that partition without disrupting the main panel's master partition. You may create and use up to 4 partitions.

SENSOR TYPE

When adding or editing security devices you can choose from the following sensor types:

Door/Window
Motion
Glass Break
Key Fob
Keypad
Auxiliary Pendant
Smoke Detector
CO Detector
Hardwire Translator
Wireless Translator
Temperature
Heat
Water
Shock Sensor
Freeze
Tilt
Image Sensor
Door Bell
Smoke-M
Door/Window-M
Occupancy Sensor
Siren
High Temperature



Note: for UL/cUL, only UL/cUL listed devices shall be used: Door/Window contact: 60-362N-10-319.5, Motion Detector: 60-639-95R, Smoke Detector: IQ Smoke QS5110-840. For UL1610 installations use only UL listed PowerG devices.

NOTE: image sensor functionality has not been investigated by UL/cUL. This is a supplementary feature that does not interfere with mandatory life safety and security protection operation of the alarm system control unit.

SENSOR GROUP

Sensor groups will change the behavior of the sensor. These are tied directly to your Sensor Type, displaying only what's relevant.

Touch the "Sensor Group" drop down to change.

A full list of Sensor Groups and descriptions can be found under "Sensor Groups" listed in the manual below.

SENSOR GROUPS

IQ Panel 2+ supports PowerG along with ONE "legacy" frequency (319.5 MHz, 345 MHz, or 433 MHz) depending on which RF daughter card is pre-installed. Sensor Group numbers and behaviors remain the same across all frequencies. When pairing a 345 MHz sensor with the Panel, an additional option for "Loop" number will be shown.

DOOR/WINDOW

GROUP	NAME	SUPERVISED	SCENARIO
10	Entry-Exit- Normal Delay	Y	Gives a period of time to exit the home or to disarm the panel when returning before sounding the alarm
12	Entry-Exit- Long Delay	Y	Gives a period of time to exit the home or to disarm the panel when returning before sounding the alarm. This can be a separate delay from the "normal delay"
13	Instant Perimeter D/W	Y	Door or window that triggers an alarm **instantly** when system is armed
14	Instant Interior Door	Y	An interior sensor that triggers an alarm **instantly** while armed to both stay and away. Does not trip if an entry/exit sensor is tripped first
16	Away Instant- Follower Delay	Y	Interior door that **triggers alarm instantly** when system is armed to away mode only

DOOR/WINDOW

GROUP	NAME	SUPERVISED	SCENARIO
25	Local Safety Sensor	Y	This sensor does **not** report or trigger an alarm. This is a **chime only** sensor when "Activity Monitoring" is active, regardless of panel status. Used for medicine cabinets, chemical storage etc
8	Reporting Safety Sensor	Y	This sensor reports to the central station and **triggers** an alarm when "Activity Monitoring" is active, regardless of panel status
9	Delayed Reporting Safety Sensor	Y	This sensor reports to the central station and triggers an alarm when "Activity Monitoring" is active, regardless of panel status. This sensor has an entry delay

*345 MHz door/window sensors will have the option to change the "Loop" number to 1 or 2. This will allow the sensor to be programmed twice as 2 different zones.

* Power G Door/Window contact 9945 adds an additional drop down menu to determine the contact type, Reed Switch or Wired.

MOTION/IMAGE SENSOR

GROUP	NAME	SUPERVISED	SCENARIO
17	Away- Instant Motion	Y	Active only when armed to "Away", and trips instantly when motion is detected. Does **not** trip if an entry/exit sensor is tripped first
15	Stay- Instant Motion	Y	Active in both "Stay" & "Away" modes, and trips instantly when motion is detected. Does **not** trip if an entry/exit sensor is tripped first
35	Stay- Delay Motion	Y	Active in both "Stay" & "Away" modes. Triggers an entry delay when motion is detected. Does **not** trip if an entry/exit sensor is tripped first
20	Away- Delay Motion	Y	Active when armed to "Away". Triggers an entry delay when motion is detected. Does **not** trip if an entry/exit sensor is tripped first
25	Safety Motion	Y	This sensor does **not** report or trigger an alarm. This is a chime only sensor when "Activity Monitoring" is active, regardless of panel status. Used for medicine cabinets, storage, activity tracking, etc

*345 MHz motion sensors will have the option to change the "Loop" number to 1, 2 or 3. This will allow the sensor to be programmed twice as 2 different zones where supported by the device.

*Power G Motion Detectors with Prefix 120, 122, 130, 140 and 142 offer additional functions such as High Traffic Shutdown and Sensitivity Level. Motions with prefix 123, 126, 127, 128 and 129 offer High Traffic Shutdown only as an additional function.

GLASS BREAK

*345 MHz glass break sensors can be programmed as "Loop" 1 only

GROUP	NAME	SUPERVISED	SCENARIO
13	Glass Break	Y	Active in both "Stay" and "Away" mode
17	Glass Break -Away Only	Y	Active in "Away" mode only

KEY FOB

*345 MHz Keyfobs will follow the IQ Panel's Keyfob programming and functionality

GROUP	NAME	SUPERVISED	SCENARIO
1	Mobile Intrusion	N	**Worn or carried**, the button(s) is/are programmed to trigger a **police panic**
3	Mobile Silent	N	**Worn or carried**, the button(s) is/are programmed to trigger a **silent police panic**
4	Fixed Auxiliary	Y	Installed in a **fixed location** such as night stand, the button(s) is/are programmed to trigger an Auxiliary panic. **NOTE:** Medical functionality has not been evaluated by UL/cUL
5	Fixed Silent Auxiliary	Y	Installed in a **fixed location** such as night stand, the button(s) is/are programmed to trigger a **silent** Auxiliary panic. **NOTE:** Medical functionality has not been evaluated by UL/cUL

KEY FOB

*345 MHz Keyfobs will follow the IQ Panel's Keyfob programming and functionality

GROUP	NAME	SUPERVISED	SCENARIO
6	Mobile Auxiliary	N	**Worn** as a wrist watch or pendant, the button(s) is/are programmed to trigger an Auxiliary panic. **NOTE:** Medical functionality has not been evaluated by UL/cUL
7	Mobile Silent Auxiliary	N	**Worn** as a wrist watch or pendant, the button(s) is/are programmed to trigger a **silent** Auxiliary panic. **NOTE:** Medical functionality has not been evaluated by UL/cUL

KEYPAD

GROUP	NAME	SUPERVISED	SCENARIO
0	Fixed Intrusion	Y	Installed in a **fixed location**, the keypad is programmed to trigger a **police panic.** **NOTE:** Hold-up functionality has not been evaluated by UL/cUL
1	Mobile Intrusion	N	**Keypad can be mobile** and is programmed to trigger a **police panic**
2	Fixed Silent	Y	Installed in a **fixed location**, the keypad is programmed to trigger a **silent police panic**
3	Mobile Silent	N	Keypad can be mobile and is programmed to trigger a **silent police panic**

KEYPAD

GROUP	NAME	SUPERVISED	SCENARIO
4	Fixed Auxiliary	Y	Installed in a **fixed location** such as night stand, the keypad is programmed to trigger an Auxiliary panic. **NOTE:** Medical functionality has not been evaluated by UL/cUL
5	Fixed Silent Auxiliary	Y	Installed in a **fixed location** such as night stand, the keypad is programmed to trigger a **silent** Auxiliary panic. **NOTE:** Medical functionality has not been evaluated by UL/cUL
6	Mobile Auxiliary	N	Keypad can be mobile and is programmed to trigger an Auxiliary panic. **NOTE:** Medical functionality has not been evaluated by UL/cUL
7	Mobile Silent Auxiliary	N	Keypad can be mobile and is programmed to trigger a **silent** Auxiliary panic. **NOTE:** Medical functionality has not been evaluated by UL/cUL

AUXILIARY PENDANT

*345 MHz auxiliary pendants can be programmed as "Loop" 1 only

GROUP	NAME	SUPERVISED	SCENARIO
0	Fixed Intrusion	Y	Installed in a **fixed location** such us under a desk, the button(s) is/are programmed to trigger a **police panic**
1	Mobile Intrusion	N	Worn or carried, the button(s) is/are programmed to trigger a **police panic**
2	Fixed Silent	Y	Installed in a **fixed location** such us under a desk, the button(s) is/are programmed to trigger a **silent police panic**
3	Mobile Silent	N	**Worn or carried**, the button(s) is/are programmed to trigger a **silent police panic**
4	Fixed Auxiliary	Y	Installed in a **fixed location** such as night stand, the button(s) is/are programmed to trigger an auxiliary panic
5	Fixed Silent Auxiliary	Y	Installed in a **fixed location** such as night stand, the button(s) is/are programmed to trigger a **silent** Auxiliary panic. **NOTE:** Medical functionality has not been evaluated by UL/cUL
6	Mobile Auxiliary	N	Worn as a wrist watch or pendant, the button(s) is/are programmed to trigger an **Auxiliary** panic
7	Mobile Silent Auxiliary	N	**Worn** as a wrist watch or pendant, the button(s) is/are programmed to trigger a **silent** Auxiliary panic. **NOTE:** Medical functionality has not been evaluated by UL/cUL
25	Safety Auxiliary Pendant	N	Used for local alerts like a nurse call button. Will not report an alarm to the Central Station

SMOKE DETECTOR/HEAT

*345 MHz smoke sensors will have the option to change the "Loop" number to 1, 2 or 3. This will allow the sensor to be programmed twice as 2 different zones where supported by the device

GROUP	NAME	SUPERVISED	SCENARIO
26	Smoke-Heat	Y	Triggers an alarm when sensor detects smoke/rapid rise in heat

SMOKE-M

GROUP	NAME	SUPERVISED	SCENARIO
26	Smoke-Heat	Y	Triggers an alarm when sensor detects smoke or a rapid rise of heat. Use **ONLY** with Qolsys multi-sensor smoke (QS5110-840)

CO DETECTOR

*345 MHz carbon monoxide sensors can be programmed as "Loop" 1 only

GROUP	NAME	SUPERVISED	SCENARIO
34	CO	Y	Triggers an alarm when sensor detects Carbon Monoxide

HARDWIRE TRANSLATOR & WIRELESS TRANSLATOR

GROUP	NAME	SUPERVISED	SCENARIO
13	Takeover	Y	Triggers an alarm when sensor is tampered in "Stay" or "Away" mode

TILT

*345 MHz tilt sensors can be programmed as "Loop" 3 only

GROUP	NAME	SUPERVISED	SCENARIO
10	Entry-Exit- Normal Delay	Y	Triggers alarm after "normal delay" expires. Arms with both "Stay" and "Away"
12	Entry-Exit- Long Delay	Y	Triggers alarm after "long delay" expires. Arms with both "Stay" and "Away
25	Garage Tilt- Safety Tilt	Y	This sensor group does **not** report or trigger an alarm. This is a chime only sensor when "Activity Monitoring" is active, regardless of panel status. Great for detached garage/shops. **NOTE:** Functionality in conjunction with garage door openers has not been evaluated by UL/cUL

WATER

*345 MHz water sensors will have the option to change the "Loop" number to 1, 2 or 3. This will allow the sensor to be programmed twice as 2 different zones where supported by the device

GROUP	NAME	SUPERVISED	SCENARIO
38	Water Sensor	Y	Triggers an alarm when sensor detects presence of water. **NOTE:** flood sensor functionality has not been evaluated by UL/cUL
25	Water Non-Reporting	Y	Used for local alerts. Will not report an alarm to the Central Station

Please note: When selecting "Water" you will see two additional options under "Sensor Sub-Type". For IQ TempH20 (QS5500-PO1) & the IQ Flood (QS5516-840/QS5536-840) select "IQ Flood", for all others, select "Other Flood"

SHOCK SENSOR

*345 MHz shock sensors will have the option to change the "Loop" number to 1 or 3. This will allow the sensor to be programmed twice as 2 different zones where supported by the device

GROUP	NAME	SUPERVISED	SCENARIO
13	Shock-Glass-Break	Y	Arms and trips shock sensors immediately when armed to both "Stay" and "Away"
17	Glass-Break-Away Only	Y	Arms and trips shock sensors immediately when armed only to "Away"

Please note: When selecting "Shock" you will see two additional options under "Sensor Sub-Type". For IQ Shock select "IQ Shock", for all others select "Other Shock". *Power G Shock Sensor with prefix 170 offers additional sensitivity level functions

FREEZE

*345 MHz temp sensors can be programmed as "Loop" 1 only

GROUP	NAME	SUPERVISED	SCENARIO
52	Freeze	Y	Triggers an alarm when sensor detects low temperatures. **NOTE:** temperature sensor functionality has not been evaluated by UL/cUL
25	Freeze Non-Reporting	Y	Used for local alerts. Will not report an alarm to the Central Station

Please note: When using the PG9905 with Group 52, Freeze, the Low threshold setting is set to 40°F by default. The Low threshold can be customized between -22°F and 158°F.

HIGH TEMPERATURE

GROUP	NAME	SUPERVISED	SCENARIO
53	Temp Reporting	Y	Triggers an alarm when sensor detects high temperatures. **NOTE:** temperature sensor functionality has not been evaluated by UL/cUL
25	Temp Non-Reporting	Y	Used for local alerts. Will not report an alarm to the Central Station

Please note: When using the PG9905 with Group 53, the High threshold setting is set to 100°F by default. The High threshold can be customized between -22°F and 158°F.

DOOR BELL

GROUP	NAME	SUPERVISED	SCENARIO
25	Local Safety Sensor	Y	This sensor does **not** report or trigger an alarm. This is a chime only sensor when "Activity Monitoring" is active, regardless of panel status. Great to automate lights, cameras and notifications etc

SIREN

GROUP	NAME	SUPERVISED	SCENARIO
33	Siren	Y	Used for supervising Z-Wave sirens for wireless connectivity. Reports to the central station.
25	Local Safety Sensor	Y	Used for supervising Z-Wave sirens for wireless connectivity. Local supervision only. Does **NOT** report to the central station.

DOOR/WINDOW-M (For use only with Multi-function Door/Window Sensors)

GROUP	NAME	SUPERVISED	SCENARIO
10	Entry-Exit- Normal Delay	Y	Gives a period of time to exit the home or to disarm the panel when returning before sounding the alarm
12	Entry-Exit- Long Delay	Y	Gives a period of time to exit the home or to disarm the panel when returning before sounding the alarm. This can be a separate delay from the "normal delay"
13	Instant Perimeter D/W	Y	Door or window that triggers alarm **instantly** when system is armed
14	Instant Interior Door	Y	An interior sensor that triggers an alarm **instantly** while armed to both stay and away. Does not trip if an entry/exit sensor is tripped first
16	Away Instant- Follower Delay	Y	Interior door that **triggers alarm instantly** when system is armed to away mode only

DOOR/WINDOW-M (For use only with Multi-function Door/Window Sensors)

GROUP	NAME	SUPERVISED	SCENARIO
25	Local Safety Sensor	Y	This sensor does **not** report or trigger an alarm. This is a **chime only** sensor when "Activity Monitoring" is active, regardless of panel status. Used for medicine cabinets, chemical storage etc
8	Reporting Safety Sensor	Y	This sensor reports to the central station and **triggers** an alarm when "Activity Monitoring" is active, regardless of panel status
9	Delayed Reporting Safety Sensor	Y	This sensor reports to the central station and triggers an alarm when "Activity Monitoring" is active, regardless of panel status. This sensor has an entry delay

OCCUPANCY SENSOR

GROUP	NAME	SUPERVISED	SCENARIO
25	Local Safety Sensor	Y	This sensor group is to be used for monitoring activity in the home. This group does not report

TEMPERATURE

GROUP	NAME	SUPERVISED	SCENARIO
51	Temp Non Reporting	Y	Only for use with the PowerG Temp Sensor (PG9905). This sensor group does **not** report to the Central Station. Allows for actual temperature monitoring (thermometer) with customizable high/ low threshold settings
52	Freeze	Y	Triggers an alarm when sensor detects low temperatures. **NOTE:** temperature sensor functionality has not been evaluated by UL/cUL
53	Temp Reporting	Y	Triggers an alarm when sensor detects high temperatures. **NOTE:** temperature sensor functionality has not been evaluated by UL/cUL

Please note: When using the PG9905 with Group 51, the High & Low threshold settings are set to 40°F and 100°F by default. When using Group 52, the Low threshold setting is set to 40°F by default. When using Group 53, the High threshold setting is set to 100°F by default. Thresholds can be customized between -22°F and 158°F.

SENSOR NAME



When you select the sensor name field you can choose from a variety of preset sensor names by scrolling up and down or create a custom description.

SENSOR NAME: CUSTOM DESCRIPTION

When you select "Custom Description" as your sensor name the android keyboard will appear. Type in the desired name (up to 56 characters) and click "Done." The name will appear in the field below "Sensor Name."

CHIME TYPE



Because of the dynamic nature of the way the IQ Panel 2 pairs and understands each individual sensor, you can program each sensor to have a unique chime or even turn chiming off for that individual sensor. To customize your chime for a particular sensor touch the Chime Type drop down and choose from the list.

VOICE PROMPTS



Voice prompts annunciate the sensor name when the sensor is opened or tripped.*

For door/window sensors, voice prompts are defaulted to "On". For most other sensors the default is "Off." Touch the drop down menu to change.

Choose individually which sensors should have voice prompts ON or OFF

***NOTE:** "Activity Monitoring Sensors" will also audibly report when they have been closed.

SOURCE



NOTE: SRF319, SRF433 (DSC Protocol), PowerG modem radio cards are used in UL/ULC listed Residential fire and burglary applications. SRF433 (AT&T Digital Life protocol) modem radio cards are used only in UL listed Residential fire and burglary applications. PowerG modem radio cards are used also in UL/ULC listed Commercial burglary applications.

Source indicates the sensor's incoming frequency when pairing to the IQ Panel 2 and IQ Panel 2+.

For the IQ Panel 2 you will see traditional SecurityRF-319 for legacy sensors and S-Line for Qolsys Encrypted sensors.

IQ Panel 2+ will show the following options depending on the pre-installed RF Daughter Card:

- PowerG
- SecurityRF
- SecurityRF-319
- S-Line
- SecurityRF-345
- 345RF 2G
- SecurityRF-433
- Zigbee

EDIT SENSOR

Edit Sensor
Edit sensors after they have already been learned in. All fields can be edited with the exception of the DL or Sensor ID.

NO	PTID	ID	SIGNAL SOURCE	TYPE	NAME	GROUP	EDIT
1	1	12BEA1	G	Motion	Upstairs Motion Detector	17-Away-Instant Motion	
2	1	12BEA2	G	Motion	Downstairs Motion Detector	17-Away-Instant Motion	
3	1	12BEA3	G	Door/Window	Front Door	10-Entry-Exit-Normal Delay	
4	1	12BEA4	G	Door/Window	Laundry Door	10-Entry-Exit-Normal Delay	
5	1	12BEA5	G	Door/Window	Back Door	13-Instant	

To make changes to a sensor, touch the "Pencil" icon next to the sensor that needs editing. Change desired fields and then touch "SAVE".

FIND IT



Swipe down for access

- SETTINGS
- ADVANCED SETTINGS
- ENTER CODE (1111, 2222)
- INSTALLATION
- DEVICES
- SECURITY SENSORS
- EDIT SENSOR

DELETE SENSOR

Delete Sensor
Delete each sensor individually or choose to delete more than one at a time. This is useful when needing to replace a sensor all together instead of simply editing programmed information.



Verify that the action is correct and touch "OK" to confirm or "CANCEL" to quit the operation



Select the sensor(s) from the list that are to be deleted and then touch "DELETE"

FIND IT



Swipe down for access

- SETTINGS
- ADVANCED SETTINGS
- ENTER CODE (1111, 2222)
- INSTALLATION
- DEVICES
- SECURITY SENSORS
- DELETE SENSOR

SENSOR STATUS

Sensor Status
Monitor sensor status in real time for things like open, close, tamper, idle and low battery.



NO	PTID	ID	SIGNAL SOURCE	NAME	TYPE	GROUP	STATUS
1	1	12BEA1	G	Upstairs Motion Detector	Motion	17-Away-Instant Motion	Idle
2	1	12BEA2	G	Downstairs Motion Detector	Motion	17-Away-Instant Motion	Idle
3	1	12BEA3	G	Front Door	Door/Window	10-Entry-Exit-Normal Delay	Closed
4	1	12BEA4	G	Laundry Door	Door/Window	10-Entry-Exit-Normal Delay	Closed
5	1	12BEA5	G	Back Door	Door/Window	13-Instant	Open

This page also allows you to quickly review programming for things like Zone number, Partition, Signal Source (319, 345, 433, PowerG, Native or Zigbee), Sensor Name, Sensor Type and Sensor Group.

FIND IT



Swipe down for access

- SETTINGS
- ADVANCED SETTINGS
- ENTER CODE (1111, 2222)
- INSTALLATION
- DEVICES
- SECURITY SENSORS
- SENSOR STATUS

SENSOR GROUP

Sensor Group
Don't have this manual handy on an install? Sensor Group gives you digital access to view each possible sensor group and it's behaviors directly on the panel.



ID	TYPE	NAME	SUPERVISORY	RESTORAL	TIMER	SIREN TYPE
0	Auxiliary Pendant	Fixed Intrusion	Y	N	Immediate	Siren3
1	Auxiliary Pendant	Mobile Intrusion	N	N	Immediate	Siren3
2	Auxiliary Pendant	Fixed Silent	Y	N	Immediate	Siren3
4	Auxiliary Pendant	Fixed Auxiliary	Y	N	Immediate	Siren3
6	Auxiliary Pendant	Mobile Auxiliary	N	N	Immediate	Siren3

The Sensor Group list is sorted by "Type" in alphabetical order from A - Z.

FIND IT



Swipe down for access

- SETTINGS
- ADVANCED SETTINGS
- ENTER CODE (1111, 2222)
- INSTALLATION
- DEVICES
- SECURITY SENSORS
- SENSOR GROUP

PANEL MOTION SETTINGS

Panel Motion Settings
Control settings for the built-in Panel Motion Detector. Change the sensitivity threshold and mask off up to 4 customizable areas to prevent false triggers.





Masking:
Touching "ADD MASK" will give a drawable area (green) that is not taken in to account for motion pixelation change, then touch "SAVE MASK" to save. Up to 4 independent mask areas can be drawn.

Sensitivity Setting:
Touch "SETTING" to change the the Panel Motion sensitivity between Low (default), Medium and High. Use the Green to Red bar on the right side of the screen to determine trigger threshold.

FIND IT



Swipe down for access

- SETTINGS
- ADVANCED SETTINGS
- ENTER CODE (1111, 2222)
- INSTALLATION
- DEVICES
- SECURITY SENSORS
- PANEL MOTION SETTINGS

WI-FI DEVICES

WI-FI DEVICES

Wi-Fi Devices
View and remove Wi-fi devices associated with the panel as well as configure the Qolsys Access point.

Wi-Fi
Scan and connect to a Wi-Fi network. This will ensure your panel can receive software updates and have a Dual Path connection.

Access Point Settings
Configure the IQ Panel 2's built in router. Enable/Disable the router, broadcast or hide the SSID and change the SSID's password etc...

Access Point Connected Devices
View connected device information such as IP, MAC address and for how long the device has been connected.

IQ Remote Devices
Pair an IQ Remote Secondary Touchscreen to the panel whether it is connected to the customer's network or the panel's built in Access Point.

3rd Party Connections
Enable or disable 3rd party connections on the panel. This feature is used for specific 3rd party device integration

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

INSTALLATION

DEVICES

WI-FI DEVICES

CONNECTING TO WI-FI

To connect to a Wi-Fi network, follow the steps below:

Swipe down from the top menu bar and select settings.

Touch Advanced Settings (Installer Code)

Then touch "Wi-Fi"

Enable Wi-Fi if not already active

Available networks appear in a list. Touch the desired network and use the keyboard to type the password (if required)



FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

INSTALLATION

DEVICES

WI-FI DEVICES

ACCESS POINT SETTINGS

WI-FI Access Point:
Enable or Disable the Panel Access Point

SSID:
Change the SSID Name. This is the name that other devices will use to connect to.

DHCP IP Range:
Modify the DHCP IP Range for the access point. Default is 50.

Change Password:
Change the password of the SSID to one of your choosing.

Activate WPS:
Connect devices to the panel's built-in access point using WPS push button.

Access Point Password:
Shows current password in use for the Panel Access Point

ACCESS POINT CONNECTED DEVICES



View the IP address, Mac address and connected duration of each Wi-Fi client connected to the panel's built in router.

Select "Actions" to then remove a device that has been associated with the panel.

You must remove saved network information from the device otherwise it will re-connect to the panel.

IQ REMOTE DEVICES

NOTE: Not UL/ULC Listed feature, not used on UL/ULC listed applications

IQ Remote Devices

Pair up to 3 IQ Remote Secondary Touchscreens to the panel via the customer's network or the panel's built in access point.

NOTE: The IQ Remote will automatically pair as Sensor Type "Keypad" and will appear on the zone list in the order in which it is paired. Sensor Groups 0, 1 & 2 are available options for this Sensor Type.

1. Connect the IQ Remote to the panel's access point or to the same Wi-Fi network the panel is connected to. **NOTE:** QW9102 & QW9103 IQ Remotes only support 2.4 GHz networks. QW9104 IQ Remotes support both 2.4 GHz and 5 GHz.
2. Prior to pairing the IQ Remote to the panel you can Test the connection by select TEST on the panel and the remote.
3. Select "Pair" on the Panel and then Pair on the IQ Remote to begin during this process the remote will also download and update to the current software version and reboot.
4. The remote device will pair to the panel and will show that it is active on the list. You can then edit (device name and sensor group), ping, delete or rediscover the device if necessary

3RD PARTY CONNECTIONS

3rd Party Connections
Enable or disable 3rd party connections on the panel. This feature is used for specific 3rd party device integration



Check the "Control4" box to enable 3rd Party Connections. This will cause the panel to reboot in order to apply the change. Once enabled a secure token can be generated in order to sync with Control4 integration.

Remote Access, Home Accessories and Savant are reserved for future use.

NOTE: Not UL/ULC Listed feature, not used on UL/ULC listed applications

FIND IT



Swipe down for access

- SETTINGS
- ADVANCED SETTINGS
- ENTER CODE (1111, 2222)
- INSTALLATION
- DEVICES
- WI-FI DEVICES
- 3RD PARTY CONNECTIONS

Z-WAVE DEVICES

Z-WAVE DEVICES

Z-Wave Devices
Add, Edit, Clear and Remove Z-Wave Devices. You can also View/Edit associations as well as access Z-Wave Settings.

Add Device (Inclusion)
Add new devices to the Z-Wave network

Edit Device
Make changes to existing devices

Clear Device (Exclusion)
Removes a Z-Wave device from it's previous network. Also deletes a device from the IQ Panel 2 if currently paired.

Delete Failed Device
Remove a failed Z-Wave device from the IQ Panel 2's memory

Remove All Devices (Factory Default Reset)
If this controller is the primary controller for your network, resetting it will result in the nodes in your network being orphaned and it will be necessary after the reset to exclude and re-include all of the nodes in the network. If this controller is being used as a secondary controller in the network, use this procedure to reset this controller only in the event that the network primary controller is missing or otherwise inoperable.

View/Edit Associations
Manually change Z-Wave associations for specific devices.

Z-Wave Settings
Configure device limits and other Z-Wave settings.

SmartStart
Enter the device's DSK or simply scan the QR Code.

Provisioning List
Devices added via SmartStart will show their progress of being included into the network.

Z-WAVE DEVICES

ADD DEVICE

1. Select "Add Device"

INCLUDE

2. Touch "Include"



3. Press the "Pair" or "Learn" button on the device when the message appears. *(see individual device documentation for instructions on button location)*

4. Adjust the device name by touching and making the appropriate selections.



5. Select "Automation" to enable simple light rules.
- **Night**: Turns light on at 7pm and off at 6am
- **Evening**: Turns light on at 7pm and off at 11pm
- **Front Door**: Turns light on for 15mins when Front Door opens (must have a sensor with the default quick name "Front Door" added in the panel).

6. Click "Add" to save the information and complete the process. (Adjustments can be made later from "Edit Device" icon)

S2 is a new Z-Wave Security Protocol. When an S2 node is attempting to be included it will request S2 security keys. These are based on the level of S2 security that the end device requires. These keys can be Unauthenticated, Authenticated or Access. These keys can be manually granted by selecting the appropriate option.

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

INSTALLATION

DEVICES

Z-Wave DEVICES

ADD DEVICE

CLEAR DEVICE

Clears Z-Wave device from a network, whether it was enrolled with another controller previously or the IQ Panel 2. Also deletes a device from the IQ Panel 2 if currently paired.



Touch "Clear Device"

Panel will start sending a "Clear" signal

Press "Pair" or "Learn" button on device*

Panel returns to Z-Wave Device menu when complete

NOTE: Each Z-Wave device is different, and not all devices have a hard button to pair or learn. Refer to your device's installation manual for specifics on pairing or learning.

DELETE FAILED DEVICE

Deletes Z-Wave device from the panel. Before adding the device to another network see instructions on how to "Exclude" a Z-Wave device. Only allows a Node ID to be deleted if it has failed and is no longer communicating.

Touch "Delete Failed Device From Panel"



Check the boxes next to the device(s) you want to delete

Delete

Touch "Delete"

REMOVE ALL DEVICES

Deletes all Z-Wave devices from the panel and resets the panel's Z-Wave controller.



Touching "Remove All Devices" brings a confirmation pop-up asking you to confirm your decision to remove all devices.

If this controller is the primary controller for your network, resetting it will result in the nodes in your network being orphaned and it will be necessary after the reset to exclude and re-include all of the nodes in the network. This procedure will send a "Device Reset Locally" to all Z-Wave devices in the IQ Panel 2's Lifeline Group (Group 1).

VIEW/EDIT ASSOCIATIONS

Manually change Z-Wave associations for specific devices.

1. Select the Z-Wave device you would like to associate with another by touching "View"

2. Select "Edit"

3. "Check" the boxes next to each device that you would like to associate with. Then select "Save"

Note: The IQ Panel 2+ supports Lifeline in Group 1 to send out Device Reset Locally when it has been associated to another Z-Wave Plus device. This is triggered when "REMOVE ALL DEVICES" is used

Z-WAVE SETTINGS

Z-Wave Settings allow an installer to set a maximum number of Z-Wave devices allowed on the IQ Panel 2 in all categories and to control other Z-Wave settings.

Device	Default	Maximum Number Supported
Thermostats	10	Maximum number of supported Thermostats is 10
Smart Sockets*	15	Maximum number of supported IQ Smart Sockets is 15
Lights	80	Max number of supported Z-Wave light modules is 80
Door Locks	20	Maximum number of supported Z-Wave Door Locks is 20
Other Z-Wave Devices	21	Maximum number of misc Z-Wave devices is 21
Garage Doors	6	Maximum number of Garage Doors is 6

NOTE: This feature has not been evaluated by UL/cUL. This is a supplementary functionality that will not interfere with the minimum mandatory operation of the life safety and burglary protection of the alarm system control unit. UL Note: Additional Z-Wave devices other than what has been indicated as maximum limits have not been evaluated by UL/cUL.

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

INSTALLATION

DEVICES

Z-WAVE DEVICES

Z-WAVE SETTINGS

*** Additional option available only through the Dealer Code.**

Z-WAVE SETTINGS

Setting	Default	Description
Allow Master Code Z-Wave Settings	Disabled	Allow Master User Code to access Z-Wave Settings
Allow Master Code Z-Wave Management	Disabled	Allow Master User Code to access Z-Wave Devices (Add, Edit, Clear, Delete Failed Device, Remove All Devices & View/Edit Associations)
Access to Automation	Enabled	When **enabled** it allows the ability to apply simple automated actions to lights and switches directly from the panel
Z-Wave	Enabled	Activate or deactivate the Z-Wave radio. Please use this procedure only when the controller (panel) is missing or inoperable
Advanced Z-Wave Settings	Disabled	When Advanced Z-Wave Settings is **enabled** the following new icons will appear on the Z-Wave Devices page: - **Continuous Add Devices:** Activates an "always listening" enroll mode. Include one Z-Wave device after another. When complete you can edit the device(s) with a custom name - **Replace Failed Node:** Allows a node that has failed to be replaced with a new device using the same node ID - **Manage Devices From Secondary Controllers:** Allows secondary controllers to manage devices on the network - **Controller Shift**: Shifts the primary controller from IQ Panel to another controller - **Add/Remove Controller**: This icon acts like an "Add/Remove" button when pairing the IQ Panel into another network

SMARTSTART

1. Select "SmartStart"

INCLUDE

2. Touch "Include"

3. Scan the Box or Device's QR code or manually enter the DSK code and select Add DSK.

4. Adjust the device name by touching and making the appropriate selections.

5. Select "Automation" to enable simple light rules.
- **Night**: Turns light on at 7pm and off at 6am
- **Evening**: Turns light on at 7pm and off at 11pm
- **Front Door**: Turns light on for 15mins when Front Door opens (must have a sensor with the default quick name "Front Door" added in the panel).

6. Click "Add" to save the information and complete the process. (Adjustments can be made later from "Edit Device" icon)

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

INSTALLATION

DEVICES

Z-WAVE DEVICES

SMARTSTART

PROVISIONING LIST

Provisioning List
Devices added via SmartStart will show up in the provision list. This list will show the network status of those devices. Once a devices reaches the "Included" state on the panel, it can no longer be deleted using the trash can method and must follow standard clearing process.

NETWORK STATUS:
Not in network: When a device has been paired but has not yet been plugged in it will show Not in Network. These devices can also be deleted using the trash can.

Started: Once the device has been paired and then plugged in, it will start the inclusion process with the panel and run in the back ground.

Included: When a device has completed the inclusion process it will then show as "included" in the provisioning list and at that point the panel's UI will reflect the included devices.

BLUETOOTH DEVICES

BLUETOOTH DEVICES

Bluetooth Devices
Add, Edit, Delete and Configure a Bluetooth Device. Bluetooth disarm supported via a mobile device. Bluetooth Chime, annunciation and 2 Way Voice supported on Anker 3102, 3108 or 3109 Bluetooth speaker.

Add Device
Pair up to 5 mobile Bluetooth devices.

Edit Device
Make changes to existing Bluetooth devices.

Delete Device
Delete a paired Bluetooth device

Remove All Devices
Removes all paired Bluetooth devices at once.

Settings
Toggle Bluetooth on/off, adjust Bluetooth disarm settings and change Bluetooth disarm timeout (1,5,10,20 & 30mins).

Add Speaker
Pair an Anker a3102, 3108 or 3109 Bluetooth speaker with the panel for remote voice annunciations, chimes and two-way voice. **NOTE:** Adding a BLE speaker to the panel replaces all chimes and voices from the built-in panel speakers.

FIND IT



Swipe down for access

- SETTINGS
- ADVANCED SETTINGS
- ENTER CODE (1111, 2222)
- INSTALLATION
- DEVICES
- BLUETOOTH DEVICES

ADD DEVICE



1. Select "Add Device"

2. Open the Bluetooth page on your mobile device. The panel will search for all available and in range bluetooth devices.

3. Select the correct device from the list on the panel and ensure the pairing code matches that on your mobile device.

4. Touch "Pair" on the panel first, and then on your mobile device.

5. Choose whether to allow disarming or not, and select the Partition to be disarmed (if Partitions are enabled).

6. Your mobile device will now show under the "Paired Devices" list on the panel.

NOTE: Your phone may show the IQ Panel as "Not Connected". This is normal

EDIT DEVICE



1. Select the pencil next to the device you would like to edit.

2. Select whether or not you would like to allow a device to disarm the panel when in proximity.

3. Select which Partition you would like the device to disarm.

Note: This option is only available when "Partitions" are enabled. A device can only be assigned to one Partition at a time.

DELETE DEVICE



1. Select the check box next to the device you would like to delete.

2. Select "Delete" at the bottom of the page.

3. Select "OK" to confirm and delete the device.

REMOVE ALL DEVICES



To delete and remove all enrolled Bluetooth devices at once, select "Remove All Devices".

Next select "OK" to confirm you would like to delete.

SETTINGS



BLUETOOTH:
Select or un-select this box to enable or disable the bluetooth radio.

BLUETOOTH DISARM:
Select or un-select this box to enable or disable the ability to disarm the panel via Bluetooth. To change this on an individual level you must edit the specific device.

BLUETOOTH DISARM TIMEOUT:
Change the time in which the panel must wait after it's been armed to away before it allows a bluetooth device to disarm it. **Default 10 min**

Select from 1, 5, 10, 20 or 30 minute disarm timeout

ADD SPEAKER



1. Select "Add Speaker"

2. Initiate Bluetooth pairing from the speaker.

3. Touch the correct device from the list on the panel to begin the pairing process.

4. Once paired, a pop up showing "Bluetooth Device Added Successfully" will appear. Touch "OK" to confirm.

5. Your speaker will now show under the "Paired Devices" list on the panel.

NOTE: Only "Anker" brand (models 3102, 3108 or 3109) speakers are supported.

SYSTEM TESTS

SYSTEM TESTS

System Tests
There are many different tests you can perform to ensure the system is working properly.

Wi-Fi Test
Test the panel's connection to the wireless (Wi-Fi) network

Image Sensor Config
Test the panel's connection to Image Sensors

Sensor Test
Shows actual dBm signal strength of each sensor and graphs sensor events against the ambient noise floor of the environment

Z-Wave Tests
Test communication between devices and the panel. Rediscover network, counters, neighbor info, diagnostics & advanced diagnostics

Cellular Test
Test the panel's connection to the cellular network and Alarm.com

PowerG Test*
Ping and receive signal strength from a PowerG sensor.

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SYSTEM TESTS

* PowerG Test available only if a PowerG Daughter card is installed in the panel.

SYSTEM TESTS

Zigbee Test
See the last signal strength, average signal strength and battery voltage on Zigbee sensors. Requires a Zigbee daughter card be installed in order for this icon to appear

Panel Glass Break Test
Test the panel's microphones to ensure proper sensitivity for built in Glass Break

Dual Path Test
Verifies the Wi-Fi path is connecting to Alarm.com

Daughter Cards Test
Tests the integrity of the installed daughter cards

Panel Test
Runs through a complete test of the panel's running processes

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SYSTEM TESTS

WI-FI TEST

Wi-Fi Test

The Wi-Fi test checks the IQ Panel 2's connection to your network (router). Before running this test, be sure to connect the panel to the network. See "customization" section for directions on connecting to Wi-Fi.

A successful test will result in a "pass" and indicates the date and time of the test along with connection speed.

To perform a Wi-Fi Test, touch the "Run" button.

NOTE: If test fails, please check your Wi-Fi settings.

FIND IT



Swipe down for access

- SETTINGS
- ADVANCED SETTINGS
- ENTER CODE (1111, 2222)
- SYSTEM TESTS
- WI-FI TEST

SENSOR TEST

Sensor Test
Shows actual dBm signal strength of each sensor and graphs sensor events against the ambient noise floor of the environment. Also displays the traditional packet count method. This new version of the Sensor Test requires **RF PIC Version 10.2.15-G1** or higher.

ZONE	NAME	AVERAGE DBM	LAST EVENT RESULTS (DBM) (PACKETS)		
1	Back Window	Strong (-43)	Strong (-47)	Perfect (16)	
2	Front Window	Strong (-31)	Strong (-33)	Perfect (8)	
3	Back Door	Good (-55)	Good (-55)	Excellent (7)	

Refer to page 99 for the sensor packet results table.

The Advanced Sensor Test shows a summary page of each sensor paired to the panel along with the average dBm level , the last event's dBm level and how many packets were received from the sensor.

Select the graph icon to the right of each sensor to view an individual sensor's graphed signal strength in real time.

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SYSTEM TESTS

SENSOR TEST

NOTE: For UL/cUL , perform a placement test first for all wireless initiating devices. The acceptable result shall be "Excellent".

SENSOR TEST

Noise Floor

From the Sensor Test page select the "Settings" cog to view the "Real Time Noise Floor". The noise floor represents the dBm threshold at which the panel can no longer sense signals from sensors.



Lower dBm levels mean there is less noise or interference on the sensor's specific operating band or frequency.

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SYSTEM TESTS

SENSOR TEST

NOTE: Manufacturer recommended signal to noise ratio is min 7dB

SENSOR TEST

- Colored points on the graph represent each state change or supervisory signal transmitted from a sensor to the panel. Points are colored based on frequency.
- The **YELLOW** line represents a dBm level where signal strength is "Poor" and potential RF failures could occur. This line dynamically adjusts to 12 dBm above the ambient RF noise floor in the environment.
- The **RED** line represents a dBm level where signal strength is "Critical" and RF failures are likely. This line dynamically adjusts to 6 dBm above the ambient RF noise floor in the environment.

TROUBLESHOOTING:
If a sensor falls below the yellow line, try changing it's orientation (vertical/horizontal), move the sensor to a different part of the door/window or adjust the panel's RF pigtail antenna.

Then re-test to see the if the result improved.



FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SYSTEM TESTS

SENSOR TEST

NOTE: Manufacturer recommended signal to noise ratio is min 7dB

SENSOR TEST

Sensor Test
The panel can test its connection and communication to individual security sensors. Before running this test there must be at least one security sensor paired with the system. This version of the sensor test is for panels with the older **RF PIC Version 10.2.15-G0**.

Sensors connected to the panel will appear on the screen. The panel will detect open and close reports. **Please allow 10 secs between tests if tripping the same device more than once.** "Signal Source" relates to a sensor's frequency.

The panel will audibly report and display test results from "No Signal" to "Perfect", including how many packets were received.

NO	ID	SIGNAL SOURCE	NAME	RESULT	LAST RUN TIME
1	61B8A0	G	Water	No Signal	
2	625DA1	G	Front Door	Perfect(8)	04:49 PM, Jun 07, 2017

Results	Packets Received
Perfect	8
Excellent	6-7
Good	3-5
Minimum	1-2
No Signal	No RF packets received

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SYSTEM TESTS

SENSOR TEST

NOTE: For UL/cUL , perform a placement test first for all wireless initiating devices. The acceptable result shall be "Excellent".

CELLULAR TEST

Cellular Test
Test the panel's built-in cellular radio connection. You must first activate the radio through Alarm.com prior to running this test. Cell signal strength is only available after the test has been ran successfully.

To begin the test press "Start" and watch for the results on the screen.

FIND IT



Swipe down for access

- SETTINGS
- ADVANCED SETTINGS
- ENTER CODE (1111, 2222)
- SYSTEM TESTS
- CELLULAR TEST

IMAGE SENSOR CONFIG

Image Sensor Config
Test an image sensors connectivity with the panel to ensure they are communicating properly and are able to take photos.

Choose an Image Sensor to Test:



Select the desired Image Sensor by touching "View" next to it's name

Touch "Sensor Tests"

Select the test you want to run:



PIR Test checks the motion sensor

Installer Peek In tests the camera (Results appear through the Alarm.com app)

FIND IT



Swipe down for access

- SETTINGS
- ADVANCED SETTINGS
- ENTER CODE (1111, 2222)
- SYSTEM TESTS
- IMAGE SENSOR CONFIG

Z-WAVE TESTS

Z-Wave Test
Test the connection between the panel and enrolled Z-Wave devices to ensure they are communicating properly.

To perform a Z-Wave Test, touch the "Run" button. A successful test will result in a "Pass" and a time stamp.



NOTE: If a test fails, relocate device, change batteries and/or rediscover network.

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SYSTEM TESTS

Z-WAVE TESTS

Z-WAVE TEST

Z-WAVE TESTS

Rediscover Network
After installing or moving a Z-Wave device one should always "Rediscover the Network". This re-maps the network and ensures all devices have the most efficient communication path leading back to the panel.

Select a single device or all and then select "Rediscover". A result including a time stamp will appear under "Status".

NOTE: If a test fails, relocate device, change batteries and/or rediscover network.

FIND IT



Swipe down for access

- SETTINGS
- ADVANCED SETTINGS
- ENTER CODE (1111, 2222)
- SYSTEM TESTS
- Z-WAVE TESTS
- REDISCOVER NETWORK

Z-WAVE TESTS

Neighbor Info
Use "Neighbor Info" to view which devices can "see" each other. The more neighbors a device can see means more possible routes back to the controller.



Touch "View" next to any device and a pop-up will appear listing it's "Neighbor Nodes"

FIND IT



Swipe down for access

- SETTINGS
- ADVANCED SETTINGS
- ENTER CODE (1111, 2222)
- SYSTEM TESTS
- Z-WAVE TESTS
- NEIGHBOR INFO

Z-WAVE TESTS

Counters

View a numerical representation of the Z-Wave network. View failed and acknowledged commands as a whole or from an individual device. A well designed network should have at least a 98% acknowledgment vs failed rate.



FIND IT



Swipe down for access

- SETTINGS
- ADVANCED SETTINGS
- ENTER CODE (1111, 2222)
- SYSTEM TESTS
- Z-WAVE TESTS
- COUNTERS

Z-WAVE TESTS

COUNTER	DESCRIPTION
Acked commands no auto route	Command was successful and acknowledged by the sensor; it did not use the normal automatic Z-Wave network route to execute the command for this device (command was re-routed on the Z-Wave network in order to succeed)
Acked commands auto route	Command was successful and acknowledged by the sensor; it used the normal automatic Z-Wave network route to execute the command for this device.
Failed commands network failed	Not possible to transmit data because Z-Wave network is busy (jammed). Command failed to execute.
Network failed	Not possible to transmit data because Z-Wave network is busy (jammed). Command failed to execute
Network not idle	Auto-routed command failed because Z-Wave network is not yet stable. Command failed to execute.
Network no route	Auto-routed command failed because there is no successful Z-Wave network route to the device. Command failed to execute
Reset All	Resets all counters back to 0 as to better diagnose the network
Details	Shows individual device details such as passed and failed commands. Here you can also reset an individual device's counter

Z-WAVE TESTS

Z-Wave Diagnostics

View a graphical representation of the installed Z-Wave network. View the network's or an individual device's last known working route. Use the Key chart to decipher which devices are repeating nodes, have a strong or weaker signal or perhaps need to be moved to another location.



FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SYSTEM TESTS

Z-WAVE TESTS

Z-WAVE DIAGNOSTICS

Z-WAVE TESTS

Advanced Z-Wave Diagnostics
Advanced Z-Wave diagnostics gives access to Network Health Test, Repeater Test & Last Working Route.



Network Health Test
Shows the minimum, maximum & average node response times on the network

Repeater Test
Tests the connection to dedicated Z-Wave repeaters on the network

Last Working Route
Shows the last working route for a specific node on the network. Also allows you to set a static "sticky" route

FIND IT



Swipe down for access

- SETTINGS
- ADVANCED SETTINGS
- ENTER CODE (1111, 2222)
- SYSTEM TESTS
- Z-WAVE TESTS
- ADVANCED Z-WAVE DIAGNOSTICS

POWER G TEST

PowerG Test
Ping a PowerG sensor and receive back it's signal strength. You can view the average signal strength over 24hrs as well as review the PowerG PIR CAM image.



STRENGTH can be: Strong, Good, Poor or No Signal

Note: for UL/cUL signal strength shall be "Strong"

FIND IT



Swipe down for access

- SETTINGS
- ADVANCED SETTINGS
- ENTER CODE (1111, 2222)
- SYSTEM TESTS
- POWERG TEST

*PowerG daughter card must be installed in the panel to access this test.

ZIGBEE TEST

Zigbee Test
See the last signal strength, average signal strength and battery voltage on Zigbee sensors.

STRENGTH can be:

-Strong

-Good

-Poor

-No Signal

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SYSTEM TESTS

ZIGBEE TEST

* Requires a Zigbee daughter card be installed in order for this icon to appear

PANEL GLASS BREAK TEST

Panel Glass Break Test

Test the panel's microphones via a clap test or glass break test. This will ensure the built in detector and microphones are functioning properly when needed. Panel Glass Break must be enabled under Installer Settings to access this test.



Testing

Select "Run" to begin test. Circle will turn **YELLOW** when a successful clap test has been detected and Microphones are listening.

Circle will turn **GREEN** when the panel hears the proper glass break frequency being detected.

NOTE: Not UL/ULC Listed feature, not used on UL/ULC listed applications

FIND IT



Swipe down for access

- SETTINGS
- ADVANCED SETTINGS
- ENTER CODE (1111, 2222)
- SYSTEM TESTS
- PANEL GLASS BREAK TEST

PANEL GLASS BREAK TEST

Glass Break Alarm Test Mode
Selecting "Start" will enable a 15 min test mode that allows the panel glass break detector to be tripped using a glass break simulator. Once tripped an alarm will be sent to the central station. Follow the on screen instructions to ensure a proper test.

RUN

RESET

START



FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SYSTEM TESTS

PANEL GLASS BREAK TEST

PANEL GLASS BREAK DETECTION REQUIREMENTS

Panel Installation Requirements:
- Wall mounted
- Power supply connected
- Panel Glass Break detection enabled
- Armed "Away" or "Stay" depending on programming





Glass Requirements
- Tempered Glass - 1/8" tO 1/4"
- Plated Glass - 1/8" to 1'4"
- Insulated Glass - 1/8" to 1/4"
- Window must be framed
- Minimum Dimensions 12" by 12"

DUAL PATH TEST

When enabled, dual path connectivity allows the IQ Panel 2 to use both cellular and Wi-Fi radios for signals and communication simultaneously.

By default Dual-Path Control is enabled. To disable, "un-check" the box.

You can also run a Dual-Path Wi-Fi test to ensure that the Dual Path is connecting properly. Unlike the standard Wi-Fi test (which checks connection to the router) the panel will check the broadband connection to Alarm.com.

NOTE: The IQ Panel 2 must be connected to a wi-fi network to enable Dual Path

NOTE: IQ Panel 2 is compatible with the following UL/ULC listed monitoring station receivers: SG-System I/II/III/IV/5. Wi-Fi is for supplemental use only for UL/cUL

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SYSTEM TESTS

DUAL PATH TEST

DAUGHTER CARDS TEST

Daughter Cards Test
Tests the integrity of installed daughter cards . Slots not populated will be "greyed" out and inaccessible to test.



Select "Run" on an individual available card to start the test. In some cases the test may take several minutes after which the panel will show a result of a "Pass" or "Fail".

If the test results in "Fail" double check the daughter card connection, reboot the panel and rerun the test again.

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SYSTEM TESTS

DAUGHTER CARDS TEST

PANEL TEST

Panel Test
Runs through and tests all panel processes either all at once or one at a time.



Select "Run" to perform an individual test or "Run All" to perform a test of all processes.

Running all tests at once will sound the siren.

Note: The Siren can be tested alone under the Panel Test menu, scroll down and select RUN

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

SYSTEM TESTS

PANEL TEST

CUSTOMIZATION

USER MANAGEMENT

The IQ Panel 2 can hold up to 242 user codes. Only Dealer, Installer and Master user codes can can create or edit user codes. Once a code is created, all information can be edited, except for the "User Type".

User Type	Access Level	Partition Access
Dealer	All settings as well as Master Reset and access to change Dealer Contact information	All Partitions
Installer	All Settings	All Partitions
Master	All user-related features and Settings, including connecting to Wi-Fi, User Management, Sound App and Sensor customization	All Partitions
User	Arming/Disarming	A user may only access their assigned partition
Guest	Arming/Disarming	A user may only access their assigned partition
Duress	Disarming (but sends duress signal to security provider).	Each partition gets a unique Duress Code

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

USER MANAGEMENT

NOTE: When "6 Digit User Code" is ENABLED a "00" will be appended to all existing 4 digit codes

DEALER BRANDING*

Dealer Branding
Here you can customize the Dealer Contact info, Logo, Help Videos and Billboard for any branding needs.

Contact Info
Edit Dealer Name, Email, Phone #, Zip Code, Website and Tag lines

Load Custom Logo
Add your company's logo to the panel replacing the envelope.

On-Screen Billboard
Add advertising images to the photo frame which cannot be deleted by a user.

Load Help Videos
Replace or add help videos to assist with end user troubleshooting

Dealer Branding Settings
Enable/Disable On-Screen Billboard photo lock feature

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (2222)

DEALER BRANDING

*This page available only through the Dealer Code

DEALER BRANDING*

Contact Info

Customize your contact info and determine what you'd like to be displayed in "Contact Us", located on the right side of the "Home Screen" header. Dealer Contact fields allow up to 50 characters, Tag Line 2 allows up to 50.

Example:

ABC Security
Automation & Security
Atlanta's Preferred
798-123-4567
jondoe@abcsecurity.com
ABCSecurity.com
84008

FIND IT



Swipe down for access

- SETTINGS
- ADVANCED SETTINGS
- ENTER CODE (2222)
- DEALER BRANDING
- CONTACT INFO

*This page available only through the Dealer Code

DEALER BRANDING*

Load Custom Logo
Load a custom dealer logo on to the Panel via micro SD Card. This image will replace the "envelope" icon in the upper right hand corner of the display.

NOTE: Before removing the SD Card, go to "Settings" then touch "SD Card" and select "Unmount"

Load Custom Logo Steps:

1. Load logo* onto an SD Card
2. Insert the SD Card into the panel
3. Go to the Dealer Branding section on the panel
4. Touch "Load Custom Logo"
5. Touch the thumbnail of the logo you wish to load
6. Touch OK

Logo requirements:

- Saved in folder entitled "logo"
- 200 x 100 pixels (or less)
- JPEG or PNG

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (2222)

DEALER BRANDING

LOAD CUSTOM LOGO

***This page available only through the Dealer Code**

DEALER BRANDING*

On-Screen Billboard

Load and lock up to 4 full-screen Dealer photos via micro SD Card as part of the photo frame screensaver. Dealer photos cannot be deleted by an end user.

NOTE: Before removing the SD Card, go to "Settings" then touch "SD Card" and select "Unmount"

Load On-Screen Billboard Photos:

1. Load photos* onto an SD Card
2. Insert the SD Card into the panel
3. Go to the Dealer Branding section on the panel
4. Touch "On-Screen Billboard"
5. Touch the thumbnails of the photos you wish to load
6. Then choose "Add New" or "Replace All"

Photo requirements:

- Saved in folder entitled "billboard"
- 1280 x 800 pixels (or less)
- JPEG or PNG

FIND IT



Swipe down for access

- SETTINGS
- ADVANCED SETTINGS
- ENTER CODE (2222)
- DEALER BRANDING
- ON-SCREEN BILLBOARD

***This page available only through the Dealer Code**

DEALER BRANDING*

Load Help Videos

Upload custom help videos with an SD Card. Make your own troubleshooting videos for your customers or use our built-in videos.



NOTE: Before removing the SD Card, go to "Settings" then touch "SD Card" and select "Unmount"

Load Help Videos:

1. Load videos* onto an SD Card
2. Insert the SD Card into the panel
3. Go to the Dealer Branding section on the panel
4. Touch "Load Help Videos"
5. Then choose "Add" or "Replace"

Video requirements:

- Saved in folder entitled "videos"
- Aspect ratio: 1280 x 800
- File Type: .m4v
- Total Storage Space: 200MB

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (2222)

DEALER BRANDING

LOAD HELP VIDEOS

***This page available only through the Dealer Code**

CONNECTING TO WI-FI

To connect to a Wi-Fi network, follow the steps below:

Swipe down from the top menu bar and select settings.

Touch Advanced Settings (Installer Code)

Then touch "Wi-Fi"

Enable Wi-Fi if not already active

Available networks appear in a list. Touch the desired network and use the keyboard to type the password (if required)



FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

WI-FI

WEATHER

H 36° L 20°

TODAY'S FORECAST

Today's forecast is displayed on the weather icon with a graphical representation of precipitation and High and Low temps.



4-DAY FORECAST

Touch the weather icon to get a 4-day forecast. This information is updated once daily via Alarm.com services. (Will not display or update weather connected to wifi only)

LOCATION

Weather reporting is based on location as indicated by the zip code entered into Alarm.com when the account is created.

FIND IT



Touch the weather icon in the upper left corner of the header to reveal a 4 day forecast

PHOTO FRAME

PHOTO FRAME

The IQ Panel 2 can be set to display digital photos when not in use. This feature, called "Photo Frame", can be changed or turned off through "Photo Frame Settings". (Swipe down from the menu bar).



SETTINGS

Display type
Choose a display type for your photo frame. Opt to turn it off completely, scroll through pre loaded images or view a "weather clock"

FIND IT



Swipe down for access

PHOTO FRAME

PHOTO FRAME APP BUTTONS

PLAY: Starts Photo Frame immediately. Good for testing photo frame feature appearance and transitions

REMOVE PHOTOS: Allows you to remove photos one by one or all at once

ADD PHOTOS: Add new photos using an SD card or download one of several "Wi-Fi" photo sets using your panel's WiFi connection. Android phones only can also transfer photos directly over bluetooth.

SETTINGS: Change the Photo Frame's "Display Type" from Off to On or enable a "Weather Clock" screen saver. Change transitions, adjust display time, set automatic on/off times and more

FIND IT



Swipe down for access

PHOTO FRAME

PHOTO FRAME SETTINGS

Item	Default	Description
Duration	1 minute	How long each image will show before transitioning to the next image in the library (1, 2, or 5 minutes)
Effect	Dissolve	Transition effect used between each image (fade to black, dissolve)
Shuffle	Enabled	Display pictures in random or sequential order
Display Type	Photo Frame	Choose what to display on the screen when the panel is not in use. (Off, Photo Frame and Weather Clock)
Photo Frame Start Time	10 minutes	Choose the amount of time to wait after the last touch before starting the selected display type. (1, 5, 10, 15, 20, 25, or 30 minutes)
Nighttime Mode Start Time	11:00 PM	Determines the time when the display, voices or chimes shutdown completely. (Use this feature to turn off the LCD, voices and/or chimes at night)
Nighttime Mode End Time	6:00 AM	Determines the time when the display, voices or chimes "wake up" after sleeping. (Use this feature to turn the LCD, voices and/or chimes back on in the morning)
Nighttime Mode Settings	Display	Choose what the Nighttime Mode Start/End times have the ability to control (Display, Voices and/or Chimes)

FIND IT



Swipe down for access

PHOTO FRAME

PHOTO FRAME SETTINGS

LOAD IMAGES FROM SD CARD



Card will slide all the way in.
To remove, push gently and card will spring out.

To load new images from an SD card:

1- Load photos* onto an SD Card
2- Insert the SD Card into the panel
3- Open the "Photo Frame" app
4- Press "Add Photos"
5- Choose "Replace All Photos" or "Add New Photos"
6- Wait for the images to load
7- Once loaded, you can press "Play" to test.

NOTE: Before removing the SD Card, go to "Settings" then touch "SD Card" and select "Unmount"

FIND IT



Swipe down for access

PHOTO FRAME

ADD PHOTOS

Photo requirements:

- JPEG
- 1280 x 800 pixels (or less)
- No larger than 5MB each
- No more than 20 images
- Saved in folder entitled "Photos"

MAINTENANCE

UPGRADE SOFTWARE

Upgrade Software

Upgrade the panel's software version using Wifi or an SD Card.

Setting	Description
Upgrade Using Network	Search the network for updates and install new software **NOTE:** For UL/cUL, remote software uploading is not allowed
Upgrade Using SD Card	Search an inserted SD Card for updates and install new software
Update Configuration Using SD Card	Search SD Card for settings configuration template and update panel settings using it
Downgrade Using Network	With the proper Patch Tag the system can be properly downgraded
Patch Tag	A code corresponding to a specific software update on the server
Automatic Background Check and Download	Allows the panel to check for new software in the background and download it to local storage so that it can be applied at a later date. Default **Enabled**
Automatic Check Interval	Determines interval the IQ Panel 2 will look for software update. Available options are Every Night, Once a Week, Once a Month. Default **Once a Week**

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

UPGRADE SOFTWARE

NOTE: Proper maintenance requires prompt administration of any software updates

UPGRADE SOFTWARE USING WI-FI

Keeping your panel up to date is essential in ensuring it receives the newest features and is free from bugs.

To perform a software update using Wi-Fi follow the steps below:

1- Ensure your panel is connected to Wi-Fi and has an internet connection.

2- From the drop down menu select “Settings" then “Advanced Settings”. (Installer/Dealer Code)

3- Touch "Upgrade Software"

4- Touch "Upgrade Using Network" The IQ Panel 2 will check for the latest software update. If your panel is up to date you will see a message confirming that you have the most recent software version.

5- If a software update IS available the panel will automatically begin downloading it.

6- Once the download is complete a pop up message will appear informing you that in order to install the software you must restart the panel. Touch "OK." Your panel will install the update and automatically restart.

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

UPGRADE SOFTWARE

NOTE: For UL/cUL the remote software feature shall not be used and the panel shall not be setup to remotely upgrade.

SOFTWARE UPDATES VIA SD CARD

1- Insert an SD card into your computer. *(*We recommend a class 4 or higher SDHC card with 4gb – 16gb storage space)*
2- Download the current software from *dealers.qolsys.com* *(requires login)*
3- Once the file is downloaded, right click the file and select "Unzip" or "Open"
4- Drag all files to your SD card. Delete ANY other files, and safely remove the SD card from your computer
5- Slide your SD card into the slot on the upper right side of the IQ Panel 2.
6- From the drop down menu Touch "Settings"
7- "Advanced Settings" and enter a valid Installer code *(default is 1111)*
8- Touch "Upgrade Software"
9- Touch "Upgrade using SD Card"
10- The panel will search the SD Card for the patch and begin downloading it automatically.
11- Once complete touch "OK" to reboot the panel. DO NOT TOUCH THE SCREEN. The process will take about 5 minutes and the LED may turn red, screen may turn off, etc. After the panel reboots the home screen will appear and the LED will turn green. For the next 5 minutes the panel will update the backup partition. Do not power down or use the panel during this time
11- Eject the SD Card: ("Settings" then touch "SD Card" then "Unmount SD Card"

IMPORTANT: Failure to perform these steps in the proper sequence may result in data corruption and/or panel failure.

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

UPGRADE SOFTWARE

AUTOMATIC BACKGROUND CHECK AND DOWNLOAD

Turning on Automatic Background Check & Download enables the panel to check for a new software version based on the Automatic Check Interval (default is Once a Week).

From the drop down menu select "Settings"

"Advanced Settings". (Installer/Dealer Code)

Touch "Upgrade Software"

Make sure the "Automatic Background Check and Download" button is checked.

Change update interval by selecting "Automatic Check Interval"

QUESTIONS? Contact us at techsupport@qolsys.com

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

UPGRADE SOFTWARE

BATTERY REPLACEMENT



1. **Power down panel:** Go to Advanced Settings and enter the Installer/Dealer/Master code, then select "Power Down"
2. **Unplug Battery Connector:** Once the panel is powered down, unplug 4 pin battery connector from the board.
3. **Remove Battery:** Pull the blue tab from under the battery downwards. This will peel away the tape holding the battery in place.
4. **Install New Battery:** Remove the protective film from the adhesive tape on the back of the battery and seat the battery into the bottom lefthand plastic corner. Plug the battery connector back into the board.

CAUTION:
Do **NOT** use a screwdriver or anything sharp that could puncture the battery.

Do **NOT** pull on the battery cable to try and remove battery.

TROUBLESHOOTING

ABOUT



FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

ABOUT

ABOUT

Item	Description	
Battery	Battery Status: Disconnected, Charging, Full	Battery Level: Displayed in %
Software	Software Version: Current Software Version Build Number:	LInux Version: Android Version:
Hardware	Hardware Version: Manufacturer: Qolsys Inc. San Jose, CA PCA Serial #: Part #: System Configuration:	System Serial #: RF PIC Version: EEPROM Format Version: Image Sensor Version:
Patches	Patch Description: Details of all previous patches applied	Last Upgrade Date:
Panel	MAC Address:	Panel Up Time:
Cellular	Carrier: Current Carrier Cellular Connection: no signal, registered etc.. Cellular Signal Strength: x/6 bars, (xx/xx) internal IMEI: Alarm.com radio number	IMSI: Carrier Sim Information ICCID: Carrier Sim Information Baseband Version: Configuration Version:

ABOUT

Item	Description	
Z-Wave	Home ID: Z-Wave Firmware Version: Z-Wave API Version:	Manufacturing ID: Product Type: Product ID:
PowerG	Modem Firmware Version Modem Build Number Radio Firmware Version	Radio Software ID PowerG RF Band
Ethernet	Connection: Connected/Disconnected IP Address: Panel's IP Address when connected	Internet: Can the panel communicate outside the home. Available/Unavailable
Wi-Fi Information	Connection: Connected/Disconnected IP Address: Panel's IP Address when connected SSID: Network panel is connected to	Speed: Connection speed shown in Mbps Internet: Can the panel communicate outside the home. Available/Unavailable
Internal Storage	Total Space: Total space shown in GB Available Space: Space available for media Photos: Breakdown of space used for photos	Videos: Breakdown of space used for videos Logs: Space used for storing panel logs
Zigbee	Zigbee Version: Zigbee Card EUI:	Zigbee Build Version:

POWER DOWN

DO NOT remove all power without following the steps below. In the event of needing to move the panel from one location to another it is safe to unplug the power supply while leaving the battery plugged in.

1. From the drop down menu select "Settings".
2. Select "Advanced Settings" then enter your installer code
3. Select "Power Down"
4. Wait for panel LED to turn off
5. Disconnect the power

IMPORTANT: Failure to perform these steps in the proper sequence may result in data corruption and/or panel failure.

QUESTIONS? Contact us at techsupport@qolsys.com

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

POWER DOWN

PANEL REBOOT

If the panel is experiencing difficulties you can often resolve it by resetting the operating system.

1. From the drop down menu select "Settings".
2. Select "Advanced Settings" then enter your installer code
3. Select "Panel Reboot"
4. Wait for the panel to restart

IMPORTANT: Failure to follow these steps properly may result in data corruption and/or panel failure.

QUESTIONS? Contact us at techsupport@qolsys.com

FIND IT



Swipe down for access

SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

PANEL REBOOT

HARD REBOOT



x 30 sec

IMPORTANT: Performing a hard reset may result in data corruption and/or panel failure. Only use this when absolutely necessary.

QUESTIONS? Contact us at techsupport@qolsys.com

PANEL TEST TROUBLESHOOTING

If you run a panel test and it fails, use the following steps to fix the issue.

Test	Description	If fails:
Arm-Disarm	Tests the arm/disarm operation	Reboot panel, run test again then if necessary perform a master reset and repeat test
Camera	Tests panel camera operation	Reboot panel, run test again then if necessary perform a master reset and repeat test
Photos	Checks that photos are loaded in the photo frame app	1) Go to Settings -> Photo Frame -> Add Photos 2) Add photos from Wifi photo sets or an SD card
Help Videos	Checks help videos are installed in the panel.	1) Go to Settings/Advanced Settings/Installation -> Load Help Videos 2) Load All the Help videos in SD card and insert it into panel 3) Add the selected files from SD card to help videos list on the panel
Battery	Checks panel battery health	1) Make sure the battery is connected 2) If test continues to fail, replace the battery
LED Green/Red	Check panel LED operation	1) Reboot the panel and run the test again 2) Master reset and repeat test

PANEL TEST TROUBLESHOOTING

Test	Description	If fails:
Panel Tamper	Check panel Tamper state	1) Check to ensure backplate is secure and installed properly. 2) Repeat test.
AC Status	Check panel AC power status	1) Inspect the wire leads are secure and properly connected on the terminal block and adapter. 2) Repeat test.
Internet Connection	Check panel's Internet connectivity	1) Go to Wifi Setting page, Enable Wifi and connect to a Wifi Network 2) Make sure Internet is available on the home router. You can check internet information in the "About" section. 3) Contact your network service provider on continued internet connectivity failure.
Wi-Fi	Tests whether panel is connected to Wifi network	1) Go to Wifi Setting page and enable wifi. 2) Connect to a Wifi Network
Upgrade Service	Checks that the panel can receive updates from the Qolsys servers	1) Verify internet and Wi-Fi connections.
Z-Wave	Check panel's Z-Wave module operation	1) Reboot the panel and repeat test. 2) Master reset and repeat test
Sirens	Check that the panel's siren is functioning properly (Burglar, Auxiliary, Fire & CO).	1) Verify the siren is plugged in

CANNOT LOAD HELP VIDEOS

If your panel cannot load a help video you will receive an error message. Please ensure that your video(s) meet the requirements:

Acceptable File types:
.m4v

Total storage space:
200MB

NOTE: videos look best
in aspect ratio
1280 x 800

LEGAL

IMPORTANT

Important warning and information can be found on the interior and exterior of the panel's mounting plate.





UL/cUL RESIDENTIAL FIRE & BURGLARY INSTALLATIONS

This product has been tested and found in compliance with the following standards: UL1023 Household Burglar-Alarm System Units, UL985 Household Fire Warning System Units, ULC-S545 Residential Fire Warning Systems Control Units and ULC-S304 Security Level I Control Units, Accessories and Receiving Equipment for Intrusion Alarm Systems. For ULC Installations refer to the Standard for the Installation of Residential Fire Warning Systems, CAN/ULC-S540:

- Use only the compatible power supply referenced in this Installation Manual. 24 h standby power must be provided for fire applications and 4h for burglary only applications (AC trouble must be transmitted to SRC within 60 minutes).
- Priority of signals on the Panel is set as Fire, CO, Burg, Panic, Aux and then Flood.
- Use at least one compatible listed Smoke Detector for Fire Installations.
- The entry delay shall not exceed 45 sec (UL) and 180 sec (ULC Security Level 1).
- The exit delay shall not exceed 120 seconds (UL).
- The control panel supports the Temporal 3 pattern for fire alarm notification
- Test transmission cycle shall be set for 7 days transmission for Residential Fire applications, or 30 days for Residential Burglary only applications.

Note: For ULC Residential Fire and Burglary (ULC-S304 Level I) installations set for daily test transmission, Wireless Supervision window shall be set to 4 hours for UL/ULC Residential Fire Installations. Wireless Supervision window shall be set to 24 hours for Residential Burglary Installations only. RF Jam detection shall be enabled. For UL Residential Fire installations, models PG9913 and PG9933 (Wireless CO) shall be used. Both CO detectors provide T4 CO alarm signal independent of the control unit and meet the 24 hour normal standby period followed by the 12 hour alarm period requirements. The control panel provides T4 audible CO alarm for at least 5 minutes following 24 hour normal standby.

UL/ULC COMMERCIAL BURGLARY INSTALLATIONS

This product has been tested and found in compliance with the following standards: UL1610 Central Station Burglar-Alarm Units and ULC-S304 Control Units, Accessories and Receiving Equipment for Intrusion Alarm Systems, Security Levels I-II.

The subscriber control unit shall provide for the connection of protective wiring, conductors, and attachments in accordance with the Standard for Installation and Classification of Burglar and Holdup Alarm Systems, UL 681 in USA and in accordance with ULC-S301, CSA C22.1, Canadian Electrical Code, Part I, Safety Standard for Electrical Installations and ULC-S302 Standard for the Installation, Inspection and Testing of Intrusion Alarm Systems, in Canada.

Note: The product is not intended for installation outdoors or outside the protected premises.

This product is UL/ULC listed under the following categories: AMCX/AMCXC Central Stations Alarm Units, UTOU/UTOU7 Control Units and Accessories, Household System Type NBSX/NBSX7 Household Burglar Alarm System Units. For further information on this product's listings please also refer to the official listing guides published at the UL website (www.ul.com) under Online Directory Section.

Programming:
The notes in the Installation Manual describing the system configurations for UL/uLC listed installations shall be implemented.

Use only PowerG sensors listed in "Supported PowerG Sensors" on page 176 of this installer manual for UL/ULC Commercial Burglary installations. Hardwire input zones cannot be used in UL/ULC Commercial Burg installations. Partitions have not been evaluated for UL/ULC Commercial Burg installations. Require valid user code to arm this system must be enabled.

UL/ULC COMMERCIAL BURGLARY INSTALLATIONS continued...

UL1610 Central Station with Standard or Encrypted Line Security Service and ULC-S304 Security Level I-II/A3 Active communication channel:

- The installation must use the integral cellular communicator, which sends events over Cellular Data Network to the compatible Sur-Gard System I/II/III/IV/5 receiver.
- The communication path supervision window is set to 180s with 90s heartbeat and the compromise detection takes place within 3 minutes. The panel is using encrypted line security AES256. NIST certificate C668.
- Wireless Supervision window shall be enabled and set to 4hours
- Open/Closing acknowledgment shall be enabled
- For ULC-S304 compliant installations using also the Wi-Fi connection, ensure Power for network equipment such as hubs, switches, routers, servers, modems, etc., is backed up or powered by an uninterruptible power supply (UPS), standby battery or the control unit, capable of facilitating 24 h standby.
- The entry delay shall not exceed 60s (UL) and 60s (ULC Security Level II).
- The exit delay shall not exceed 60s (UL) and 45s (ULC Security Level II).

UL/ULC COMMERCIAL BURGLARY INSTALLATIONS continued...

Protection of the Control Unit:
The local control unit and the local power supply must be protected in one of the following ways:

- The control unit and audible alarm device must be in a protected area which is armed 24 hours a day.
- Each partition must arm the area protecting the control unit and the audible alarm device power supply. This may require duplicate protection armed by each partition. Access to this protected area, without causing an alarm, will require that all partitions be disarmed.
- In all cases described above, the protected area for the control unit must be programmed as not-bypassable

For installations employing packet switched (network) communications such as Cellular/Wi-Fi the following recommendations shall be followed:

- Select the Internet Service Providers that have redundant servers/systems and Back-up power.
- Routers shall have Firewalls enabled and methods to identify and protect against "Denial of Service" attacks (i.e. via "spoofing").

UL/ULC COMMERCIAL BURGLARY INSTALLATIONS continued...

User Information:

- The installer should advise the user and note in the User's Manual
- Service organization name and telephone number
- The programmed exit and entry time
- Instructions to test system weekly
- Note that the installer code cannot arm or disarm the system
- The installer should caution the user not to give system information (e.g., codes, bypass methods, etc.) to casual users (e.g., service people) and to only give out codes set to expire within 24 hours
- Identification of the conditions that might be expected to result in false alarms or impaired operation of the product(s): arming the system and not respecting the exit delay, entering the protected premises and not respecting the entry delay for disarming the system can cause false alarms.
- Control units shall provide for the connection of protective wiring, conductors, and attachments in accordance with CAN/ULC-S301, Standard for Signal Receiving Centre Burglar Alarm Systems and Operations, or CAN/ULC S302, Standard for the Installation, Inspection and Testing of Intrusion Alarm Systems. See also Appendix C (Informative), False Alarm Prevention Features, for suggested false alarm prevention features.

FCC & ISED CANADA COMPLIANCE STATEMENT

This Class [B] digital apparatus meets all requirements of the Canadian Interference–Causing Equipment Regulations.
Cet appareil numérique de la classe [B] respecte toutes les exigences du Réglement sur le matériel brouilleur du Canada.

IMPORTANT! Changes or modifications not expressly approved by Qolsys Inc. could void the user's authority to operate the equipment.

CAUTION! This equipment complies with radiation exposure limits set forth for uncontrolled environment. The antenna(s) used for this transmitters must be installed to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC & ISED CANADA COMPLIANCE STATEMENT continued...

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

–Reorient or relocate the receiving antenna.
–Increase the separation between the equipment and receiver.
–Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
–Consult the dealer or an experienced radio/TV technician for help.

SPECIFICATIONS

SPECIFICATIONS

Items	Parameters	IQ Panel 2
Platform	Android OS	Android 5.1
LCD Display	Size	7" LCD
	Resolution	1280 x 800
	Brightness	300 cd/m2
	RGB	24bit
Touchscreen	Type	Capacitive glass multi-touch
User Codes	Up to 242	Role based (Dealer, Installer, Master, User, Guest, Duress)
Wireless	WiFi	Wi-Fi 802.11 a/b/g/n/ac dual band 2.4/5ghz - including built-in router capability
	Image Sensor	Supports up to 5 Alarm.com Image Sensors (if included)
	Z-Wave	Supports up to 152 devices (80 lights, 15 Smart Sockets, 20 Locks, 10 Thermostats, 21 Misc, 6 Garage Doors)
	Cellular	LTE (Bands 2,4,5,12,13,17)
	Security R/F	Up to 128 RF Zones. IQ Panel 2 uses Encrypted 319.5MHz. IQ Panel 2+ uses PowerG plus ONE of the following depending on SKU: Encrypted 319.5MHz, 345MHz or 433MHz.
	Bluetooth	Qualcomm Bluetooth Low Energy (BLE) 4.0
Hardwire Input	Wired x2	2 non powered closed loop circuit with 4.7k EOL resistor
Siren Output	Wired x1	1 controlled output (open collector), 300mA max with a 12v power supply wired in series. **NOTE:** For UL/cUL, external siren is for supplementary use only
Flash Memory	Internal Storage	12GB NAND Flash
SD Card Slot	Push-Push	Micro SD slot x 1

SPECIFICATIONS

Items	Parameters	IQ Panel 2
LED Indicator	Status LED	Green (Disarmed), Red (Armed)
Speaker	Stereo 1W x 2	Stereo speakers (unified audio)
Camera	Front Camera	5MP fixed focus
Microphone	Microphone	Stereo microphones x 2
Siren	Piezo	SPL minimum 85dB for UL985
Tamper	Tamper Switch	Reporting tamper release button
Battery	Type	Litium Polymer 3200mAh. Spring Power Technology (Shenzhen) CO., LTD, Model SP584646-1S2P
Buttons	Standby	Right side button used for sleep/wake, hard reboot, and clean screen cancel
Mechanical	Dimension	5"H x 7.75"W x .75"D (195mm x 130mm x 23mm)
Power Supply	AC/DC External Plug-in Adapter	Output: 5v – 7v 1000mA CC, Input 100-240VAC 50/60Hz. Adapter evaluated at 120vAC for UL/cUL
Mount	Back Plate	Wall mount or table top (stand included)
Certification	UL/cUL/ULC	UL/cUL Residential Fire and Burglary and UL/ULC Commercial Burglary Alarm Control Unit. Compliant with standards: UL985, UL1023, UL1610, ULC-S545, ULC-S304
	FCC	2AAJXQS-IQPANEL2 (may contain additional modules with separate FCC ID's)
	IC	11205A-QSIQPANEL2
	NOM	ANCE Certificado No.: ANC1901A00018806
Temperature	Operational	0 to 49C, up to 93% relative humidity, indoor, dry ordinary locations use only
	Storage	-20 to 50C

SUPPORTED S-LINE SENSORS

Detector Type	Model
Door/Window	QS1133-840[UL], (UL Listed M/N: 60-362N-10-319.5), QS1135-840, QS1136-840, QS1137-840
Door/Window - Shock Sensor	QS1138-840
Vanishing Door/Window Contact	QS1134-840[UL], (UL Listed M/N: IQ Mini)
PIR Motion Detector	QS1230-840[UL], (UL Listed M/N: 60-639-95R), QS1231-840
Glassbreak Detector	QS1431-840[UL], (UL Listed M/N: IQ Glass-S)
Smoke Detector	QS5110-840[UL]
Wireless CO Detector	QS5210-840
Keyfobs	QS1331-840
Tilt Sensor	QS1131-840
Flood Detector	QS5536-840
Temperature Sensor	QS5535-840
Hardwire Translator	QS7130-840, QS7131-840

NOTE: [UL] indicates that the device is certified to UL standards. These devices are not suitable for UL Commercial Burg applications.

SUPPORTED POWER-G SENSORS

Detector Type	Model
Door/Window	PG9945[UL RF/CB] , PG9307[UL RB], PG9309, PG9312[UL CB]
Door/Window - Shock Sensor	PG9935[UL CB]
Dual Tech (PIR+Microwave) Motion Detector	PG9984(P)[UL CB]
Glassbreak Detector	PG9922[UL CB]
Heat Detector	PG9936H[UL RF]
Keyfobs	PG9929, PG9939, PG9949, PG9938[UL CB]
Outdoor Motion Detector	PG9902, PG9974(P), PG9944, PG9994(P)[UL CB]
PIR Motion Detector	PG9904(P), PG9914, PG9924, PG9934(P), PG9862, PG9872[UL CB]
Sirens	PG9901, PG9911[UL RF/RB]
Smoke Detector	PG9916, PG9926, PG9936[UL RF]
Wireless CO Detector	PG9913, PG9933[UL RF]
Wireless Repeater	PG9920[UL CB]
Vanishing Door/Window Contact	PG9303[UL CB], PG9975[UL RB]
PowerG Wired to Wireless Converter	PG9WLSHW8[UL RFB CB]

NOTE: Only the PowerG sensors marked with [UL CB] in the table above shall be used in UL/ULC Residential and Commercial Burg (UL1610/ULC-S304 Security Level I-II) listed installations. Devices marked with [UL RB] in the table above shall be used only in UL/ULC Residential Burg (UL1023/ULC-S304 Security Level I) listed installations. Devices marked with [UL RF] in the table above can be used in UL/ULC Residential Fire (UL985/ULC-S545) listed installations.

SUPPORTED 433 MHz (SRF433 DSC protocol) SENSORS

Detector Type	
Door/Window	WS4945[UL]
PIR Motion Detector	WS4904P[UL], WLS914-433[UL]
Glassbreak Detector	WLS912L-433[UL]
Smoke Detector	WS4936[UL]
Wireless CO Detector	WS4933[UL]
Keyfobs	WS4938[UL], WL4939[UL]
Tilt Sensor	WS4965[UL]
Flood Detector	WS4985[UL]
Repeater	WS4920[UL]

NOTE: [UL] indicates that the device is certified to UL standards. These devices are to be used only for UL residential fire and burg applications and are not suitable for UL Commercial Burg applications. IQ Panel 2 shall use security RF modem radio card model SRF-433 DSC (DSC protocol).

SUPPORTED 433 MHz (SRF433 AT&T Digital Life) SENSORS

Detector Type	
Door/Window	SW-ATT-V2[UL]
Recessed Door/Window Contact	SW-ATT-RDW[UL]
PIR Motion Detector	SW-ATT-PIR[UL]
Glassbreak Detector	SW-ATT-GB[UL]
Smoke Detector	SW-ATT-SMKT[UL]
Wireless CO Detector	SW-ATT-CO[UL]
Keyfobs	SW-ATT-FOB
Repeater/Signal Booster	SW-ATT-RPTR4[UL]
Hardwire Translator	SW-ATT-TAKRF[UL]

NOTE: [UL] indicates that the device is certified to UL standards. These devices are to be used only for UL residential fire and burg applications and are not suitable to UL Commercial Burg applications. IQ Panel 2 shall use security RF modem radio card model SRF-433AT&T (Digital Life protocol).

IQ Panel 2
QS9201-1200-840
QS9202-1200-840

IQ Panel 2+

Verizon	AT&T	Telus
QS9201-1208-840	QS9202-1208-840	QS9207-1208-124
QS9201-5208-840	QS9202-5208-840	QS9207-5208-124
QS9201-4208-840	QS9202-4208-840	QS9207-4208-124

Conforms to UL Std. S985, 1023. & 1610
Certified to ULC Sub C1023 & ULC Std S545

Qolsys Inc. proprietary.
Reproduction without permission is not permitted.

Document#: IQP2-IM-8-20
Revision Date: 04/19/21
Software version: 2.6.0