




GRUPOamper

Gateway AM-GZ80x

Precautions & Guarantee



Content

1	CAUTIONS, WARNINGS & STATEMENTS.....	3
1.1	GENERAL AND SAFETY PRECAUTIONS.....	3
1.2	SYMBOLS USED IN THIS MANUAL.....	3
2	GUARANTEE.....	6
2.1	CASES NOT INCLUDED IN THE COVERAGE OF THE WARRANTY.....	6
2.2	USER RESPONSABILITIES.....	6
2.3	AMPER RESPONSABILITIES.....	7
2.4	LIMITATIONS.....	7

1 CAUTIONS, WARNINGS & STATEMENTS

1.1 GENERAL AND SAFETY PRECAUTIONS.

- Supplied devices and hardware are not toys. Use them responsibly.
- The company declines all responsibility for any negligence in the use, installation and operation of the devices when the instructions for use are not followed.
- Keep out away of children.
- Exercise extreme caution during handling.
- Read this manual thoroughly, observe all instructions and retain it for future reference.
- Devices and accessories may be updated without prior notice.



Before the first use of the devices, please make sure they have no damage. if any device or cables are damaged, please do not use them and contact our technical service.

1.2 SYMBOLS USED IN THIS MANUAL



This symbol is used in this manual to indicate safety warnings, which, if not followed, could lead to accidents and injuries.



This symbol indicates important details to keep in mind.



This symbol indicates important details regarding the environment.

CE Declaration of Conformity

This equipment complies with the requirements for electromagnetic compatibility, EN55022 Class B for ITE and EN 50082-1. This meets the essential protection requirements of the European Council Directive 89/336 / EEC in the approximation of Member States laws relating to electromagnetic compatibility.

European Directive 1994/62 / EC

The packaging of the product is optimized to minimize the negative effects on the environment. If you dispose of them, do so responsibly.

European Directive 2002/96 / EC

Through this document, we inform about the European Directive on recycling of Electrical and Electronic Equipment (WEEE). This directive concerns the management of waste from electrical appliances and arises from certain EU measures to protect the environment. It contemplates the introduction of a compulsory collection and recycling system for electrical and electronic equipment. The user is responsible for taking the device to a recycling centre at the end of its useful life. Recycling companies remove harmful materials from the devices and process it according to established directives. This procedure is intended to increase the amount of reusable materials.



This symbol means that your damaged electronic device must be stored separately and not mixed with normal waste. The European Union has implemented a specific collection and recycling system in which producers are responsible.

This appliance has been designed and manufactured with high quality materials and components that can be recycled and reused.

Electrical and electronic materials contain parts that are necessary for the system to work properly, if not handled correctly they can harm health and the environment.

Therefore, please do not throw your damaged device with normal trash.

If you are the owner of the appliance, you must deposit it at the appropriate local collection point or leave it to the supplier when you buy a new appliance.

If you are a professional user, please follow the instructions of your provider. If the appliance is rented or left to your care, please contact your supplier.

Help us to protect the environment we live in!



¡Warnings!

Attention: Failure to follow these instructions could result in death or serious personal injury.

1. Read all instructions carefully before connecting the equipment to your power source.
2. Verify the device's power type in the labelling.
3. Use the power adapter included in the packaging of your device. To reduce the risk of electric shock, do not remove the cover or attempt to disassemble it. Opening or removing the cover may expose you to dangerous voltage levels. Likewise, improper mounting may cause electric shock with the use of the device.
4. Do not expose this device to fire, direct sunlight or excessive heat.
5. Do not expose this equipment to rain or moisture and do not allow it to come in contact with water.
6. Do not install this device in an environment where IMPACT RISK is likely to occur.
7. You can clean this device using a thin cloth. Never use solvents or abrasive products that can damage the plastic surface. Never use spray or other cleaning products.
8. Be careful not to scratch the plastic surface.
9. The device is designed to operate in temperatures between 0 ° C and 40 ° C.
10. The device must be installed at least 1 meter from radio frequency equipment, such as TVs, radios, hi-fi or video (which can radiate electromagnetic fields).
11. Do not install the equipment behind a cabinet or any heavy equipment, or otherwise block the wireless signal.
12. Do not quickly disconnect and reconnect the power connection of the device or damage it. If you have to turn it off, use the tools within the program intended for that purpose. If an operator instructs you to disconnect, wait at least 10 seconds before reconnecting.
13. Do not connect the Ethernet port to any network other than Ethernet.
14. Do not attempt to upgrade this equipment in an environment with electrical instability. This could cause unexpected problems.
15. Do not operate the system or connect / disconnect cables during lightning storms.
16. Children are not aware of the hazards of electrical appliances. Therefore, keep the device under adult supervision or out of the reach of children.

Do not attempt to repair the device yourself. If you experience problems with the equipment, or need repair or warranty information, please contact your supplier.

This device is intended for indoor use only.

Do not connect devices to USB ports that are not explicitly approved by **AMPER**.

2 GUARANTEE

AMPER warrants to the original purchaser of the equipment for a period of 12 months from the date of purchase (as stated on receipt of purchase), this product will be free from defects in material and workmanship and will operate in accordance with the detailed description in This manual, the quick start guide and the service user manual.

If the product is defective in material or workmanship, or if the product does not function as guaranteed during the warranty period, **AMPER** will replace it once the ARM (Return Merchandise Authorization) protocol has been met. The replacement mentioned above with respect to the product will be the total responsibility of AMPER.

AMPER will transfer to the user the guarantees on the materials granted by the manufacturer to the extent that they are transferable, but will not guarantee any material independently.

2.1 CASES NOT INCLUDED IN THE COVERAGE OF THE WARRANTY

This warranty does not apply if the product is damaged by transportation, handling, storage, accident, abuse or misuse, if the product has been used or maintained without following the instructions in this document, if it has been modified Some form or if the serial number has been deleted or has something written on it. The repair or modification of the product by any means other than an authorized agent will void this warranty

2.2 USER RESPONSABILITIES

To receive this warranty service during the period in which the product is guaranteed, as established above, the user must send a request to **AMPER** complete the following steps:

1. Contact **AMPER** Technical Support for an RMA number (Material Return Authorization).
2. Return the damaged product to the address provided by the technical support service of (the shipping costs are assumed by the user).
3. Lastly, provide proof with the original date on which the purchase was made.

AMPER will not accept shipments with postage due as warranty service. However, it will assume the cost of sending the replacement products sent to the user after completing the previous three steps. The products sent for repair may be replaced by replacement parts of the same type instead of repairing them. For the repair of the articles can be used restored or used. If **AMPER**, in its sole discretion, cannot replace the defective product, it will reimburse the estimated price at which the product is valued after the time it has been in use.

IF THE PRODUCT HAS THE ABILITY TO STORE SOFTWARE, DATA AND OTHER INFORMATION PROGRAMS, COPIES OF SAFETY SHOULD BE PERIODICALLY CARRIED OUT OF THE INFORMATION CONTAINED IN THE STORAGE SUPPORTS IN ORDER TO PROTECT THE CONTENTS AND TO CAUSE CAUSES OF POSSIBLE OPERATION FAILURES. **DURING THE WARRANTY PERIOD OR ANY OTHER TYPE OF TECHNICAL SUPPORT, THE CONTENTS OF THE PRODUCT STORAGE SUPPORT MAY BE LOST, REPLACED OR FORMED.** IN NO EVENT, SHALL **AMPER** AND ITS AGENTS BE LIABLE FOR ANY LOSS OF SOFTWARE, DATA OR OTHER INFORMATION PROGRAMS CONTAINED ON THE STORAGE SUPPORT OR IN ANY OTHER PART OF THE PRODUCT RECEIVING THE SERVICE.

2.3 AMPER RESPONSABILITIES

Whenever the user complies with the obligations set forth above in the section, **AMPER** will replace the product with an equal or equivalent functionality, at its discretion, without any charge (except shipping costs, as indicated above)

2.4 LIMITATIONS

The foregoing warranty is in lieu of and **AMPER** disclaims all other warranties, whether oral or written, express or implied, including any warranty or merchantability or fitness for a particular purpose. Any implied warranties, including any warranties of merchantability or fitness for a particular purpose, that have not been denied or that have superseded the foregoing, shall be limited to 24 months of the foregoing warranty. No other representation or claim of any nature made by any person shall be binding on the **AMPER** or will modify the terms of the warranty and liability.

In no event shall **AMPER** be liable for special, incidental, consequential, or other damages resulting from the possession or use of the equipment, including without limitation damage to property and, to the extent permitted by law, Personal injury, even if the **AMPER** knew or knew of the possibility of such damages. Some countries do not allow limitations on the duration of an implied warranty and / or the exclusion or limitation of damages, in which case the foregoing limitations or exclusions may not apply to the User. S & C does not authorize any person or party to assume or create for him any other obligation or responsibility related to the products except as indicated herein.

IN NO EVENT, SHALL S & C BE LIABLE FOR ANY INDIRECT, INCIDENTAL, PUNITIVE, SPECIAL OR CONSEQUENTIAL DAMAGES OR DAMAGES FOR LOSS OF DATA, BENEFITS, INCOME OR USE INCURRED BY YOU OR ANY THIRD PARTY, WHETHER IN CONTRACT OR TORT, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES