# Z-Wave Protocol Implementation Conformance Statement

## S100 iO Master Roller Blind

## General Information

| | |
|---|---|
| **Product Identifier:** | 10002081-13X |
| **Brand Name:** | Simon |
| **Product Version:** | HW: 1 FW: 4.24:76.51 |
| **Z-Wave Certification #:** | ZC10-18026014 |

## Product Features

| | |
|---|---|
| **Neutral Wire Required** | Yes |
| **Z-Wave Scene Type** | Central Scene |
| **Firmware Updatable** | Updatable by Professional/Technician |

## Z-Wave Product Information

| | |
|---|---|
| Supports Z-Wave Beaming Technology? | Yes |
| Supports Z-Wave Network Security? | Yes |
| Supports Z-Wave AES-128 Security S0? | No |
| Supports Security S2? | No |
| SmartStart Compatible? | No |

## Z-Wave Technical Information

| | |
|---|---|
| **Z-Wave Frequency:** | CEPT (Europe) |
| **Z-Wave Product ID:** | 0x0000 |
| **Z-Wave Product Type:** | 0x0005 |
| **Z-Wave Hardware Platform:** | ZM5202 |
| **Z-Wave Development Kit Version:** | 6.51.07 |
| **Z-Wave Library Type:** | Enhanced Slave |
| **Z-Wave Device Type / Role Type:** | Wall Controller / Always On Slave |

## Association Group Information

| Group # / Max Nodes | Description |
|---|---|

## S100 iO Master Roller Blind

2 / 20         ctrl. This group is used to add the devices to be controlled by Master Roller blind. Device sends Basic Sets, Multilevel Start or Stop level change when controlling sunblinds, and Manufacturer specific Gets, Configuration Gets and Sets when manual association is being performed over Simon devices.

**Supported Command Classes (12):**

| | |
|---|---|
| Association Group Information V3 | Association V2 |
| Basic | Central Scene V3 |
| Configuration V2 | Device Reset Locally |
| Firmware Update Meta-Data V4 | Manufacturer Specific V2 |
| Powerlevel | Switch Multilevel V3 |
| Version V2 | Z-Wave Plus Info V2 |

**Controlled Command Classes (5):**

| | |
|---|---|
| Association V2 | Basic |
| Configuration V2 | Manufacturer Specific V2 |
| Switch Multilevel V3 | |