


Inclusion of Z-Wave product



Select **More** in the right lower corner of the screen.



Select **Z-Wave**.




Select **Include device** for unsecure inclusion.
Select **Include device securely** for secure inclusion.

Exclusion of Z-Wave product



Select **More** in the right lower corner of the screen.



Select **Z-Wave**.




Select **Exclude device**.

Set the controller in Controller Learn Mode



Select **More** in the right lower corner of the screen.



Select **Z-Wave**.




Select **Activate learn mode** to enter learn mode.

Product Reset



Select **More** in the right lower corner of the screen.



Select **Z-Wave**.



Select **Factory reset Z-Wave controller** to reset Z-Wave controller.