

Overview

This Quick Start Guide (QSG) provides the basics to set up the DEN Smart Home app and configure a SmartStrike. Refer to the complete Installation Guide and User Guide located at densmarthome.com for more information on installing the SmartStrike and using the app.


Before you begin

In order to setup and use the DEN Smart Home app there are items required such as the SmartStrike and access to the QR for the SmartStrike. Ensure that the SmartStrike is close by and the battery door is removed and available. Important! Always use 2 AA Lithium batteries.

Install the DEN SmartStrike™ app


The app is available for download in the Google Play store and the iOS App Store.





Create a DEN User Account

1




Open the app and select register at the bottom of the screen.

2



Enter your name and select next.

3




Create a password and select next.

4




5



DEN SMARTSTRIKE™


Quick Start Guide




Add a profile Image from your phone's camera or gallery.

A message will appear indicating that the account has been created. However, before it can be used your email must be verified. Check your email for a message from DEN Smart Home to verify your account. Once verified, return to the app to login.


Register Your SmartStrike™



Enter the credentials for your account and select sign In.





Setup two-factor authentication. Refer to the app User Guide for details on two-factor authentication.



Remove the battery door from the SmartStrike and scan the QR code located on the inside of the door. Reattach the battery door to the SmartStrike.

DEN SMARTSTRIKE™

Quick Start Guide




When the device is located, select add to location to proceed.



Create a location for the SmartStrike and select next.



Add an image for the location from your phone's camera or gallery.



Create a name for the SmartStrike that best identifies the door it will unlock.




The SmartStrike will perform a test to verify connection.



When the device registered message appears the SmartStrike can now be used.

DEN SMARTSTRIKE™

Quick Start Guide



If a device out of range message appears, move closer to the SmartStrike and try connecting to the SmartStrike.



If a SmartStrike already registered message appears, unregister the device. Refer to app User Guide for steps.