

ZW32 Smart Outlet Manual

Federal Communications Commission (FCC) Statement

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

IC Caution:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

DECLARATION DE CONFORMITE D'INDUSTRIE CANADA

Ce périphérique a été testé et reconnu conforme aux limites spécifiées dans RSS-210.

Son utilisation est soumise aux deux conditions suivantes :

- (1) il ne doit pas provoquer d'interférences gênantes et
- (2) il doit tolérer les interférences reçues, notamment celles susceptibles d'en perturber le fonctionnement.

WARRANTY

Evalogik Products warrants this product to be free from manufacturing defects for a period of two years from the original date of consumer purchase. This warranty is limited to the repair or replacement of this product only and does not extend to consequential or incidental damage to other products that may be used with this product.

This warranty is in lieu of all other warranties, expressed or implied. Some states do not allow limitations on how long an implied warranty lasts or permit the exclusion or limitation of incidental or consequential damage, so the above limitations may not apply to you.

This warranty gives you specific rights, and you may also have other rights which vary from state to state. If the unit should prove defective within the warranty period.

SPECIFICATIONS

Model: ZW32

Power: 120 VAC, 60 Hz.

Signal (Frequency): 908.42 MHz.

Maximum Loads: 600W, incandescent,

½ HP Motor or 1800W (15A) Resistive

Range: Up to 100 feet line of sight between the

Wireless Controller and the closest Z-Wave

receiver module.

Operating Temperature Range: 32-104° F (0-40° C)

For indoor use only.

Specifications subject to change without notice

due to continuing product improvement

Website www.nie-tech.com

WARNING

RISK OF FIRE

RISK OF ELECTRICAL SHOCK

RISK OF BURNS

CONTROLLING APPLIANCES:

EXERCISE EXTREME CAUTION WHEN USING Z-Wave DEVICES TO CONTROL APPLIANCES. OPERATION OF THE Z-Wave DEVICE MAY BE IN A DIFFERENT ROOM THAN THE CONTROLLED APPLIANCE, ALSO AN UNINTENTIONAL ACTIVATION MAY OCCUR IF THE WRONG BUTTON ON THE REMOTE IS PRESSED. Z-Wave DEVICES MAY AUTOMATICALLY BE POWERED ON DUE TO TIMED EVENT PROGRAMMING.

DEPENDENT UPON THE APPLIANCE, THESE UNATTENDED OR UNINTENTIONAL OPERATIONS COULD POSSIBLY RESULT IN A HAZARDOUS CONDITION. FOR THESE REASONS, WE RECOMMEND DO NOT RETURN THIS PRODUCT TO THE STORE THE FOLLOWING:

DO NOT USE Z-Wave DEVICES TO CONTROL ELECTRIC HEATERS OR ANY OTHER APPLIANCES WHICH MAY PRESENT A HAZARDOUS CONDITION DUE TO UNATTENDED OR UNINTENTIONAL OR AUTOMATIC POWER ON CONTROL.



Smart Outlet

Turn ON/OFF manually or remotely via the Z-Wave controller

- Can be Included in multiple Groups and Scenes
- Compatible with all incandescent and CFL/ LED bulbs
- Blue LED indicates switch location in a dark room
- Z-Wave Certified for simple pairing and integrated home automation
- Screw Terminal Installation — requires wiring connections for Line (Hot), Load, Neutral.

WARNING — SHOCK HAZARD

Turn OFF the power to the branch circuit for the switch and lighting fixture at the service panel. All wiring connections must be made with the power OFF to avoid personal injury and/or damage to the switch.

- A. Receptacle
- B. Lin (Black) - Line in
- C. Nin (White) - Nutral in



Single receptacle wiring

1. Shut off power to the circuit at circuit breaker or fuse box.

IMPORTANT! Verify power is OFF to outlet box before continuing.

2. Remove wall plate.
3. Remove the outlet mounting screws.
4. There are two screw terminals on the outlet; these are marked
 - B. Lin — Black (connected to power)
 - C. Nin — White(Nutral)

5. Observe Important Wiring Information

IMPORTANT!: This outlet is rated for and intended to only be used with copper wire. Wire Gauge Requirements Use larger wires suitable for at least 80° C for supplying Line (HOT), Load, Neutral connections.

Wire strip length:

For attachment to screw terminals: Strip insulation 1" , For attachment using the enclosure's holes: Strip insulation 5/8".

7. Connect the black wire that comes from the electrical service panel (Hot) to the terminal marked Lin.
8. Connect the white wire to the neutral terminal marked Nin (use jumper wire if needed).
9. Insert smart outlet into the switch box being careful not to pinch or crush wires.
10. Secure the outlet to the box using the supplied screws.
11. Mount the wall plate.
12. Reapply power to the circuit at fuse box or circuit breaker and test the system.

Basic Operation

The connected outlet can be turned ON/OFF Remotely with a Z-Wave Controller

2. Linking your Z-Wave device

Reset Outlets to factory default:

Use controller to remove device from network will reset it to factory default

Adding device into the network:

1. Follow the instructions for your Z-Wave certified controller to include a device to the Z-Wave network.
2. Once the controller is ready to include your device, triple press the front button to include it into the network.
3. Once your controller has confirmed that the device has been included, refresh the Z-Wave network to optimize performance.
4. The device is associated in the same group when it included in setting process. Now you can control your Z-Wave device according to groups, scenes, schedules and automation programmed. If your controller features remote access, you can now control all devices in Z-Wave network from mobile devices.

To exclude the device

1. Follow the instructions for your Z-Wave certified controller to exclude a device from the Z-Wave network.
2. Once the controller is ready to Exclude your device, triple press the front button to exclude it from the network.

Note: Your controller may need to be within 10 feet of the device to be included.

All non-battery nodes within Z-Wave network will act as repeater.

The association group supports five nodes and lifeline function.

Use this procedure only in the event that the network primary controller is missing or otherwise inoperable.

Package content

In-wall Smart Outlet-1pcs

Screw-2 pcs

Installation Operation manual-1pcs