

## Z-Wave Protocol Implementation Conformance Statement

### FIBARO Swipe

#### General Information

<b>Product Identifier:</b>	FGGC-001
<b>Brand Name:</b>	FIBARO
<b>Product Version:</b>	1
<b>Z-Wave Certification #:</b>	ZC10-16030005

#### Z-Wave Product Information

Supports Z-Wave Beaming Technology?	Yes
Supports Z-Wave Network Security?	Yes
Supports Z-Wave AES-128 Security S0?	No
Supports Security S2?	No
SmartStart Compatible?	No

#### Z-Wave Technical Information

<b>Z-Wave Frequency:</b>	CEPT (Europe)
<b>Z-Wave Product ID:</b>	0x1000
<b>Z-Wave Product Type:</b>	0x0D01
<b>Z-Wave Hardware Platform:</b>	ZM5101
<b>Z-Wave Development Kit Version:</b>	6.51.06
<b>Z-Wave Library Type:</b>	Enhanced Slave
<b>Z-Wave Device Type / Role Type:</b>	Wall Controller / Portable Slave

#### Association Group Information

Group # / Max	Description
<b>Nodes</b>	
1 / 1	“Lifeline” reports the device status and allows for assigning single device only (main controller by default).
2 / 5	“Flick UP” is assigned to moving the hand up over the panel (sends Basic Set command frames).
3 / 5	“Flick DOWN” is assigned to moving the hand down over the panel (sends Basic Set command frames).
4 / 5	“Flick LEFT” is assigned to moving the hand from the right to the left side of the panel (sends Basic Set command frames).
5 / 5	“Flick RIGHT” is assigned to moving the hand from the left to the right side of the panel (sends Basic Set command frames) .

# Z-Wave Protocol Implementation Conformance Statement

(Continued)

## FIBARO Swipe

6 / 5                    “Circular AirWheel” is assigned to circular move of the hand clockwise or counter-clockwise over the panel  
(sends Switch Multilevel Start/Stop Level Change command frames).

### Controlled Command Classes (3):

Basic

Central Scene

CRC16 Encapsulation