

**VZW31-SN**

# **Instructions**

# Next Gen Smart Lighting

We're excited to have you on this journey with us and we're here for you every step of the way. Not only are we smart home owners ourselves, but we build all of our products alongside 1,000's of passionate community members. To see how the project came to life and how everyone contributed, please see Page 54 or visit: [inov.li/phoenix](http://inov.li/phoenix). It's truly amazing working with people of all walks of life and even more humbling to see everyone's dedication to making some of the best smart home products.

Thank you so much for your trust in us and welcome to the next generation of smart lighting with Inovelli.

Eric H. - Founder/CEO

Eric M. - Founder/CTO

Handwritten signatures of Eric H. and Eric M. in black ink. Eric H.'s signature is on the left, and Eric M.'s signature is on the right.

# Table of Contents

Quick Setup & Inclusion	05	Advanced Features	43
Wiring	11	Switch Parameters	45
Warnings	14	Other Advanced Features	46
Vocabulary	21	Z-Wave™ Information	47
Steps 1-4	22	Product & Contact Info	61
Step 5 - Installation	30	FCC/IC Info	63
Pre-Setup	31	Product Info	66
Example	33	Contact/Warranty Info	67
Configuration & Mode	34	Project Phoenix	68
Hub/Gateway Setup	37		
SmartThings	39	Scan for the most	
Home Assistant	40	recent instructions or	
Hubitat	41	visit: <a href="http://inov.li/vzw31sn">inov.li/vzw31sn</a>	



# Navigating this Manual

We designed this manual as if we were installing the switch ourselves. We suggest reviewing the full manual before beginning the installation process. There are five areas this manual covers:

1. Getting to know your switch
2. Figuring out your wiring
3. Pre-programming your switch (after wiring installation)
4. Connecting to your hub/gateway
5. Configuring your switch (optimize the settings)

As we continue to work with hub manufacturers, and improve our products. It may be necessary to periodically update this manual. You can always find the latest version of this manual by visiting: [inov.li/vzw31sn](http://inov.li/vzw31sn)

**Quick Setup & Inclusion.**

# Quick Setup Notes

We get it, you're ready to go. No need to flip through the manual, you want the abridged version. **This section assumes you have your switch wired correctly and the blue LED Bar is lit up.**

It also assumes you know how to enter the Z-Wave pairing mode on your hub/gateway (and have a Z-Wave compatible hub/gateway).

To see which hubs are compatible, please visit: [inov.li/vzw31snhubs](https://inov.li/vzw31snhubs)


While these instructions likely won't change, for the most up-to-date instructions, we recommend scanning the QR code to the right or to visit: [inov.li/vzw31snQS](https://inov.li/vzw31snQS)



# Including Your Switch

**Auto-Pairing:** The switch will automatically start the inclusion process when power is restored. To indicate the switch is in inclusion mode, the LED Bar (D) will pulse blue. If the LED Bar (D) is not pulsing, tap the config button (C) 3x rapidly or pull the air-gap (E) out and push it back in. Start the Z-Wave inclusion process on the hub at any time. If successful, the LED Bar (D) will flash green.

If the switch is unsuccessful during inclusion, you can exclude (reset) the switch by putting your gateway in exclusion mode and pressing the config button (C) three times. The LED Bar (D) will pulse blue and then flash green if successful or red if not. After exclusion, you can try inclusion again.



# Getting to Know Your Switch

Please use the next couple pages to get to know your smart switch.

**A. Light On / Increase Dim % Level:** Tap 1x to turn on your light or hold to increase the brightness level (dim percentage). In addition, it can be used to activate scene control (multi-taps and holds) where up to 7 scenes can be added\*.

**B. Light Off / Decrease Dim % Level:** Tap 1x to turn off your light or hold to decrease the brightness level (dim percentage). In addition, it can be used to activate scene control (multi-taps and holds) where up to 7 scenes can be added\*.


**C. Config / Favorites Button:** Used to configure certain



parameters of the switch. In addition, it can be used to activate scene control (multi-taps and holds) where up to 7 scenes can be added\*.

**D. RGB LED Bar:** Multi-functional LED bar that shows the % level at which your switch is at. In addition, it can be used as a notifier\* for various events (ie: turn red when alarm is armed, pulse purple if garage is left open, etc).

**E. Air Gap:** This can be pulled out to cut power to the load and is there for safety purposes.



\* Hub must support these features. Please see pg. 46.

# Quick Tap Sequences

If you are using your switch as a Dimmer or Multi-Way setup, please see the quick tap sequences below or visit pages 34-35 for more details. The Single-Pole and On/Off tap sequence is not shown because it is the default setting (no programming needed).

Wiring Type	Sequence	Confirmation
Multi-Way (Toggle)	Hold on ↓ paddle, tap config 5x, release	Violet
Multi-Way (Aux)	Hold on ↑ paddle, tap config 5x, release	White
Switch Type	Sequence	Confirmation
Dimmer	Hold on ↓ paddle, tap config 3x, release	Orange
Smart	Hold on ↑ paddle, tap config 4x, release	Yellow

**Wiring.**

# Wiring Notes

Due to the number of ways these switches can be wired, all schematics are housed online and you can access the schematics by scanning the QR Code at the bottom right, or by visiting: [inov.li/vzw31snwiring](http://inov.li/vzw31snwiring)

To work your way through this section, first read the warnings, then familiarize yourself with the vernacular used. Finally, keep notes as you go through the first three (3) steps as you will use them to determine whether or not your wiring is compatible and whether or not you have to pre-program/setup your switch (pg. 28).

Finally, please do not attempt to install these switches if you are unfamiliar with electrical as serious injury can occur.



# Safety Reminder

Consult a qualified electrician if necessary as **we are unable to give wiring advice outside of schematics.**

If you are unsure how electrical circuits work, please do not try installing this device. As exciting as it is to have a smart switch installed, it can be dangerous and even life-threatening if you do not install it correctly. Improper installation will void the product's warranty.

Please read through the warnings on the next few pages before installing your switch. We can't stress enough how dangerous installation can be if you don't know what you're doing.

# Warnings

**Caution - Please Read:** This device (Vzw31-SN) is intended for installation in accordance with the National Electric Code and local regulations in the United States, or the Canadian Electrical Code and local regulations in Canada. If you are unsure or uncomfortable about performing this installation consult a qualified electrician. This product is made for indoor use only and is not designed or approved for use on power lines other than 120VAC, 60Hz, single phase. Attempting to use this Vzw31-SN on non-approved power lines may have hazardous consequences.

**Attention - Information importante:** Cet appareil (Vzw31-SN) est conçu pour être installé conformément au « National Electric Code » et aux réglementations locales aux

États-Unis, ou au Code canadien de l'électricité et aux réglementations locales canadiennes. Si vous ne vous sentez pas à l'aise ou qualifiés pour effectuer cette installation, veuillez consulter un électricien qualifié. Ce produit est conçu pour une utilisation intérieure uniquement et n'est pas conçu ou approuvé pour une utilisation avec une ligne électrique ayant un voltage autre que 120 VCA, 60 Hz, monophasé. L'utilisation du Vzw31-SN avec une ligne électrique non approuvée peut avoir des résultats dangereux.

**Other Warnings:** Risk of Fire, Electrical Shock & Burns

**Autres avertissements:** Risque d'incendie, de choc électrique et de brûlures

# Warnings (Continued)

**Recommended Installation Practices:** Use only indoors or in an outdoor rated box. Turn off the circuit breaker. Installing this switch and module with the power on will expose you to dangerous voltages. Connect only copper or copper-clad wire to the switch or module.

To reduce the risk of overheating and possible damage to other equipment, use the Vzw31-SN load output to control no more than indicated.

- 600 Watts (Incandescent)
- 300 Watts (LED)
- 150 Watts (CFL)

Dimming an inductive load (by connecting to the light load wire), such as a fan or transformer, could cause damage to the dimmer, the load bearing device, or both.



To install your 2-1 Switch (Vzw31-SN), you'll need to identify the following four wires (NOTE: Neutral is not mandatory, but recommended):

- **Line:** Usually black and can also be called the, "hot" or "live" and carries 120VAC electricity into the electrical box
- **Neutral\*:** Usually white and is commonly daisy chained from box to box, usually appearing as a white wire bundle.
- **Load:** Usually black, blue or red
- **Ground:** Bare copper wire or metal fixture (if grounded)

\* Neutral is mandatory in certain installations. See page 29 for additional details.

# Warnings (Continued)

If you are having difficulties identifying wires, please consult an electrician.

**Pratiques d'installation recommandées:** Utiliser uniquement à l'intérieur ou à l'extérieur dans une boîte adaptée aux conditions extérieures. Éteignez le disjoncteur. L'installation de cet interrupteur et de ce module alors que le courant est allumé vous exposera à des tensions dangereuses. Connectez uniquement un fil de cuivre ou gainé de cuivre au commutateur ou au module.

Pour réduire le risque de surchauffe et d'endommager d'autres équipements, il est important de connecter des lumières incandescentes ayant moins de 600 watts, des lumières DEL ayant moins de 300 watts, des ampoules fluocompactes ayant moins de 150

watts ou un ventilateur utilisant moins de 1 ampère et ce dernier avec l'interrupteur en mode marche/arrêt uniquement.

La gradation d'une charge inductive, comme un ventilateur ou un transformateur, pourrait endommager le gradateur, l'interrupteur ou les deux appareils. Veuillez régler l'interrupteur en mode marche/arrêt si vous utilisez un ventilateur.

Pour installer votre interrupteur 2 en 1 (Vzw31-SN), vous devrez identifier les quatre fils suivants (REMARQUE: le neutre est optionnel, mais recommandé) :

- **Ligne:** généralement noire et peut également être appelée « chaud » ou « sous tension » et transporte l'électricité 120 VCA

# Warnings (Continued)

dans le boîtier électrique

- **Neutre:** habituellement blanc et connecté en série d'une boîte à l'autre, les fils sont habituellement attachés ensemble dans la boîte électrique
- **Charge:** habituellement noire, bleue ou rouge
- **Mise à terre:** fil de cuivre nu ou boîtier métallique (si celui-ci est mis à la terre)

Si vous rencontrez des difficultés à identifier les fils, veuillez consulter un électricien.

**Équipement médical:** Veuillez ne pas utiliser cet interrupteur pour contrôler de l'équipement médical ou nécessaire à la survie. Les appareils Z-Wave ne doivent jamais être utilisés pour contrôler la marche or l'arrêt d'équipement médical et/ou nécessaires à la survie.

# Vocabulary

Before we go into actual steps, it's important to be familiar with the vernacular used on the following pages. Please see below:

- **Line:** This is your hot wire (120V) - aka: "live" wire
- **Load:** This is the wire that runs from your light switch to what you're controlling (ie: bulb(s), fan, etc)
- **Neutral:** This is the wire that carries current back to the power source (you may not have this in your house)
- **Single-Pole:** One switch controlling one or more load(s)
- **Multi-Way:** Refers to 3-Way (2 switches, 1 load), 4-Way (3 switches, 1 load), or 5-Way setups (4 switches, 1 load)
- **Toggle ("Dumb") Switch:** Refers to your existing switch (ie: the switch(es) you had before replacing with your smart switch(es))
- **Aux Switch:** Refers to the Inovelli Aux Switch ([inov.li/aux](http://inov.li/aux))

# Step 1 - Determine Wiring Type

The first step is to determine how many switches control your load(s) (aka: light(s)).


Using the diagram on the next page, please determine what your wiring type is and remember this selection:

- **Single-Pole:** One switch controls one load (load may contain more than one light, etc).
- **Multi-Way:** Two or more switches control one load (load may contain more than one light, etc). We will use the term, "multi-way" instead of 3-Way, 4-Way, 5-Way, etc as the programming of the switch is the same regardless.




### **Single-Pole**

One switch controls one (or more) load(s).



### **Multi-Way**

Two or more switches control one (or more) load(s).



# Step 2 - Determine Switch Layout

**NOTE:** If you determined in Step #1 that your switch is single-pole, you can skip this step. This step is for multi-way setups only.

Using the diagram on the next page, please determine what your wiring layout is and remember this selection:

- **Smart Switch + Toggle Switch:** One smart switch and one (or more) toggle/existing switch (one already in your wall).
- **Smart Switch + Aux Switch:** One smart switch and one (or more) aux/add-on switch (Model #: AUX01 or [inov.li/aux](http://inov.li/aux)).
- **Smart Switch + Smart Switch:** Two (or more) smart switches.

See [inov.li/vzw31snlayout](http://inov.li/vzw31snlayout) for the pro/cons of each setup. You may not mix/match (ie: Smart + Aux + Toggle) in the same circuit.

**Switch Layout (Circle One):** Toggle, Aux, or Smart Switch(es)





### **Smart + Toggle Switch**

One Inovelli smart switch & one (or more) toggle/existing switch.



### **Smart + Aux Switch**

One Inovelli smart switch & one (or more) Inovelli aux switch (AUX01).



### **Smart Switches**

Two (or more) Inovelli smart switches.

# Step 3 - AC Power Type

In this step, we will determine if you have a neutral wire, which is typically white and located in the back in your switch gang-box (typically in a bundle of wires tied together).

Here are some signs you may have a neutral wire:

- If your house was built in the mid-1980's or later
- If there is an outlet (receptacle) near the switch
- If switches are in the same gang-box (regardless of the year your house was built)

See the next page for details on checking for a neutral wire.



After turning off your breaker, pull out the switches (**WARNING:** there may be multiple circuits in one gang-box -- please ensure all circuits are turned off). Check the back of your gang-box for a bundle of white wires. These are typically neutrals.

# Step 4 - Compatibility Check

In this step, we will determine if your switch can be installed with your current wiring setup. If not, you can see some alternate solutions on how to accomplish compatibility.

Taking the answers you circled in Steps 1-3, please see the chart on the next page to see if your switch is compatible with your setup.

**Example:** If you circled, "Multi-Way", "Toggle Switch" and "Neutral", you will see that your wiring is compatible. However, if you circled, "Multi-Way", "Toggle Switch" and "No Neutral", you will see that your wiring is not compatible and you will need to purchase an auxiliary switch ([inov.li/aux](http://inov.li/aux)).

Wiring Type	Switch Layout	Power Type	Supported
Single-Pole		Neutral	Yes
		No Neutral	Yes
Multi-Way (3+ Way)	Toggle (Switch)	Neutral	Yes
		No Neutral	No
	Aux (Switch)	Neutral	Yes
		No Neutral	Yes
	Smart (Switch)	Neutral	Yes
		No Neutral	No

**IMPORTANT:** For installations where no neutral wire is present, you may need to install a special bypass to prevent flickering and/or keep your switch powered. Bypasses can be purchased here: [inov.li/bypass](http://inov.li/bypass)

# Step 5 - Switch Installation

The last step is to physically install your switch. After you've determined your wiring type, switch layout, AC Power type and whether or not you have a compatible setup, it's time to look at the wiring schematics and install your switch.

As noted in the beginning of this section, there are many different ways your switch can be wired that if we posted them here, we'd have an encyclopedia of a manual, so all of our schematics are housed online.

Keep note of your answers from the prior steps and either scan the QR Code to the right or go to: [inov.li/vzw31snwiring](http://inov.li/vzw31snwiring) and match up your answers to the correct schematic section.



**Pre-Setup.**

# Pre-Setup Notes

**NOTE: If you plan on using your switch as an on/off switch and in a single-pole setting, you may skip this step.** If you plan on using your switch as a dimmer and/or in a multi-way setup, please continue.

Since this switch has so many different available configurations (on/off, dimmer, smart, aux, toggle, neutral, non-neutral, etc), you may need to pre-program the switch to work manually.

Luckily, it's as simple as pressing a couple buttons. Feel free to follow the steps on the next couple of pages, scan the QR Code or visit: [inov.li/vzw31snpresetup](https://inov.li/vzw31snpresetup)

Again, if you are using this switch as an on/off and single-pole setting, you can skip this section.





# Pre-Setup Example

Here's an example of how to use the chart on the next page (pg.34):

Let's say you want your switch to be a dimmer switch and you have it wired in a multi-switch setting using a toggle (dumb) switch.


Using the chart on pg. 34, you would first hold down on the bottom part of the paddle (B), while simultaneously tapping the config button (C) 3x. After seeing the LED bar change color to signify a success (orange in this case), release the bottom of the paddle.

Next, to program the switch to work in a multi-switch setup using a toggle (dumb) switch, you would then hold down on the bottom part of the paddle (B), while simultaneously tapping the config button (C) 5x. After seeing the LED bar change color to signify a success (violet in this case), release the bottom of the paddle.

# Switch Configuration

Use the button sequence below to adjust the mode of the switch according to your wiring configuration. The LED bar (D) will flash the associated color to indicate success. For a visual example of configuring to a multi-way (toggle) setting, see: [inov.li/vzw31snSCVid](http://inov.li/vzw31snSCVid).

Hubs supporting advanced settings can also update this setting via their respective apps.




Wiring Type	Sequence	Color
Single-pole	Hold on ↑ paddle (A), tap config (C) 6x, release	Cyan
Multi-Way (Toggle)	Hold on ↓ paddle (B), tap config (C) 5x, release	Violet
Multi-Way (Aux)	Hold on ↑ paddle (A), tap config (C) 5x, release	White

# Switch Mode

Use the button sequence below to adjust the mode of the switch according to the type of switch you want. The LED bar will flash the associated color to indicate success. For a visual example of changing to a dimmer, see: [inov.li/vzw31snSMVid](http://inov.li/vzw31snSMVid).

Hubs supporting advanced settings can also update this setting via their respective apps.



Switch Type	Sequence	Color
On/Off	Hold on ↑ paddle (A), tap config (C) 3x, release	Red
Dimmer	Hold on ↓ paddle (B), tap config (C) 3x, release	Orange
Smart	Hold on ↑ paddle (A), tap config (C) 4x, release	Yellow

Page intentionally left blank.

**Hub/Gateway Setup.**

# Hub/Gateway Setup Notes

As manufacturers update their hub/gateway platforms, the setup process may change. We recommend checking our website for the latest directions, by scanning the relvant QR code.

If you don't see your hub, please go to: [inov.li/vzw31sn0T](https://inov.li/vzw31sn0T)

## SmartThings



[inov.li/  
vzw31snST](https://inov.li/vzw31snST)

## Home Asst. Z-Wave JS



[inov.li/  
vzw31snZWJS](https://inov.li/vzw31snZWJS)

## Home Asst. Z-Wave JS UI



[inov.li/  
vzw31snZWJSUI](https://inov.li/vzw31snZWJSUI)

## Hubitat




[inov.li/  
vzw31snHE](https://inov.li/vzw31snHE)

# SmartThings Instructions

**COMPATIBLE HUBS:** Samsung SmartThings Hub V1, V2 and Samsung or Aeotec Hub V3 (NOTE: You may need to install a Device Handler or Edge Driver to ensure full functionality of the switch. For more info, please go to: [inov.li/vzw31snSTPrereqs](http://inov.li/vzw31snSTPrereqs)).

First, Follow the directions on page 7 to put the switch in pairing mode. When the LED bar (C) is pulsing blue proceed:

- Open the SmartThings app and click on the devices icon 
- Tap on the (+) button and click, "Add Device"
- Under the, "Scan for nearby devices", click, "Scan" and your hub will search, find and initialize the device
- If successful, the LED Bar (C) will turn green and your app will show the new switch (feel free to rename it)

# Home Assistant Instructions

**COMPATIBILITY:** We recommend either Z-Wave JS or Z-Wave JS UI (formerly Z-Wave JS2mqtt). NOTE: you will also need a compatible Z-Wave stick - a full list can be found here: Z-Wave JS = [inov.li/vzw31snZWJSsticks](https://inov.li/vzw31snZWJSsticks) or Z-Wave JS UI = [inov.li/vzw31snZWJSUIsticks](https://inov.li/vzw31snZWJSUIsticks)).

You didn't think we'd be able to fit the HA instructions in here, did you?! Please visit our website :)

## Z-Wave JS Instructions



[inov.li/vzw31snZWJS](https://inov.li/vzw31snZWJS)

## Z-Wave JS UI Instructions




[inov.li/vzw31snZWJSUI](https://inov.li/vzw31snZWJSUI)



# Hubitat Instructions

**COMPATIBLE HUBS:** Hubitat C3, C4, C5 and C7 (NOTE: You may need to install a Device Driver to ensure full functionality of the switch. We recommend doing this prior to pairing. For more info, please go to: [inov.li/vzw31snHEPrereqs](http://inov.li/vzw31snHEPrereqs)).

First, Follow the directions on page 7 to put the switch in pairing mode. When the LED bar (C) is pulsing blue proceed:

- Login to your Hubitat portal and click on the devices tab 
- Tap on the (+) Add Device button and click, "Z-Wave" under, "Add device manually"
- Click, "Start Z-Wave Pairing" and your hub should go into pairing mode, find and initialize the device
- If successful, the LED Bar (C) will turn green and your app will show the new switch (feel free to rename it)

Page intentionally left blank.

**Advanced Features.**

# Advanced Features Notes

**NOTE:** The advanced features shown below are what is built into the switch firmware, and may or may not be supported by your hub/gateway. We've confirmed they're supported on SmartThings, Hubitat, and Home Assistant (ZHA and Z-Wave2MQTT).

These switches are packed with a ton of amazing features, which include scene control (multi-tap), animated notifications, smart bulb mode, energy monitoring, and approximately 60 different parameters to customize your switch.

The manual does not have enough room to list out and explain all the parameters and advanced features. However, the following pages will direct you to the proper URL's. An overview can be found at the QR code to the right or at the following URL: [inov.li/vzw31snAF](https://inov.li/vzw31snAF)



# Switch Parameters

There are approximately 60 different parameters on this switch, making it one of the most customizable switches out there.

Due to the space constraints in this manual, we had to list them all out on our website. You can access these parameters by scanning the QR Code or by visiting: [inov.li/vzw31snparameters](http://inov.li/vzw31snparameters)

Some of the highlights include: changing the dimming speed, multi-tap speed, min/max brightness, LED bar color (individual LED's or full bar), power/energy monitoring reporting, default dim level, and so much more.



If your hub does not support parameter changes, you can program a lot of these directly from the configuration button. Please visit: [inov.li/vzw31snLC](http://inov.li/vzw31snLC)

# Other Advanced Features

To setup some of the other advanced features, such as: Animated Notifications, Scene Control, Smart Bulb Mode and Z-Wave Binding, please see the URL's below as the instructions will be different depending on the hub you're using.

- **Animated Notifications:** [inov.li/vzw31snAN](http://inov.li/vzw31snAN)
- **Scene Control:** [inov.li/vzw31snSC](http://inov.li/vzw31snSC)
- **Smart Bulb Mode:** [inov.li/vzw31snSBM](http://inov.li/vzw31snSBM)
- **Z-Wave Associations:** [inov.li/vzw31snZA](http://inov.li/vzw31snZA)

As noted on page 45, your switch has the ability to program parameters from the configuration button. To learn more, please visit: [inov.li/vzw31snLC](http://inov.li/vzw31snLC)

**Z-Wave Information.**

# About Z-Wave & This Device

As mentioned in the beginning of the manual, we're all smart home owners ourselves and have an amazing community of people who are eager to help and share their setups.

If you ever run into any issues, please do not hesitate to submit a ticket, or post in the community. We'd love to hear from you.

**Community Link:** [inov.li/community](https://inov.li/community)

**Submit a Ticket:** [inov.li/support](https://inov.li/support) (or scan the QR Code below)

Thanks again for your support and we look forward to helping you get the most out of our smart home!





# Z-Wave Association Groups

## Group 1: Lifeline

Members of this group will receive unsolicited messages related to the status of the switch.

## Group 2: Basic Set

Sends On & Off commands to associated devices.

1. Single press UP button sends BasicSet (0xFF)
2. Single press Down sends BasicSet (0x00)

## Group 3: Switch Multilevel Set

Sends set level commands to associated devices when switch is pressed.

1. Release Up or Down button sends SwitchMultiLevelSet which keeps associated devices in sync with this device.
2. Single press Up button sends SwitchMultiLevelSet(0xFF)
3. Single press Down button sends SwitchMultiLevelSet(0x00)
4. If P53(Double Up To Max) = 1, 2x press Up button sends SwitchMultiLevelSet(0X63)
5. If P54(Double Down To Min) = 1, 2x press Down button sends SwitchMultiLevelSet(0X01)

## Group 4: Switch Multilevel Start/Stop

Sends start / stop level change to associated devices, It is only dimmer mode.

1. Hold Up button sends SW\_MULTILEVEL\_START\_LEVEL\_CHANGE (Up)
2. Hold Down button sends SW\_MULTILEVEL\_START\_LEVEL\_CHANGE (Down)
3. Release Either button sends SW\_MULTILEVEL\_STOP\_LEVEL\_CHANGE

## Group 5: Double-tap Basic Set

Sends On & Off commands to associated devices.

1. 2x press UP button sends BasicSet (0xFF)
2. 2x Single press Down sends BasicSet (0x00)

## Group 6: Triple-tap Basic Set

Sends On & Off commands to associated devices.

1. 3x press UP button sends BasicSet (0xFF)
2. 3x Single press Down sends BasicSet (0x00)

# Z-Wave Association Groups

Grouping Identifier	Max Nodes	Send Commands
Group 1	0x0A	1. Central Scene Notification
		2. Multilevel Report
		3. Protection Report
		4. Device Reset Locally
		5. Meter Report
Group 2	0x0A	Basic Set
Group 3	0x0A	Switch Multilevel Set
Group 4	0x0A	Switch Multilevel Start/stop
Group 5	0x0A	Basic Set
Group 6	0x0A	Basic Set

Multilevel Switch Device Type Basic mapping:

- Basic Set (Value) maps to Multilevel Switch Set (Value)
- Basic Report (Current Value, Duration) maps to Multilevel Switch Report (Value, Duration).

# Z-Wave Parameters & Meter Info

As mentioned on page 45, there are over 60 parameters on this switch and this manual would turn into an encyclopedia if we listed them all out. The most up-to-date parameter documentation can be found on our website here: [inov.li/vzw31snparameters](http://inov.li/vzw31snparameters)

## **Meter Command Information**

Meter Type: 0x01 - Electric Meter

Meter Scale: 0x00 - kwh

Meter Scale: 0x02 - W

Rate Type: 0x01 - Import only (consumed)

# Security 2 Command Classes


Command Class	Version	Required Security Class
Z-Wave Plus Info	V2	None
Switch Multilevel	V4	S0/S2
Configuration	V4	S0/S2
Central Scene	V3	S0/S2
Association	V3	S0/S2
Multi-Channel Association	V3	S0/S2
Association Group Information	V3	S0/S2
Transport Service	V2	None
Version	V3	S0/S2

Command Class	Version	Required Security Class
Manufacturer Specific	V2	S0/S2
Device Reset Locally	V1	S0/S2
Indicator	V3	S0/S2
Powerlevel	V1	S0/S2
Security 0	V1	None
Security 2	V1	None
Supervision	V1	None
Firmware Update Meta Data	V5	S0/S2
Meter	V3	S0/S2
Protection	V2	S0/S2

# LED Bar Indicators

This switch uses its LED bar to display when certain events take place and/or during configuration modes.

Please see the chart below for more details and please visit the following URL to understand how to setup Animated Notifications: [inov.li/vzw31snAN](http://inov.li/vzw31snAN)



About	Sequence	Color / Animation
Inclusion / Exclusion	Auto-inclusion or tap Config (C) 3x rapidly	Blue / Pulse (Flashes Green if successful, Red if failed)
Factory Reset	Hold Config (C) And Hold A for 20+ sec.	Red / Slow Blink

About	Sequence	Color / Animation
Z-Wave Signal Test	Hold Config (C) for 5-10 sec.	Green / Solid (Will change to Red if no signal, Yellow if weak signal, Green for good signal)
On / Off Mode	Hold Up (A) and tap Config (C) 3x	Red / Solid
Dimmer Mode	Hold Down (B) and tap Config (C) 3x	Orange / Solid
Enable Smart Bulb Mode	Hold Up (A) and tap Config (C) 4x	Yellow / Solid
Disable Smart Bulb Mode	Hold Down (B) and tap Config (C) 4x	Blue / Solid

About	Sequence	Color / Animation
3-Way Aux Mode	Hold Up (A) and tap Config (C) 5x	White / Solid
3-Way Dumb Mode	Hold Down (B) and tap Config (C) 5x	Pink / Solid
Single Pole Mode	Hold Up (A) and tap Config (C) 6x	Cyan / Solid
Button Delay Time Set to 0	Hold Up (A) and tap Config (C) 7x	Green / Solid
Button Delay Time Set to 5 (500ms)	Hold Down (B) and tap Config (C) 7x	Yellow / Solid
Enable Local Protection Mode	Hold Up (A) and tap Config (C) 10x	Green / Solid



About	Sequence	Color / Animation
Disable Local Protection Mode	Hold Down (A) and tap Config (C) 10x	Red / Solid
Enable Remote Protection Mode	Hold Up (A) and tap Config (C) 15x	Green / Solid
Disable Remote Protection Mode	Hold Down (A) and tap Config (C) 15x	Red / Solid

The device supports the Indicator Command Class, version 3 and support the Indicator ID 0x50 (Identify) and Properties ID 0x03, 0x04 and 0x05.

# Z-Wave SmartStart

This device is compatible with SmartStart.

SmartStart enabled products can be added into a Z-Wave network by scanning the Z-Wave QR Code found on the bottom left corner of the switch, the back of the box or the insert inside the package with a controller providing SmartStart inclusion. No further action is required and the SmartStart product will be added automatically within 10 minutes of being switch on and in the network vicinity.

# Manufacturer Compatibility

This product can be operated in any Z-Wave network with other Z-Wave certified devices from other manufacturers. All non-battery operated nodes within the network will act as repeaters regardless of vendor to increase reliability of the network. Each module is designed to act as a repeater, which will re-transmit a radio frequency (RF) signal by routing the signal around obstacles and radio dead spots to ensure that the signal is received at its intended destination. The Inovelli Red Series 2-1 Switch is a security enabled Z-Wave Plus™ device. A security enabled Z-Wave Plus controller must be used in order to fully utilize the product.

# Factory Reset / Exclusion Info

To factory reset your device, hold the Configuration / Favorites Button (C) and hold paddle A for 20 seconds until the LED Bar (D) turns red and let go. The switch should blink red a few times indicating it has been factory reset. You may also use a certified Z-Wave controller to remove the device from your network to factory default. Only use these procedures in the event that the primary controller is missing or otherwise inoperable.

Exclusion will reset your device as well and can be done directly from the hub. This is helpful if you're running into issues with inclusion. To exclude a device, start the exclusion process on your hub and press the Configuration / Favorites Button (C) 3x rapidly. The LED Bar (D) will start pulsing blue and if successful, it will flash green. If unsuccessful it will flash red.

# DSK Location & Long Range

The DSK information required for some inclusion methods can be found either on the product (QR Code located at the bottom front-left of the switch), on the back of the box (QR Code located at the bottom right), or on the insert inside the box.

This switch supports Z-Wave Long Range and can be included into a network with a compatible Z-Wave Long Range hub/gateway.

To include via Long Range, enable Long Range support in your hub/gateway and add the DSK into the provisioning list. Then apply power to the switch and wait for the device to be added to the network.

## Z-Wave Local & RF Protection Command Class

Local Protection State	Description
0	Unprotected - The device is not protected, and may be operated normally via the user interface.
2	No operation possible - It is not possible at all to control a device directly via the user interface.

RF Protection State	Description
0	Unprotected - The device MUST accept and respond to all RF Commands.
1	No RF control - all runtime Commands are ignored by the device. The device MUST still respond with status on requests.
2	No RF response at all. The device will not even reply to status requests.

**Product & Contact Info.**

# Product & Contact Info Notes

As mentioned in the beginning of the manual, we're all smart home owners ourselves and have an amazing community of people who are eager to help and share their setups.

If you ever run into any issues, please do not hesitate to submit a ticket, or post in the community. We'd love to hear from you.

**Community Link:** [inov.li/community](https://inov.li/community)

**Submit a Ticket:** [inov.li/support](https://inov.li/support) (or scan the QR Code below)

Thanks again for your support and we look forward to helping you get the most out of our smart home!





# FCC/IC Statements

**FCC Caution:** Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency

# FCC/IC Statements (Cont.)

energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna, increase the separation between the equipment and receiver, connect the equipment into an outlet on a circuit different from that to which the receiver is connected or consult the dealer or an experienced radio/TV technician for help. This equipment should be installed and

operated with minimum distance 8in (20cm) between the radiator and your body.

**IC Caution:** This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

**DECLARATION DE CONFORMITE D'INDUSTRIE CANADA:** Ce périphérique a été testé et reconnu conforme aux limites spécifiées dans RSS-210. Son utilisation est soumise aux deux conditions suivantes: (1) il ne doit pas provoquer d'interférences gênantes et (2) il doit tolérer les interférences, notamment celles susceptibles d'en perturber le fonctionnement.

# Product Info

Name: Smart 2-1 Switch (On/Off or Dimmer)

SKU #: VZW31-SN

Power: 120V AC, 60Hz

Signal (Frequency): 908.42 MHz

Operating Temperature Range: 32-95° F (0-35° C)

Maximum Load (Watts): 600W Incandescent, 300W LED, 150W CFL

Not rated for inductive loads or fans.

Range: Up to 100 meters line of sight between the Wireless Controller (HUB) and the closest Z-Wave Repeater.

Certifications: UL Listed (#E528330), FCC/IC & Z-Wave Plus Certified

For indoor use. Specifications subject to change without notice due to continuing product improvement.

# Company Info / Warranty

If you run into any issues, feel free to reach out to us at: [contact@inovelli.com](mailto:contact@inovelli.com). We typically answer tickets within 24-48 hours and are staffed by actual smart home owners.

All Inovelli products come with a one (1) year warranty (defined as 365 days). This warranty protects you from breakdowns in the material or workmanship under normal use. This warranty is limited in a couple areas. Purchases must be made from Inovelli or an authorized reseller. The product should be used in the manner directed in the instructions. The product must only be used and/or installed in the United States or Canada.

For full warranty info, please visit: [inov.li/warranty](http://inov.li/warranty)

# Project Phoenix

During COVID, it was impossible for us to source Z-Wave chips and we didn't know if we would ever be able to get back into the Z-Wave game. However, in late 2022, we were able to source chips again and become the first company to release an 800 Series light switch.

We named this, "Project Phoenix" because we rose from the ashes of COVID and came out with an even more impressive Z-Wave switch than before. As usual, we relied heavily on our amazing community who was just as excited to see Z-Wave back in our portfolio. The signatures you see in the manual or box are community members who worked on this project as we believe the products should be built by people who actually use them. To see the origin of this project, as well as the journey scan the code or visit: [inov.li/phoenix](https://inov.li/phoenix)



**Thank You.**

inovelli®



# Configuration Parameters

#	Name	Size	Range	Description	Default
1	Dimming Speed (Dimming Up)	1	0-254	<p>Now in 100ms. This changes the speed in which the attached light dims up or down. A setting of 0 should turn the light immediately on or off (almost like an on/off switch). Increasing the value should slow down the transition speed.</p> <p>0-100 in ms, (0-10000 ms) (not support 1~4)            101-160 in seconds, (1-59 seconds)            161 - 254 in minutes (1-93 minutes)</p>	25(2.5s)
2	Dimming Speed (From Switch) (Dimming Up)	1	0-255	<p>Now in 100ms. This changes the speed in which the attached light dims up or down when controlled from the physical switch. A setting of 0 should turn the light immediately on or off (almost like an on/off switch). Increasing the value should slow down the transition speed. A setting of 255 should keep this in sync with parameter 1.</p> <p>0-100 in ms, (0-10000 ms) (not support 1~4)            101-160 in seconds, (1-59 seconds)            161 - 254 in minutes (1-93 minutes)            255- Keep in sync with parameter 1</p>	255

3	Ramp Rate (OFF to ON)	1	0-255	<p>Now in 100ms. This changes the speed in which the attached light dims up or down when controlled from the physical switch. A setting of 0 should turn the light immediately on or off (almost like an on/off switch). Increasing the value should slow down the transition speed. A setting of 255 should keep this in sync with parameter 1.</p> <p>0-100 in ms, (0-10000 ms) (not support 1~4)  101-160 in seconds, (1-59 seconds)  161 - 254 in minutes (1-93 minutes)  255- Keep in sync with parameter 1</p>	255
4	Ramp Rate (From Switch) (OFF to ON)	1	0-255	<p>Now in 100ms. This changes the speed in which the attached light dims up or down when controlled from the physical switch. A setting of 0 should turn the light immediately on or off (almost like an on/off switch). Increasing the value should slow down the transition speed. A setting of 255 should keep this in sync with parameter 1.</p> <p>0-100 in ms, (0-10000 ms) (not support 1~4)  101-160 in seconds, (1-59 seconds)  161 - 254 in minutes (1-93 minutes)  255- Keep in sync with parameter 1</p>	255
5	Dimming Speed (Dimming down)	1	0-255	<p>Now in 100ms. This changes the speed in which the attached light dims up or down when controlled from the physical switch. A setting of 0 should turn the light immediately on or off (almost like an on/off switch). Increasing the value should slow down the transition speed. A setting of 255 should keep this in sync with parameter 1.</p> <p>0-100 in ms, (0-10000 ms) (not support 1~4)  101-160 in seconds, (1-59 seconds)  161 - 254 in minutes (1-93 minutes)  255- Keep in sync with parameter 1</p>	255

6	Dimming Speed (From Switch) (Dimming Down)	1	0-255	<p>Now in 100ms. This changes the speed in which the attached light dims up or down when controlled from the physical switch. A setting of 0 should turn the light immediately on or off (almost like an on/off switch). Increasing the value should slow down the transition speed. A setting of 255 should keep this in sync with parameter 1.</p> <p>0-100 in ms, (0-10000 ms) (not support 1~4)  101-160 in seconds, (1-59 seconds)  161 - 254 in minutes (1-93 minutes)  255- Keep in sync with parameter 1</p>	255
7	Ramp Rate (ON to OFF)	1	0-255	<p>Now in 100ms. This changes the speed in which the attached light dims up or down when controlled from the physical switch. A setting of 0 should turn the light immediately on or off (almost like an on/off switch). Increasing the value should slow down the transition speed. A setting of 255 should keep this in sync with parameter 1.</p> <p>0-100 in ms, (0-10000 ms) (not support 1~4)  101-160 in seconds, (1-59 seconds)  161 - 254 in minutes (1-93 minutes)  255- Keep in sync with parameter 1</p>	255
8	Ramp Rate (From Switch) (ON to OFF)	1	0-255	<p>Now in 100ms. This changes the speed in which the attached light dims up or down when controlled from the physical switch. A setting of 0 should turn the light immediately on or off (almost like an on/off switch). Increasing the value should slow down the transition speed. A setting of 255 should keep this in sync with parameter 1.</p> <p>0-100 in ms, (0-10000 ms) (not support 1~4)  101-160 in seconds, (1-59 seconds)  161 - 254 in minutes (1-93 minutes)  255- Keep in sync with parameter 1</p>	255

9	Minimum Level	1	1-54	The minimum level that the dimmer allows the bulb to be dimmed to. Useful when the user has a bulb that does not turn on at a lower level	1
10	Maximum Level	1	55-99	The maximum level that the dimmer allows the bulb to be dimmed to. Useful when the user has an LED bulb that reaches its maximum level before the dimmer value of 99	99
11	Invert Switch	1	0-1	Inverts the orientation of the switch. Useful when the switch is installed upside down. Essentially up becomes down and down becomes up.  Need to ensure that the LED bar also flips upside down so that the direction of the dimming is correct.  0 - Disabled 1 - Enabled	0
12	Auto Off Timer	2	0-32767	Automatically turns the switch off after this many seconds. When the switch is turned on a timer is started that is the duration of this setting. When the timer expires, the switch is turned off.	0 (Off)
13	Default Level (Local)	1	0-99	Default level for the dimmer when it is powered on from the local switch. A setting of 0 means that the switch will return to the level that it was on before it was turned off.	0 (Previous)
14	Default Level (Z-Wave)	1	0-99	Default level for the dimmer when it is powered on from a Z-Wave command. A setting of 0 means that the switch will return to the level that it was on before it was turned off.	0 (Previous)
15	State After Power Restored	1	0-100	The state the switch should return to once power is restored after power failure. 0: OFF 1-99 :1-99 level 100 :Previous	100 (Previous)

17	Load Level Indicator Timeout	1	0-11	<p>Shows the level that the load is at for x number of seconds after the load is adjusted and then returns to the Default LED state. By default, it should always show the level when the load is ON (value 11).</p> <p>Size: 1</p> <p>Default: 11</p> <p>0 – Always Off</p> <p>1 - Turns on for 1 second after level is adjusted</p> <p>2 - Turns on for 2 seconds after level is adjusted</p> <p>3 - Turns on for 3 seconds after level is adjusted</p> <p>..</p> <p>9 - Turns on for 9 seconds after level is adjusted</p> <p>10 - Turns on for 10 seconds after level is adjusted</p> <p>11 - Always On</p>	11
18	Active Power Reports	1	0-100	<p>The power level change that will result in a new power report being sent. The value is a percentage of the previous report.</p> <p>0 = no report;</p>	10
19	Periodic Power & Energy Reports	2	0, 30~32767	<p>Time period between consecutive power &amp; energy reports being sent (in seconds). The timer is reset after each report is sent.</p>	3600
20	Energy Reports	2	0-32767	<p>The energy level change that will result in a new energy report being sent. The value is a percentage of the previous report.</p> <p>It should be 0-32767.</p> <p>This means that how many kWh of energy is added will send energy report.</p> <p>0 = no report;</p> <p>1~32767, 0.01kWh~327.67kWh;</p>	10

21	Power Type	1	0-1	0 – Non Neutral 1 - Neutral	1
22	Switch Type	1	0-2	0 – Load only 1 – Double control 2 – AUX 3 - single full wave (Only OnOff Mode)	0
50	Button Delay Time	1	0-9	Adjust the delay used in waiting for a scene command Options: 0 = 0ms (Only Up and Down delay time 0ms , config delay time 500 ms) 1 = 100ms 2 = 200ms 3 = 300ms (Up , Down and config delay time 300ms ) 4 = 400ms(Up , Down and config delay time 400ms ) 5 = 500ms(Up , Down and config delay time 500ms ) 6 = 600ms(Up , Down and config delay time 600ms ) 7 = 700ms(Up , Down and config delay time 700ms ) 8 = 800ms(Up , Down and config delay time 800ms ) 9 = 900ms(Up , Down and config delay time 900ms )	5
52	Use Smart Bulb	1	0~1	It determines whether or not the dimmer is loaded a smart bulb. 0 = Smart Bulb Mode Disable 1 = Smart Bulb Mode Enable	1
53	Double up to max	1	0~1	Double tap the "up" button to change level to 100%. -0. Disable (default) -1. Enable	0

54	Double Down to min	1	0~1	Double tap the "down" button to change level to 1%. -0. Disable (default) -1. Enable	0
<u>59</u>	<u>Association Behavior</u>	<u>1</u>	<u>0-3</u>	Association Behavior When should the switch send commands to associated devices? 0-Disable 1- Local 2- Z-wave Hub 3- Local + z-wave hub	<u>1</u>
64	LED1 Strip Effect	4	0 - 4294967295	Byte1 =Choose color, Byte2 = Choose brightness level Byte3 = Choose duration Byte4 = Choose effect	0
69	LED2 Strip Effect	4	0 - 4294967295	Byte1 =Choose color, Byte2 = Choose brightness level Byte3 = Choose duration Byte4 = Choose effect	0
74	LED3 Strip Effect	4	0 - 4294967295	Byte1 =Choose color, Byte2 = Choose brightness level Byte3 = Choose duration Byte4 = Choose effect	0
79	LED4 Strip Effect	4	0 - 4294967295	Byte1 =Choose color, Byte2 = Choose brightness level Byte3 = Choose duration Byte4 = Choose effect	0

<b>84</b>	LED5 Strip Effect	4	0 - 4294967295	Byte1 =Choose color, Byte2 = Choose brightness level Byte3 = Choose duration Byte4 = Choose effect	0
<b>89</b>	LED6 Strip Effect	4	0 - 4294967295	Byte1 =Choose color, Byte2 = Choose brightness level Byte3 = Choose duration Byte4 = Choose effect	0
<b>94</b>	LED7 Strip Effect	4	0 - 4294967295	Byte1 =Choose color, Byte2 = Choose brightness level Byte3 = Choose duration Byte4 = Choose effect	0
<b>95</b>	Default ALL LED Strip Color (When On)	1	0-255	This is the color of the LED strip in a hex representation.	170(Blue)
<b>96</b>	Default ALL LED Strip Color (When Off)	1	0-255	This is the color of the LED strip in a hex representation.	170(Blue)
<b>97</b>	Default ALL LED Strip Intensity	1	0-100	This is the intensity of the LED strip. 0 - Off 10 - Low .. 50 - Mid .. 100- High	33



98	Default ALL LED Strip Intensity (When OFF)	1	0-100	This is the intensity of the LED strip. 0 - Off 10 - Low .. 50 - Mid .. 100- High	1
99	ALL LED Strip Effect	4	0 - 4294967295	Byte1 =Choose color, Byte2 = Choose brightness level Byte3 = Choose duration Byte4 = Choose effect	0
123	Aux Switch Scenes	1	0-1	0 – Disable 1 – Enable Send Different Central Scene numbers for aux switch? See central scene section below.	0
158	Dimmer/ OnOff Mode	1	0-1	0 - Dimmer Mode 1 - OnOffMode	1
159	OnlyOneLed Mode	1	0-1	This parameter can be set only in OnOff mode. In Dimmer mode,The value is invalid. 0 – Disable All Led show 1 - Enable one led show	0
160	Firmware progress LED	1	0-1	Whether to display the effect during FLASH update 0 - Disable 1 - Enable (default)	1
161	Relay Click In OnOff Mode	1	0-1	0 - Audible Click for ON/OFF Mode ON 1 - Audible Click for ON/OFF Mode OFF	0

162	Double tap to clear notification	1	0-1	0- Enabled (Default) 1- Disabled	0
-----	----------------------------------	---	-----	-------------------------------------	---

## P99 \_ALL LED Strip Effect

Byte 4 - Effect	Byte 3 - Color	Byte 2 - Level	Byte 1 - Duration
0- Off			1-60 is in seconds calculated
1- Solid			-
2- Fast Blink			-
3- Slow Blink			61-120 is in minutes calculated
4- Pulse			-
5- Chase			by(value-60)
6- Open close	0-255	0-10	Example a value of 65 would be 65-60 =
7- Small to Big	Calculated by using a	0 - Low	5 minutes
8- Aurora	hue	-	-
9- Slow Falling	color	5 - Mid	-
10- Medium Falling	circle(value/255*360)	-	120-254
11- Fast Falling	Please see item 4.3	10 - High	Is in hours calculated by(value-120)
12- Slow Rising			Example a value of 132 would be 132-
13- Medium Rising			120 would be 12 hours.
14- Fast Rising			-
15- Medium Blink			-
16- Slow Chase			-
17- Fast Chase			-
18- Slow Siren			-
19- Fast Siren			-

P64 P69 P74 P79 P84 P89 P94\_ LED1~7 Strip Effect

<u>Byte 4 - Effect</u>	<u>Byte 3 - Color</u>	<u>Byte 2 - Level</u>	<u>Byte 1- Duration</u>
0- Off 1- Solid 2- Fast Blink 3- Slow Blink 4- Pulse 5- Chase 6- Falling 7- Rising 8- Aurora	<u>0-255</u> <u>Calculated by using a</u> <u>hue</u> <u>color</u> <u>circle(value/255*360)</u> <u>Please see item 4.3</u>	<u>0-100</u> <u>0 - Off</u> <u>..</u> <u>50 - Mid</u> <u>..</u> <u>100 - High</u>	<u>1-60 is in seconds calculated</u> <u>..</u> <u>61-120 is in minutes calculated</u> <u>by(value-60)</u> <u>Example a value of 65 would be 65-60 =</u> <u>5 minutes</u> <u>..</u> <u>120-254</u> <u>Is in hours calculated by(value-120)</u> <u>Example a value of 132 would be 132-</u> <u>120 would be 12 hours.</u> <u>..</u> <u>255 Indefinitely</u>