

## Z-Wave Protocol Implementation Conformance Statement

### Dimmer Plug

#### General Information

<b>Product Identifier:</b>	AD147-6
<b>Brand Name:</b>	Everspring
<b>Product Version:</b>	02
<b>Z-Wave Certification #:</b>	ZC10-14080010

#### Z-Wave Product Information

Supports Z-Wave Beaming Technology?	Yes
Supports Z-Wave Network Security?	Yes
Supports Z-Wave AES-128 Security S0?	No
Supports Security S2?	No
SmartStart Compatible?	No

#### Z-Wave Technical Information

<b>Z-Wave Frequency:</b>	CEPT (Europe)
<b>Z-Wave Product ID:</b>	0x0003
<b>Z-Wave Product Type:</b>	0x0003
<b>Z-Wave Hardware Platform:</b>	SD3502
<b>Z-Wave Development Kit Version:</b>	6.51.02
<b>Z-Wave Library Type:</b>	Enhanced 232 Slave
<b>Z-Wave Device Type / Role Type:</b>	Light Dimmer Switch / Always On Slave

#### Association Group Information

Group # / Max Nodes	Description
1 / 1	1. When the unit is powered for the first time, the unit will send a Notification Report to the node of Group 1. 2. When setting the unit or changing the unit's status, the unit will send a Multilevel Switch Report to the node of Group 1. 3. Device Reset: When performing Reset the unit will send Device Reset Locally Notification to the node of Group 1. 4. The minimum interval time between two reports sent from this unit to the node of Group 1 is 3 seconds. Refer to Configuration parameter 2 for more information.
2 / 4	When the button on the unit or the wall switch is pressed, the unit will send a Basic Set command to the nodes of Group 2. When the unit is OFF, Basic Set Value = 0x00. When the unit is ON, Basic Set Value = 0xFF.

# Z-Wave Protocol Implementation Conformance Statement

(Continued)

## Dimmer Plug

### Controlled Command Classes (1):

Basic