



Z-Wave Protocol Implementation Conformance Statement

Smart Power Plug

General Information

Product Identifier: NAS-WR01Z
Brand Name: Coolcam
Product Version: HW: 65 FW: 3.70
Z-Wave Certification #: ZC10-16055074

Product Features

Color White
Firmware Updatable Updatable by Manufacturer
Switch Load Capacity Volt-Ampere 12A 220V
Switch Type Push Button

Z-Wave Product Information

Supports Z-Wave Beaming Technology? Yes
Supports Z-Wave Network Security? Yes
Supports Z-Wave AES-128 Security S0? No
Supports Security S2? No
SmartStart Compatible? No

Z-Wave Technical Information

Z-Wave Frequency: CEPT (Europe)
Z-Wave Product ID: 0x1087
Z-Wave Product Type: 0x0003
Z-Wave Hardware Platform: ZM5202
Z-Wave Development Kit Version: 6.51.06
Z-Wave Library Type: Enhanced 232 Slave
Z-Wave Device Type / Role Type: On/Off Power Switch / Always On Slave

Z-Wave Protocol Implementation Conformance Statement

(Continued)

Smart Power Plug

Association Group Information

Group # / Max **Description**

Nodes

- | | |
|-------|--|
| 1 / 5 | GROUP 1 is lifeline service that assigned to plug status – ON/OFF. It enables the Plug to send reports and readings to Z Wave Controller or Z Wave Gateway. This Group Support: NOTIFICATION_REPORT_V4
METER_REPORT_V4 SWITCH_BINARY_REPORT DEVICE_RESET_LOCALLY_NOTIFICATION |
| 2 / 5 | GROUP 2 allows for sending control commands to associated devices such as Siren, relay module, lighting, etc. If current load is over the max current defined in parameter #3, the Plug will send a BASIC_SET (0xFF) to associated devices. When current load is normal, plug will send a BASIC_SET (0x00) to associated devices.
This Group Support: BASIC_SET |
| 3 / 5 | GROUP 3 allows for Send Notification to associated devices in this group. This Group Support:
NOTIFICATION_REPORT_V4 |

Supported Command Classes (13):

- | | |
|------------------------------------|-------------------------------------|
| Association Group Information V1 | Command Class Association V2 |
| Command Class Basic | Command Class Configuration |
| Command Class Device Reset Locally | Command Class Manufacturer Specific |
| Command Class Meter V4 | Command Class Notification V4 |
| Command Class Powerlevel | Command Class Switch All |
| Command Class Switch Binary | Command Class Version V2 |
| Command Class Z-Wave+ Info V2 | |

Controlled Command Classes (1):

- Command Class Basic