

## Z-Wave Protocol Implementation Conformance Statement

# Dome Door/Window Sensor Pro

### General Information

<b>Product Identifier:</b>	DMDP1
<b>Brand Name:</b>	Dome
<b>Product Version:</b>	HW: 1 FW: 1.01
<b>Z-Wave Certification #:</b>	ZC10-17065635

### Product Features

<b>Battery Quantity</b>	1
<b>Battery Type</b>	3.7V 14505
<b>Color</b>	White
<b>Firmware Updatable</b>	Updatable by Consumer by RF
<b>Sensors</b>	Air Temperature Open/Closed (Binary)
<b>Supported Notification Types</b>	Access Control Home Security

### Z-Wave Product Information

Supports Z-Wave Beaming Technology?	No
Supports Z-Wave Network Security?	Yes
Supports Z-Wave AES-128 Security S0?	Yes
Supports Security S2?	No
SmartStart Compatible?	No

# Z-Wave Protocol Implementation Conformance Statement

(Continued)

## Dome Door/Window Sensor Pro

### Z-Wave Technical Information

<b>Z-Wave Frequency:</b>	U.S. / Canada / Mexico
<b>Z-Wave Product ID:</b>	0x0201
<b>Z-Wave Product Type:</b>	0x0003
<b>Z-Wave Hardware Platform:</b>	ZM5101
<b>Z-Wave Development Kit Version:</b>	6.61.00
<b>Z-Wave Library Type:</b>	Enhanced 232 Slave
<b>Z-Wave Device Type / Role Type:</b>	Notification Sensor / Reporting Sleeping Slave

### Association Group Information

#### Group # / Max Description

##### Nodes

1 / 5	Group 1 is the “Lifeline” group, which can hold five members, typically including the main Z-Wave controller. The Door/Window Sensor sends this group a Notification Report or a Binary Sensor Report when it is opened or closed (see Configuration Parameter 3.) It also sends this group a multilevel sensor report to report the temperature and a Battery Report in response to Battery Get commands.
2 / 5	Group 2 supports up to 5 members and the Door/Window Sensor sends a Basic Set command to this group (or the Control Group) to directly trigger devices (like a light, chime, etc.) when the tamper switch either opens or closes. The value of the Basic Set command (e.g. brightness of the lamp) is configured using configuration parameter 07.
3 / 5	Group 3 supports up to 5 members and the Door/Window Sensor sends it a NOTIFICATION_REPORT or SENSOR_BINARY_REPORT when the tamper switch either opens or closes.
4 / 5	Group 4 supports up to 5 members and the Door/Window Sensor sends a Basic Set command to this group to directly trigger devices (like a light, chime, etc.) when the sensor detects the door/window opening or closing. The value of the Basic Set command (e.g. brightness of the lamp) is configured using configuration parameters 08 and 09.
5 / 5	Group 5 supports up to 5 members and the Door/Window Sensor sends it a NOTIFICATION_REPORT or SENSOR_BINARY_REPORT when the sensor detects the door/window opening.

#### Supported Command Classes (16):

Association Group Info	Association V2
Battery	Configuration
Device Reset Locally	Firmware Update Meta-Data V2
Manufacturer Specific V2	Multi-Channel Association V3
Notification V4	Powerlevel
Security S0	Sensor Binary V2
Sensor Multilevel V7	Version V2
Wake Up V2	Z-Wave Plus Info V2