

Z-Wave Protocol Implementation Conformance Statement

Smart Water Leakage Sensor

General Information

Product Identifier:	hm-hs1wl-z.eu
Brand Name:	Zipato
Product Version:	HW: 14 FW: 2.00
Z-Wave Certification #:	ZC10-17115877

Product Features

Battery Quantity	2
Battery Type	AA
Supported Notification Types	Water Alarm

Z-Wave Product Information

Supports Z-Wave Beaming Technology?	No
Supports Z-Wave Network Security?	Yes
Supports Z-Wave AES-128 Security S0?	No
Supports Security S2?	No
SmartStart Compatible?	No

Z-Wave Technical Information

Z-Wave Frequency:	CEPT (Europe)
Z-Wave Product ID:	0x1000
Z-Wave Product Type:	0x8004
Z-Wave Hardware Platform:	ZM5202
Z-Wave Development Kit Version:	6.51.09
Z-Wave Library Type:	Routing Slave
Z-Wave Device Type / Role Type:	Notification Sensor / Reporting Sleeping Slave

Association Group Information

Group # / Max Nodes	Description
---------------------	-------------

Z-Wave Protocol Implementation Conformance Statement

(Continued)

Smart Water Leakage Sensor

- 2 / 5 Association group 2: Root Device group(Binary Sensor) Maximum supported nodes are 5. Binary Sensor Command Class: Compatible with 300 series 1- Binary Sensor reports status of water or no water via Lifeline. 2- When the sensor detects status change between water and no water, the device will be triggered.
- 3 / 5 Association group 3: Root Device group(Binary Sensor) Maximum supported nodes are 5. Binary Sensor Command Class:Compatible with 300 series 1-Binary Sensor reports the removed status of water sensor. 2-When the sensor detects status change of tamper, the device will be triggered.
- 4 / 5 Association group 4: Root Device group(Notification) Maximum supported nodes are 5. 1-Notification reports reports status of detect water or no water via Lifeline. 2-When the sensor detects status change between water and no water, the device will be triggered.
- 5 / 5 Association group 5: Root Device group(Notification) Maximum supported nodes are 5. 1-Binary Sensor reports the removed status of water sensor. 2- When the sensor detects status change of tamper, the device will be triggered.

Supported Command Classes (11):

Association Group Info	Association V2
Battery	Device Reset Locally
Manufacturer Specific V2	Notification V7
Powerlevel	Sensor Binary V2
Version V2	Wake Up V2
Z-Wave Plus Info V2	