



## Z-Wave Protocol Implementation Conformance Statement

### FIBARO Motion Sensor

#### General Information

<b>Product Identifier:</b>	FGMS-001
<b>Brand Name:</b>	FIBARO
<b>Product Version:</b>	HW: 1 FW: 3.03:03.03
<b>Z-Wave Certification #:</b>	ZC10-18015921

#### Product Features

<b>Battery Quantity</b>	1
<b>Battery Type</b>	CR123A
<b>Color</b>	White
<b>Firmware Updatable</b>	Updatable by Consumer by RF
<b>Sensors</b>	Air Temperature
<b>Supported Notification Types</b>	Access Control

#### Z-Wave Product Information

Supports Z-Wave Beaming Technology?	No
Supports Z-Wave Network Security?	Yes
Supports Z-Wave AES-128 Security S0?	Yes
Supports Security S2?	No
SmartStart Compatible?	No

# Z-Wave Protocol Implementation Conformance Statement

(Continued)

## FIBARO Motion Sensor

### Z-Wave Technical Information

<b>Z-Wave Frequency:</b>	CEPT (Europe)
<b>Z-Wave Product ID:</b>	0x1001
<b>Z-Wave Product Type:</b>	0x0801
<b>Z-Wave Hardware Platform:</b>	ZM5202
<b>Z-Wave Development Kit Version:</b>	6.51.07
<b>Z-Wave Library Type:</b>	Enhanced 232 Slave
<b>Z-Wave Device Type / Role Type:</b>	Notification Sensor / Reporting Sleeping Slave

### Association Group Information

#### Group # / Max Description

##### Nodes

1 / 1	"Lifeline" reports the device status and allows for assigning single device only (main controller by default).
2 / 5	"Motion" is assigned to the motion sensor - sends motion detection and alarm cancellation frames to the associated devices.
3 / 5	"Tamper" is assigned to the tamper - sends tamper alarm and alarm cancellation frames to the associated devices.
4 / 5	"Motion BC" is assigned to the motion sensor - sends motion detection and alarm cancellation frames to the associated devices. Provides backward compatibility with controllers not supporting Z-Wave+ protocol.
5 / 5	"Tamper BC" is assigned to the tamper - sends tamper alarm and alarm cancellation frames to the associated devices. Provides backward compatibility with controllers not supporting Z-Wave+ protocol.

#### Supported Command Classes (20):

Command Class Application Status	Command Class Association Group Info
Command Class Association V2	Command Class Basic
Command Class Battery	Command Class Configuration
Command Class CRC16 Encap	Command Class Device Reset Locally
Command Class Firmware Update Md V3	Command Class Manufacturer Specific V2
Command Class Multi Channel Association V2	Command Class Notification V5
Command Class Powerlevel	Command Class Security
Command Class Sensor Alarm	Command Class Sensor Binary
Command Class Sensor Multilevel V8	Command Class Version V2
Command Class Wake Up V2	Command Class Z-Wave+ Info V2

#### Controlled Command Classes (1):

Command Class Basic
---------------------