



## Z-Wave Protocol Implementation Conformance Statement

### Plug-in Switch Mini

#### General Information

<b>Product Identifier:</b>	TZWP-102
<b>Brand Name:</b>	Telldus
<b>Product Version:</b>	HW: 1 FW: 1.00
<b>Z-Wave Certification #:</b>	ZC10-18036072

#### Product Features

<b>Switch Type</b>	Push Button
<b>Firmware Updatable</b>	Updatable by Consumer by RF
<b>Supported Meter Type</b>	Electric Energy
<b>Switch Load Capacity Watts</b>	2300
<b>Z-Wave Scene Type</b>	Scene

#### Z-Wave Product Information

Supports Z-Wave Beaming Technology?	Yes
Supports Z-Wave Network Security?	Yes
Supports Z-Wave AES-128 Security S0?	Yes
Supports Security S2?	Yes: S2 Unauthenticated
SmartStart Compatible?	No

#### Z-Wave Technical Information

<b>Z-Wave Frequency:</b>	CEPT (Europe)
<b>Z-Wave Product ID:</b>	0x0003
<b>Z-Wave Product Type:</b>	0x0003
<b>Z-Wave Hardware Platform:</b>	ZM5101
<b>Z-Wave Development Kit Version:</b>	6.71.01
<b>Z-Wave Library Type:</b>	Enhanced 232 Slave
<b>Z-Wave Device Type / Role Type:</b>	On/Off Power Switch / Always On Slave

Association Group Information

Group # / Max      Description

Nodes

1 / 5                      1. When the state of Smart Plug (turn on or off the load) is changed: 1.Set Configuration parameter 0x03 to 0:Do not send Basic Report 2. Set Configuration parameter 0x03 to 1: Send Basic Report 3. Set Configuration parameter 0x03 to 2: Send Basic Report only when Load condition is changed not by Z-WAVE Command, such as short pressing. 2. Sending Meter Report.

Supported Command Classes (19):

Association Group Info	Association V2
Basic	Configuration
Device Reset Locally	Firmware Update Meta-Data V4
Manufacturer Specific	Manufacturer Specific V2
Meter V3	Powerlevel
Scene Activation	Scene Actuator Conf
Security S0	Security S2
Supervision	Switch Binary
Transport Service V2	Version V2
Z-Wave Plus Info V2	