

Z-Wave Protocol Implementation Conformance Statement

Wall Controller

General Information

Product Identifier:	SR-ZV9003T4-RGBW-EU
Brand Name:	Sunricher
Product Version:	HW: 1 FW: 1.10
Z-Wave Certification #:	ZC10-18056116

Product Features

Firmware Updatable	Updatable by Consumer by RF
Z-Wave Scene Type	Central Scene

Z-Wave Product Information

Supports Z-Wave Beaming Technology?	Yes
Supports Z-Wave Network Security?	Yes
Supports Z-Wave AES-128 Security S0?	Yes
Supports Security S2?	Yes: S2 Unauthenticated
SmartStart Compatible?	No

Z-Wave Technical Information

Z-Wave Frequency:	CEPT (Europe)
Z-Wave Product ID:	0xa107
Z-Wave Product Type:	0x0300
Z-Wave Hardware Platform:	ZM5101
Z-Wave Development Kit Version:	6.71.01
Z-Wave Library Type:	Enhanced 232 Slave
Z-Wave Device Type / Role Type:	Wall Controller / Always On Slave

Association Group Information

Group # / Max	Description
Nodes	
1 / 1	1. Send "Command Class Device Reset Locally" to associated devices of this group to report factory reset information when factory reset the wall controller. 2. Double click a group number of the wall controller to send

Z-Wave Protocol Implementation Conformance Statement

(Continued)

Wall Controller

- 2 / 12 Press button "1" to activate group. 1.Press and hold down button "1" to switch the associated devices with a Basic Set commands. 2.Press PWM1-PWM4 buttons, direct control of associated devices using Color Switch Set commands. 3.Press and hold down PWM1-PWM4 buttons, direct control of associated devices using Color Switch Start Level Change commands. 4.Short touch or slide touch the "Color Wheel", direct control of associated devices using Color Switch Set commands. 5.Press and hold down brightness button, direct control of associated devices using Multilevel Switch Start Level Change commands. 6. Short press "play/pause" button,direct control of associated devices using Scene Activation Set, Scene ID = 255. 7. Press and hold down "play/pause" button, direct control of associated devices using Scene Conf Set, Scene ID = 255.
- 3 / 12 Press button "2" to activate group. 1.Press and hold down button "2" to switch the associated devices with a Basic Set commands. 2.Press PWM1-PWM4 buttons, direct control of associated devices using Color Switch Set commands. 3.Press and hold down PWM1-PWM4 buttons, direct control of associated devices using Color Switch Start Level Change commands. 4.Short touch or slide touch the "Color Wheel", direct control of associated devices using Color Switch Set commands. 5.Press and hold down brightness button, direct control of associated devices using Multilevel Switch Start Level Change commands. 6. Short press "play/pause" button,direct control of associated devices using Scene Activation Set, Scene ID = 255. 7. Press and hold down "play/pause" button, direct control of associated devices using Scene Conf Set, Scene ID = 255.
- 4 / 12 Press button "3" to activate group. 1.Press and hold down button "3" to switch the associated devices with a Basic Set commands. 2.Press PWM1-PWM4 buttons, direct control of associated devices using Color Switch Set commands. 3.Press and hold down PWM1-PWM4 buttons, direct control of associated devices using Color Switch Start Level Change commands. 4.Short touch or slide touch the "Color Wheel", direct control of associated devices using Color Switch Set commands. 5.Press and hold down brightness button, direct control of associated devices using Multilevel Switch Start Level Change commands. 6. Short press "play/pause" button,direct control of associated devices using Scene Activation Set, Scene ID = 255. 7. Press and hold down "play/pause" button, direct control of associated devices using Scene Conf Set, Scene ID = 255.

Supported Command Classes (14):

Association Group Info	Association V2
Central Scene V3	Device Reset Locally
Firmware Update Meta-Data V4	Manufacturer Specific V2
Multi-Channel Association V3	Powerlevel
Security S0	Security S2
Supervision	Transport Service V2
Version V2	Z-Wave Plus Info V2

Controlled Command Classes (5):

Basic V2	Scene Activation
Scene Actuator Conf	Switch Color V3
Switch Multilevel V4	