

Z-Wave Protocol Implementation Conformance Statement

Wall Controller

General Information

Product Identifier:	SR-ZV9002T4-CCT-RU
Brand Name:	Sunricher
Product Version:	HW: 1 FW: 1.10
Z-Wave Certification #:	ZC10-18066134

Product Features

Z-Wave Scene Type	Scene & Central Scene
Firmware Updatable	Updatable by Consumer by RF

Z-Wave Product Information

Supports Z-Wave Beaming Technology?	Yes
Supports Z-Wave Network Security?	Yes
Supports Z-Wave AES-128 Security S0?	Yes
Supports Security S2?	Yes: S2 Unauthenticated
SmartStart Compatible?	No

Z-Wave Technical Information

Z-Wave Frequency:	Russia
Z-Wave Product ID:	0xa103
Z-Wave Product Type:	0x031A
Z-Wave Hardware Platform:	ZM5101
Z-Wave Development Kit Version:	6.71.01
Z-Wave Library Type:	Enhanced 232 Slave
Z-Wave Device Type / Role Type:	Wall Controller / Always On Slave

Association Group Information

Group # / Max	Description
Nodes	
1 / 1	1. Send "Command Class Device Reset Locally" to associated devices of this group to report factory reset information when factory reset the wall controller. 2. Double click a group number of the wall controller to send

Z-Wave Protocol Implementation Conformance Statement

(Continued)

Wall Controller

- 2 / 12 1. Press and hold down button "1" to activate group in order to switch the associated devices with a Basic Set or dim these devices by using the two brightness buttons or adjust color temperature by using color wheel. 2. Short press Scene button S1/S2/S3/S4, direct control of associated devices using Scene Activation Set, Scene ID = 0x10 / 0x20 / 0x30 / 0x40. 3. Press and hold down Scene button S1/S2/S3/S4, direct control of associated devices using Scene Conf Set, Scene ID = 0x10 / 0x20 / 0x30 / 0x40.
- 3 / 12 1. Press and hold down button "2" to activate group in order to switch the associated devices with a Basic Set or dim these devices by using the two brightness buttons or adjust color temperature by using color wheel. 2. Short press Scene button S1/S2/S3/S4, direct control of associated devices using Scene Activation Set, Scene ID = 0x10 / 0x20 / 0x30 / 0x40. 3. Press and hold down Scene button S1/S2/S3/S4, direct control of associated devices using Scene Conf Set, Scene ID = 0x10 / 0x20 / 0x30 / 0x40.
- 4 / 12 1. Press and hold down button "3" to activate group in order to switch the associated devices with a Basic Set or dim these devices by using the two brightness buttons or adjust color temperature by using color wheel. 2. Short press Scene button S1/S2/S3/S4, direct control of associated devices using Scene Activation Set, Scene ID = 0x10 / 0x20 / 0x30 / 0x40. 3. Press and hold down Scene button S1/S2/S3/S4, direct control of associated devices using Scene Conf Set, Scene ID = 0x10 / 0x20 / 0x30 / 0x40.
- 5 / 12 1. Press and hold down button "4" to activate group in order to switch the associated devices with a Basic Set or dim these devices by using the two brightness buttons or adjust color temperature by using color wheel. 2. Short press Scene button S1/S2/S3/S4, direct control of associated devices using Scene Activation Set, Scene ID = 0x10 / 0x20 / 0x30 / 0x40. 3. Press and hold down Scene button S1/S2/S3/S4, direct control of associated devices using Scene Conf Set, Scene ID = 0x10 / 0x20 / 0x30 / 0x40.

Supported Command Classes (14):

Association Group Info	Association V2
Central Scene V3	Device Reset Locally
Firmware Update Meta-Data V4	Manufacturer Specific V2
Multi-Channel Association V3	Powerlevel
Security S0	Security S2
Supervision	Transport Service V2
Version V2	Z-Wave Plus Info V2

Controlled Command Classes (3):

Basic V2	Switch Color V2
Switch Multilevel V2	