



Z-Wave Protocol Implementation Conformance Statement

Wall Controller

General Information

Product Identifier: SR-ZV9002T4-CCT-RU
Brand Name: Sunricher
Product Version: HW: 1 FW: 1.10
Z-Wave Certification #: ZC10-18066134

Product Features

Z-Wave Scene Type Scene & Central Scene
Firmware Updatable Updatable by Consumer by RF

Z-Wave Product Information

Supports Z-Wave Beaming Technology? Yes
Supports Z-Wave Network Security? Yes
Supports Z-Wave AES-128 Security S0? Yes
Supports Security S2? Yes: S2 Unauthenticated
SmartStart Compatible? No

Z-Wave Technical Information

Z-Wave Frequency: Russia
Z-Wave Product ID: 0xa103
Z-Wave Product Type: 0x031A
Z-Wave Hardware Platform: ZM5101
Z-Wave Development Kit Version: 6.71.01
Z-Wave Library Type: Enhanced 232 Slave
Z-Wave Device Type / Role Type: Wall Controller / Not Z-Wave Plus

Association Group Information

Group # / Max	Description
Nodes	
1 / 1	1. Send "Command Class Device Reset Locally" to associated devices of this group to report factory reset information when factory reset the wall controller. 2. Double click a group number of the wall controller to send

Z-Wave Protocol Implementation Conformance Statement

(Continued)

Wall Controller

- 2 / 12 1. Press and hold down button "1" to activate group in order to switch the associated devices with a Basic Set or dim these devices by using the two brightness buttons or adjust color temperature by using color wheel. 2. Short press Scene button S1/S2/S3/S4, direct control of associated devices using Scene Activation Set, Scene ID = 0x10 / 0x20 / 0x30 / 0x40. 3. Press and hold down Scene button S1/S2/S3/S4, direct control of associated devices using Scene Conf Set, Scene ID = 0x10 / 0x20 / 0x30 / 0x40.
- 3 / 12 1. Press and hold down button "2" to activate group in order to switch the associated devices with a Basic Set or dim these devices by using the two brightness buttons or adjust color temperature by using color wheel. 2. Short press Scene button S1/S2/S3/S4, direct control of associated devices using Scene Activation Set, Scene ID = 0x10 / 0x20 / 0x30 / 0x40. 3. Press and hold down Scene button S1/S2/S3/S4, direct control of associated devices using Scene Conf Set, Scene ID = 0x10 / 0x20 / 0x30 / 0x40.
- 4 / 12 1. Press and hold down button "3" to activate group in order to switch the associated devices with a Basic Set or dim these devices by using the two brightness buttons or adjust color temperature by using color wheel. 2. Short press Scene button S1/S2/S3/S4, direct control of associated devices using Scene Activation Set, Scene ID = 0x10 / 0x20 / 0x30 / 0x40. 3. Press and hold down Scene button S1/S2/S3/S4, direct control of associated devices using Scene Conf Set, Scene ID = 0x10 / 0x20 / 0x30 / 0x40.
- 5 / 12 1. Press and hold down button "4" to activate group in order to switch the associated devices with a Basic Set or dim these devices by using the two brightness buttons or adjust color temperature by using color wheel. 2. Short press Scene button S1/S2/S3/S4, direct control of associated devices using Scene Activation Set, Scene ID = 0x10 / 0x20 / 0x30 / 0x40. 3. Press and hold down Scene button S1/S2/S3/S4, direct control of associated devices using Scene Conf Set, Scene ID = 0x10 / 0x20 / 0x30 / 0x40.

Supported Command Classes (14):

Command Class Association Group Info	Command Class Association V2
Command Class Central Scene V3	Command Class Device Reset Locally
Command Class Firmware Update Md V4	Command Class Manufacturer Specific V2
Command Class Multi Channel Association V3	Command Class Powerlevel
Command Class Security	Command Class Security 2
Command Class Supervision	Command Class Transport Service V2
Command Class Version V2	Command Class Z-Wave+ Info V2

Controlled Command Classes (3):

Command Class Basic V2	Command Class Switch Color V2
Command Class Switch Multilevel V2	