



Z-Wave Protocol Implementation Conformance Statement

Heatit Z-Push Button 8

General Information

Product Identifier:	Heatit Z-Push Button 8
Brand Name:	HEATIT
Product Version:	HW: 1 FW: 1.26
Z-Wave Certification #:	ZC10-19086706

Product Features

Firmware Updatable	Updatable by Consumer by RF
Z-Wave Scene Type	Central Scene

Z-Wave Product Information

Supports Z-Wave Beaming Technology?	No
Supports Z-Wave Network Security?	Yes
Supports Z-Wave AES-128 Security S0?	Yes
Supports Security S2?	Yes: S2 Unauthenticated
SmartStart Compatible?	No

Z-Wave Technical Information

Z-Wave Frequency:	CEPT (Europe)
Z-Wave Product ID:	0xa305
Z-Wave Product Type:	0x0300
Z-Wave Hardware Platform:	ZM5101
Z-Wave Development Kit Version:	6.71.03
Z-Wave Library Type:	Enhanced 232 Slave
Z-Wave Device Type / Role Type:	Wall Controller / Portable Slave

Association Group Information

Group # / Max	Description
Nodes	
1 / 5	1. Send Command Class "Device Reset Locally Notification V1" to associated devices of this group to report factory reset information when factory reset the remote control. 2. When remote control battery power value

Z-Wave Protocol Implementation Conformance Statement

(Continued)

Heatit Z-Push Button 8

- 2 / 5 Short press I/O button of Group 2 to send ON/OFF command to associated devices of this group using Command Class "Basic Set V2". Press and hold down I/O button of Group 2 to send light intensity increase/decrease command to associated devices of this group using Command Class "Multilevel V4".
- 3 / 5 Short press I/O button of Group 3 to send ON/OFF command to associated devices of this group using Command Class "Basic Set V2". Press and hold down I/O button of Group 3 to send light intensity increase/decrease command to associated devices of this group using Command Class "Multilevel V4".
- 4 / 5 Short press I/O button of Group 4 to send ON/OFF command to associated devices of this group using Command Class "Basic Set V2". Press and hold down I/O button of Group 4 to send light intensity increase/decrease command to associated devices of this group using Command Class "Multilevel V4".
- 5 / 5 Short press I/O button of Group 5 to send ON/OFF command to associated devices of this group using Command Class "Basic Set V2". Press and hold down I/O button of Group 5 to send light intensity increase/decrease command to associated devices of this group using Command Class "Multilevel V4".

Supported Command Classes (17):

- | | |
|--|--|
| Command Class Association Group Info | Command Class Association V2 |
| Command Class Battery | Command Class Central Scene V3 |
| Command Class Configuration | Command Class Device Reset Locally |
| Command Class Firmware Update Md V4 | Command Class Manufacturer Specific V2 |
| Command Class Multi Channel Association V3 | Command Class Powerlevel |
| Command Class Security | Command Class Security 2 |
| Command Class Supervision | Command Class Transport Service V2 |
| Command Class Version V2 | Command Class Wake Up V2 |
| Command Class Z-Wave+ Info V2 | |

Controlled Command Classes (2):

- | | |
|---------------------|------------------------------------|
| Command Class Basic | Command Class Switch Multilevel V4 |
|---------------------|------------------------------------|