



Z-Wave Protocol Implementation Conformance Statement

Vitrum VI EU on-off 6 triac 921.7 MHz

General Information

Product Identifier:	01EB6S263
Brand Name:	Vitrum
Product Version:	HW: 1 FW: 5.50:01.01
Z-Wave Certification #:	ZC10-20076933

Product Features

Switch Load Capacity Current	
Switch Load Capacity Watts	
Switch Type	Decorator Paddle Push
Z-Wave Scene Type	Central Scene
Loads Controlled	10
Switch Load Capacity Volt-Ampere	
Neutral Wire Required	No
Firmware Updatable	Not Updatable

Z-Wave Product Information

Supports Z-Wave Beaming Technology?	Yes
Supports Z-Wave Network Security?	Yes
Supports Z-Wave AES-128 Security S0?	No
Supports Security S2?	Yes: S2 Unauthenticated
SmartStart Compatible?	No

Z-Wave Protocol Implementation Conformance Statement

(Continued)

Vitrum VI EU on-off 6 triac 921.7 MHz

Z-Wave Technical Information

Z-Wave Frequency:	South Korea
Z-Wave Product ID:	0x2062
Z-Wave Product Type:	0x8161
Z-Wave Hardware Platform:	ZM5202
Z-Wave Development Kit Version:	6.71.03
Z-Wave Library Type:	Enhanced 232 Slave
Z-Wave Device Type / Role Type:	On/Off Power Switch / Always On Slave

Association Group Information

Group # / Max Description

Nodes

1 / 20	Lifeline report Add Controller Node ID to the list of Node ID destinations belonging to the Lifeline Group, in order to let the controller receive Central Scene Notification report and Device Reset Locally Notification reports. Lifeline report with End Point information Add both Controller Node ID and Controller End Point to the list of End Points belonging to the Lifeline Group, in order to let the controller receive Central Scene Notification report with the End Point source address information. That may be achieved by sending the Multichannel Association Set Command Class and filling "Multi Channel Node ID" field with the Controller Node ID and "End Point" field with the Controller End Point.
2 / 20	Add Node IDs to the list of Node ID destinations belonging to the Button 1 Control group in order control the added nodes by sending Basic Set commands.
3 / 20	Add Node IDs to the list of Node ID destinations belonging to the Button 2 Control group in order to control the added nodes by sending Basic Set commands.
4 / 20	Add Node IDs to the list of Node ID destinations belonging to the Button 3 Control group in order to control the added nodes by sending Basic Set commands.
5 / 20	Add Node IDs to the list of Node ID destinations belonging to the Button 4 Control group in order to control the added nodes by sending Basic Set commands.
6 / 20	Add Node IDs to the list of Node ID destinations belonging to the Button 5 Control group in order to control the added nodes by sending Basic Set commands.
7 / 20	Add Node IDs to the list of Node ID destinations belonging to the Button 6 Control group in order to control the added nodes by sending Basic Set commands.

Supported Command Classes (17):

Association Group Info	Association V2
Basic	Central Scene V3
Configuration V2	Device Reset Locally
Manufacturer Specific V2	Multi-Channel Association V3
Multi-Channel V4	Node Naming
Powerlevel	Security S2
Supervision	Switch Binary