

## Z-Wave Protocol Implementation Conformance Statement

# Z-Wave Dim Remote Control

### General Information

<b>Product Identifier:</b>	SR-ZV9001K2-DIM
<b>Brand Name:</b>	Sunricher
<b>Product Version:</b>	HW: 1 FW: 1.26
<b>Z-Wave Certification #:</b>	ZC10-20066922

### Product Features

<b>Battery Quantity</b>	1
<b>Battery Type</b>	CR2450
<b>Firmware Updatable</b>	Updatable by Consumer by RF
<b>Z-Wave Scene Type</b>	Central Scene

### Z-Wave Product Information

Supports Z-Wave Beaming Technology?	No
Supports Z-Wave Network Security?	Yes
Supports Z-Wave AES-128 Security S0?	Yes
Supports Security S2?	Yes: S2 Unauthenticated
SmartStart Compatible?	No

### Z-Wave Technical Information

<b>Z-Wave Frequency:</b>	CEPT (Europe)
<b>Z-Wave Product ID:</b>	0xa30f
<b>Z-Wave Product Type:</b>	0x0300
<b>Z-Wave Hardware Platform:</b>	ZM5101
<b>Z-Wave Development Kit Version:</b>	6.71.03
<b>Z-Wave Library Type:</b>	Enhanced 232 Slave
<b>Z-Wave Device Type / Role Type:</b>	Wall Controller / Portable Slave

### Association Group Information

Group # / Max	Description
---------------	-------------

# Z-Wave Protocol Implementation Conformance Statement

(Continued)

## Z-Wave Dim Remote Control

2 / 5      Short press button 1 of Group 2 to send ON/OFF command to associated devices of this group using Command Class "Basic Set V2". Press and hold down button 2 of Group 2 to send light intensity increase/decrease command to associated devices of this group using Command Class "Multilevel V4".

### Supported Command Classes (17):

Association Group Info	Association V2
Battery	Central Scene V3
Configuration	Device Reset Locally
Firmware Update Meta-Data V4	Manufacturer Specific V2
Multi-Channel Association V3	Powerlevel
Security S0	Security S2
Supervision	Transport Service V2
Version V2	Wake Up V2
Z-Wave Plus Info V2	

### Controlled Command Classes (2):

Basic	Switch Multilevel V4
-------	----------------------